

A

Abbreviations and Their Meanings 0-18
 ABS Automated Bleed Procedure 5-191
 ABS Description and Operation 5-205
 ABS Indicator Always On 5-188
 ABS Indicator Inoperative 5-189
 Accelerator Pedal Position (APP) Sensor
 Replacement
 Engine Controls - 4.8L, 5.3L, 6.0L 6-753
 Accumulator Assembly, Spacer Plate and
 Gaskets
 4L60-E/4L65-E 7-218
 Acid Rain 8-681
 Air Cleaner
 Assembly Replacement
 Engine Controls - 4.8L, 5.3L, 6.0L 6-814
 Element Replacement
 Engine Controls - 4.8L, 5.3L, 6.0L 6-814
 Resonator Outlet Duct Replacement
 Engine Controls - 4.8L, 5.3L, 6.0L 6-815
 Air Conditioning (A/C) Diagnostics -
 Pressure Zone A 1-8
 Air Conditioning (A/C) Diagnostics -
 Pressure Zone B 1-10
 Air Conditioning (A/C) Diagnostics -
 Pressure Zone C 1-12
 Air Conditioning (A/C) Diagnostics -
 Pressure Zone D 1-13
 Air Conditioning (A/C) Refrigerant Pressure
 Sensor Replacement 1-38
 Air Conditioning (A/C) System - Noise
 Diagnosis 1-19
 Air Conditioning (A/C) System
 Performance Test 1-5
 Air Distributor Duct Replacement - HVAC 1-50
 Air Inlet Grille Panel
 Replacement 8-58
 Air Intake System Description
 Engine Controls - 4.8L, 5.3L, 6.0L 6-825
 Air Outlet Replacement - Instrument
 Panel - HVAC 1-51
 Air Pressure Test 0-114
 Air/Wind Noise Diagnosis 0-114
 Alcohol/Contaminants-in-Fuel Diagnosis
 Engine Controls - 4.8L, 5.3L, 6.0L 6-727, 6-728
 Altitude vs Barometric Pressure
 Engine Controls - 4.8L, 5.3L, and 6.0L 6-410
 Aluminum Wheel
 Porosity Repair 3-69
 Refinishing 3-69
 Ambient Light Sensor Replacement -
 Lighting Systems 8-637
 Amplifier Replacement - Entertainment 11-53
 Antenna Cable Replacement -
 Entertainment 11-56
 Antenna Module Replacement -
 Entertainment 11-56
 Arrows and Symbols, Description 0-4
 Ashtray Replacement 8-499
 Assist Rod
 Replacement - Hood 8-49
 Assist Step
 Replacement 8-420

Audible Warnings Description and
 Operation 8-529
 Audio System Troubleshooting
 Hints - Entertainment 11-45
 Automatic Transmission Fluid/Filter
 Replacement
 4L60-E/4L65-E 7-185
 Automatic Transmission Oil Cooler Flushing
 and Flow Test
 4L60-E/4L65-E 7-156, 7-161
 Automatic Transmission Range
 Selector Cable
 Adjustment
 4L60-E/4L65-E 7-179
 Replacement
 4L60-E/4L65-E 7-177
 Automatic Transmission Range Selector
 Cable Bracket
 Replacement
 4L60-E/4L65-E 7-179
 Axle Housing Inspection
 Rear Drive Axle 4-52
 Axle Identification - Rear 0-13
 Axle Replacement, Rear
 Rear Drive Axle 4-51

B

Backfire
 Engine Controls - 4.8L, 5.3L, 6.0L 6-698
 Backing Patch Fabrication - Plastic Panel
 Information and Repair 8-694
 Backlash Adjustment
 Rear Drive Axle 4-57
 Backup Lamp Bulb Replacement - Lighting
 Systems 8-666
 Backup Lamp Replacement - Lighting
 Systems 8-665
 Backup Lamps Always On - Lighting
 Systems 8-604
 Backup Lamps Inoperative - Lighting
 Systems 8-605
 Ball Joint Replacement, Lower
 Front Suspension 3-25
 Ball Joint Replacement, Upper
 Front Suspension 3-24
 Base Engine Misfire with Abnormal Internal
 Lower Engine Noises
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-35
 Base Engine Misfire with Abnormal Valve
 Train Noise
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-35
 Base Engine Misfire with Coolant
 Consumption
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-36
 Base Engine Misfire with Excessive Oil
 Consumption
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-36
 Base Engine Misfire without Internal
 Engine Noises
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-34
 Basecoat/Clearcoat Paint Systems 8-677
 Battery Charging - Engine Electrical 6-375

- Battery Common Causes of Failure -
 Engine Electrical 6-378
- Battery Description and Operation 6-407
- Battery Electrical Drain/Parasitic Load Test 6-376
- Battery Inspection/Test - Engine Electrical 6-373
- Battery Negative Cable
 Disconnect/Connect Procedure - Engine
 Electrical 6-388
 Replacement - Engine Electrical 6-388
- Battery Positive Cable
 Replacement - Engine Electrical 6-389, 6-390
- Battery Replacement - Engine Electrical 6-393
- Battery Tray
 Replacement - Engine Electrical 6-396
- Battery Usage Specifications - Engine
 Electrical 6-360
- Bearings Inspection
 Rear Drive Axle 4-52
- Bezel Replacement
 Console Shift Lever 8-519
- Blade Element Cleaning 8-1043
- Bleeding the Power Steering System 2-13
- Blower
 Diagnosis
 Operates Continuously (A/C - Manual) 1-88
- Blower Motor - Noise Diagnosis 1-18
- Blower Motor Replacement - HVAC 1-50
- Blower Motor Resistor Assembly
 Replacement - HVAC 1-49
- Body Control Module
 Replacement
 Body Control System 8-34
- Body Control Module Programming/RPO
 Configuration
 Body Control System 8-37
- Body Control System Description and
 Operation 8-37
- Body Side Panel
 Replacement - Outer 8-209
 Sectioning - Outer 8-214, 8-219
- Brake Assist System Description and
 Operation - Hydraulic Brakes 5-61
- Brake Assist System Diagnosis
 Hydraulic Brakes 5-26
- Brake Caliper
 Bracket Replacement - Front
 Disc Brakes 5-97
- Bracket Replacement - Rear
 Disc Brakes 5-101
- Inspection
 Disc Brakes 5-66
- Overhaul - Front
 Disc Brakes 5-83
- Overhaul - Rear
 Disc Brakes 5-85
- Replacement - Front
 Disc Brakes 5-79
- Replacement - Rear
 Disc Brakes 5-81
- Brake Component Specifications
 Hydraulic Brakes 5-3
- Brake Fluid Loss
 Hydraulic Brakes 5-16
- Brake Hose Replacement - Front
 Hydraulic Brakes 5-48
- Brake Hose Replacement - Rear
 Hydraulic Brakes 5-51
- Brake Pad Inspection
 Disc Brakes 5-65
- Brake Pads
 Replacement - Front
 Disc Brakes 5-69
- Replacement - Rear
 Disc Brakes 5-74
- Brake Pedal Assembly Replacement
 Hydraulic Brakes 5-42
- Brake Pedal Excessive Effort
 Hydraulic Brakes 5-14
- Brake Pedal Excessive Travel
 Hydraulic Brakes 5-13
- Brake Pedal Pulsation
 Hydraulic Brakes 5-11
- Brake Pedal Pushrod Inspection
 Hydraulic Brakes 5-31
- Brake Pedal Travel Measurement
 and Inspection
 Hydraulic Brakes 5-28
- Brake Pipe and Hose Inspection
 Hydraulic Brakes 5-31
- Brake Pipe Replacement
 Hydraulic Brakes 5-43
- Brake Pressure Modulator Valve
 Replacement - ABS 5-194
- Brake Rotor
 Refinishing
 Disc Brakes 5-118
- Replacement - Front
 Disc Brakes 5-106
- Replacement - Rear
 Disc Brakes 5-110
- Surface and Wear Inspection
 Disc Brakes 5-64
- Thickness Measurement
 Disc Brakes 5-64
- Brake System Bleeding
 Hydraulic Brakes 5-54, 5-55
- Brake System Diagnosis
 Hydraulic Brakes 5-22
- Brake System External Leak Inspection
 Hydraulic Brakes 5-29
- Brake System Flushing
 Hydraulic Brakes 5-56
- Brake System Internal Leak Test
 Hydraulic Brakes 5-29
- Brake System Noise
 Hydraulic Brakes 5-11
- Brake System Slow Release - Hydraulic
 Brakes 5-16
- Brake System Specifications
 Hydraulic Brakes 5-3
- Brake System Vacuum Source Test -
 Hydraulic Brakes 5-28
- Brake System Vehicle Road Test
 Hydraulic Brakes 5-27
- Brake Warning Indicator Always On
 Hydraulic Brakes 5-8

Brake Warning Indicator Inoperative	
Hydraulic Brakes	5-9
Brakes Drag	
Hydraulic Brakes	5-15
Braking Action Uneven - Front to Rear	
Hydraulic Brakes	5-13
Braking Action Uneven - Pulls to One Side	
Hydraulic Brakes	5-12
Bumper Replacement	
Front	8-136
Burnishing Pads and Rotors	
Disc Brakes	5-78
Buzz Noise or High Frequency	
Rattle Sound	
4L60-E/4L65-E	7-174

C

Camshaft	
and Bearings Cleaning and Inspection	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-212
Bearing Installation	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-215
Bearing Removal	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-209
Installation	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-269
Removal	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-175
Camshaft Position (CMP) Sensor	
Replacement	
Engine Controls - 4.8L, 5.3L, 6.0L	6-812
Camshaft Replacement	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-131
Capacities - Approximate Fluid	0-33
Cargo Box Cover Hinge Bracket	
Replacement	8-73
Cargo Box Side Panel	
Replacement - Inner	8-255
Carpet Replacement	
Front - Interior Trim	8-534
Rear - Interior Trim	8-535
Case Porosity Repair	
4L60-E/4L65-E	7-155
Caster and Camber Adjustment, Front	3-15
Catalytic Converter Replacement - Engine	
Exhaust	6-840
Caution, Notice and Important, Definition of	P-3
Change Engine Oil Indicator Always On	8-483
Charge Indicator	
Always On - Engine Electrical	6-381
Inoperative - Engine Electrical	6-381
Charging System Description and Operation	6-408
Charging System Test - Engine Electrical	6-379
Checking and Adding Fluid	
Power Steering System	2-16
Chime Always On	
Instrument Panel, Gages and Console	8-485

Chime Inoperative	
Instrument Panel, Gages and Console	8-487
CKP System Variation Learn Procedure	
Engine Controls - 4.8L, 5.3L, 6.0L	6-744
Cleanliness and Care	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-310
Clearcoat Repair Specifications	
3M Products	8-675
Meguiar Products	8-676
Clearcoat Repair without Repainting	8-680
Clearcoat Thickness	8-682
Clutch Plate Diagnosis	
4L60-E/4L65-E	7-151
Coding Keys and Lock Cylinders	0-25
Coil Spring Replacement	
Rear Suspension	3-62
Compartment Lid	
Replacement - Rear	8-98
Compartment Lid Trim	
Replacement - Rear	8-90
Compartment Sill Plate	
Replacement - Rear	8-89
Component Location	
4L60-E/4L65-E	7-34
Component Resistance	
4L60-E/4L65-E	7-17
Component Specifications	
Disc Brakes	5-63
Component Views	
ABS	5-155
Automatic Transmission Electronic	
4L60-E/4L65-E	7-20
Body Control System	8-15
Body Rear End	8-65
Cruise Control	11-6
Data Link Communications	8-276
Engine Controls - 4.8L, 5.3L, 6.0L	6-430
Engine Cooling	6-319
Engine Electrical	6-363
Entertainment	11-29
Garage Door Opener	11-70
Horns	8-424
Hydraulic Brakes	5-5
Instrument Panel, Gages and Console	8-444
Keyless Entry	11-77
Lighting Systems	8-560
Power Door Systems	8-302
Power Roof Systems	8-720
Compressor Hose Assembly	
Replacement - HVAC	1-31
Compressor Oil Balancing - HVAC	1-27
Compressor Relay Replacement - HVAC	1-35
Compressor Replacement - HVAC	1-28
Condenser Replacement - HVAC	1-40
Connector Description	
Automatic Transmission Inline 20-Way	
4L60-E/4L65-E	7-243
Connector End Views	
ABS	5-156
Automatic Transmission Inline 20-Way	
4L60-E/4L65-E	7-38
Automatic Transmission Internal	
4L60-E/4L65-E	7-39

- Connector End Views (cont.)
 Automatic Transmission Related
 4L60-E/4L65-E 7-40
 Body Control System 8-16
 Body Rear End 8-67
 Data Link Communications 8-279
 Engine Controls - 4.8L, 5.3L, 6.0L 6-441
 Engine Cooling 6-320
 Engine Electrical 6-365
 Entertainment 11-33
 Garage Door Opener 11-71
 Horns 8-426
 Hydraulic Brakes 5-7
 Instrument Panel, Gages and Console 8-446
 Keyless Entry 11-78
 Lighting Systems 8-565
 Power Door Systems 8-306
 Power Roof Systems 8-724
 Powertrain Control Module (PCM)
 Engine Controls - 4.8L, 5.3L, 6.0L 6-438
- Console
 Armrest Replacement
 Front Floor 8-522
 Replacement 8-520
 Shift Lever Bezel Replacement 8-519
 Trim Plate Replacement - Upper 8-516
- Console Compartment Door
 Hinge Replacement 8-512
 Latch Replacement 8-514
 Lock Cylinder Replacement 8-513
- Constant Noise
 Rear Drive Axle 4-18
- Control and Shift Solenoids
 Replacement
 4L60-E/4L65-E 7-210
- Control Arm Bracket Replacement, Lower
 Front Suspension 3-36
- Control Arm Replacement, Lower
 Front Suspension 3-32
- Control Arm Replacement, Rear Axle Lower
 Rear Suspension 3-53
- Control Arm Replacement, Upper
 Front Suspension 3-30
 Rear Suspension 3-52
- Control Module References
 Body Control Systems 8-33
- Conversion Table, English/Metric 0-3
- Coolant Air Bleed Hose
 Replacement 6-346
- Coolant Air Bleed Pipe
 Assembly Replacement 6-344
 Cleaning and Inspection
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-246
 Installation
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-295
 Removal
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-161
- Coolant Heater
 Cord Replacement 6-356
 Inoperative 6-332
 Replacement 6-355
- Coolant in Combustion Chamber
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-40
- Coolant in Engine Oil
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-40
- Cooling Fan
 Always On 6-325
 Inoperative 6-326
 Relay Replacement 6-340, 6-341
 Replacement - Electric 6-339
- Cooling System Description and Operation 6-357
- Cooling System Leak Testing 6-333
- Courtesy Lamps Always On - Lighting
 Systems 8-606
- Courtesy Lamps Inoperative - Lighting
 Systems 8-607
- Crankcase Ventilation Hoses/Pipes
 Replacement
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-73
- Crankcase Ventilation System
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-45
- Crankshaft
 Bearings Cleaning and Inspection
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-187
 Bearings Installation
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-262
 Bearings Removal
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-178
- Balancer Cleaning and Inspection
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-198
- Balancer Installation
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-303
- Balancer Removal
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-154
- Front Oil Seal Installation
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-278
- Rear Oil Seal Installation
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-276
- Crankshaft Balancer Replacement
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-107
- Crankshaft Front Oil Seal Replacement
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-110
- Crankshaft Position (CKP) Sensor
 Replacement
 Engine Controls - 4.8L, 5.3L, 6.0L 6-810
- Crankshaft Rear Oil Seal Replacement
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-113
- Cross Bar No. 5
 Replacement - Floor Panel 8-244
- Crossmember
 Brace Replacement - Front 8-414
- Crossmember Replacement
 Front Steering Gear 8-414
 Rear Steering Gear 8-416
- Cruise Control
 Inoperative/Malfunctioning 11-18
- Cruise Control Description and Operation 11-21

Cruise Control Indicator	
Always On	11-16
Inoperative	11-17
Cupholder Replacement	8-500
Cuts Out, Misses	
Engine Controls - 4.8L, 5.3L, 6.0L	6-688
Cylinder Boring and Honing	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-185
Cylinder Head	
Assemble	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-228
Cleaning and Inspection	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-222
Disassemble	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-219
Installation - Left	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-284
Installation - Right	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-286
Removal - Left	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-167
Removal - Right	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-168
Cylinder Head Replacement - Left	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-98
Cylinder Head Replacement - Right	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-102
Cylinder Leakage Test	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-41

D

Data Link Communications Description and Operation	8-294
Daytime Running Lamps (DRL) Always On - Lighting Systems	8-608
Daytime Running Lamps (DRL) Diode Replacement - Lighting Systems	8-638
Daytime Running Lamps (DRL) Inoperative - Lighting Systems	8-609
Decimal and Metric Equivalents	0-3
Definition of Caution, Notice and Important	P-3
Definitions and Abbreviations	
Automatic Transmission	
4L60-E/4L65-E	7-234
Defroster Door Replacement - HVAC	1-53
Defroster Duct Replacement - Windshield - HVAC	1-52
Defrosting Insufficient - HVAC	1-17
Delay in Drive and Reverse	
4L60-E/4L65-E	7-175
Delayed Downshifts or No Part Throttle	
4L60-E/4L65-E	7-170
Description of Arrows and Symbols	0-4
Detonation/Spark Knock	
Engine Controls - 4.8L, 5.3L, 6.0L	6-685

Diagnosis	
Body Leans or Sways	3-5
Memory Steer	3-6
Noise - Front Suspension	3-8
Noise - Rear Suspension	3-9
Poor Directional Stability	3-7
Suspension Bottoms	3-5
Wheel Bearings	3-11
Diagnosis - Strategy Based	0-30
Diagnostic Starting Point	
ABS	5-158
Automatic Transmission	
4L60-E/4L65-E	7-41
Body Control System	8-18
Body Rear End	8-68
Cruise Control	11-7
Data Link Communications	8-280
Disc Brakes	5-64
Doors	8-313
Engine Controls - 4.8L, 5.3L, 6.0L	6-450
Engine Cooling	6-320
Engine Electrical	6-365
Engine Exhaust	6-830
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-33
Entertainment	11-38
Garage Door Opener	11-71
Horns	8-426
HVAC	1-3
Hydraulic Brakes	5-7
Instrument Panel, Gages and Console	8-447
Keyless Entry	11-78
Lighting Systems	8-574
Park Brake	5-119
Power Steering System	2-6
Propeller Shaft	4-4
Rear Drive Axle	4-16
Roof	8-734
Suspension General Diagnosis	3-3
Diagnostic System Check	
ABS	5-158
Audible Warnings	8-449
Automatic Transmission	
4L60-E/4L65-E	7-42
Body Rear End	8-68
Cruise Control	11-7
Door Systems	8-313
Engine Controls - 4.8L, 5.3L, 6.0L	6-450
Engine Cooling	6-321
Engine Electrical	6-365
Entertainment System	11-39
Horns	8-426
Instrument Cluster	8-448
Keyless Entry	11-79
Lighting Systems	8-575
Power Roof	8-735
Diagnostic Trouble Code (DTC) List	
ABS	5-162
Body Control System	8-19
Cruise Control	11-10
Data Link Communications	8-280
Doors	8-316
Engine Controls - 4.8L, 5.3L, 6.0L	6-465
Engine Cooling	6-322
Engine Electrical	6-366

- Diagnostic Trouble Code (DTC) List (cont.)
- Entertainment 11-41
 - Instrument Panel, Gages and Console 8-456
 - Keyless Entry 11-80
 - Lighting Systems 8-578
 - Roof 8-739
- Diagnostic Trouble Code (DTC)
List - Vehicle
- Vehicle DTC Information 10-3
- Diagnostic Trouble Code (DTC) List/Type
- 4L60-E/4L65-E 7-52
- Diagnostic Trouble Code (DTC)
Type Definitions
- 4L60-E/4L65-E 7-51
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-412
- Diagnostic Trouble Code (DTC) Type(s)
- Engine Controls - 4.8L, 5.3L, 6.0L 6-412
- Diagnostic Work Sheets 0-5
- Dieseling, Run-On
- Engine Controls - 4.8L, 5.3L, 6.0L 6-698
- Differential Adjustment Shim Specifications
- Rear Drive Axle 4-14
- Differential Inspection
- Rear Drive Axle 4-52
- Differential Replacement
- Rear Drive Axle 4-45
- Differential Side Bearing Preload Adjustment
- Rear Drive Axle 4-55
- Differential Side Bearings Replacement
- Rear Drive Axle 4-49
- Dimensions
- Body 8-154, 8-155, 8-156, 8-157, 8-158, 8-159
 - Frame 8-410
- Disabling the Park Brake Automatic
Adjuster 5-144
- Disassembled Views
- 4L60-E/4L65-E 7-23
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-25
- Disc Brake
- Backing Plate Replacement
 - Rear 5-114
 - Hardware Replacement
 - Front 5-88
 - Rear 5-92
 - Mounting and Hardware Inspection
 - Rear 5-67
 - Mounting and Hardware Inspection
 - Front 5-67
- Disc Brake Splash Shield
Replacement - Front 5-113
- Door Adjustment 8-350
- Door Ajar Indicator
- Malfunction 8-326
- Door Ajar Indicator Description
and Operation 8-393
- Door Check Link
Replacement 8-356
- Door Handle
- Bezel Replacement 8-342
 - Replacement
 - Inside 8-358
- Door Lock Function Inoperative with
Transmitter - Keyless Entry 11-86
- Door Replacement 8-351
- Door Sill Plate Replacement
- Interior Trim 8-533
- Door Unlock Function Inoperative with
Transmitter - Keyless Entry 11-85
- Drain Cock
- Replacement - Engine Cooling 6-351
- Draining and Filling Cooling System 6-334
- Draining Fluids and Oil Filter Removal
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-152
- Drive Belt Chirping Diagnosis
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-46
- Drive Belt Excessive Wear Diagnosis
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-57
- Drive Belt Falls Off Diagnosis
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-55
- Drive Belt Idler Pulley Replacement
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-61
- Drive Belt Replacement - Accessory
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-59
- Drive Belt Replacement - Air Conditioning
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-60
- Drive Belt Rumbling Diagnosis
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-51
- Drive Belt Squeal Diagnosis
- Engine Mechanical - 4.8L, 5.3L and 6.0L 6-48
- Drive Belt Tensioner
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-58
- Drive Belt Tensioner Replacement -
Accessory
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-62
- Drive Belt Tensioner Replacement - Air
Conditioning
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-62
- Drive Belt Vibration Diagnosis
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-53
- Drive Belt Whine Diagnosis
- Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-50
- Drive Pinion and Ring Gear Replacement
- Rear Drive Axle 4-37
- Drive Pinion Bearings Replacement
- Rear Drive Axle 4-41
- Drive Pinion Flange/Yoke and/or Oil Seal
Replacement
- Rear Drive Axle 4-33
- Driveline Disassembled Views - Propeller
Shaft 4-3
- Driver Information Center
- Switches Inoperative 8-484
- Driver Information Center Description and
Operation 8-527
- Drives in Neutral
- 4L60-E/4L65-E 7-173
- DTC 1025 11-42
- DTC 1035 11-42
- DTC 1045 11-42
- DTC 1055 11-42
- DTC B0012 9-42
- DTC B0013 9-42
- DTC B0014 9-42
- DTC B0016 9-42
- DTC B0017 9-42
- DTC B0018 9-42
- DTC B0022 9-45
- DTC B0024 9-45

DTC B0026	9-45	DTC B2575	8-586
DTC B0028	9-48	DTC B2580	8-588
DTC B0029	9-48	DTC B2585	8-590
DTC B0030	9-48	DTC B2600	8-592
DTC B0040	9-51	DTC B2610	8-594
DTC B0041	9-51	DTC B2615	8-596
DTC B0042	9-45	DTC B2620	8-598
DTC B0043	9-45	DTC B2645	8-600
DTC B0044	9-45	DTC B2752	8-428
DTC B0045	9-51	DTC B2815	11-43
DTC B0051	9-54	DTC B2947	11-111
DTC B0053	9-55	DTC B2948	11-113
DTC B0057	9-56	DTC B2957	11-115
DTC B0058	9-56	DTC B2958	11-117
DTC B0059	9-56	DTC B2960	11-120
DTC B0064	9-59	DTC B2961	8-462
DTC B0065	9-59	DTC B3031	11-122
DTC B0066	9-59	DTC B3033	11-123
DTC B0077	9-62	DTC B3102	11-81
DTC B0078	9-62	DTC B3802	8-602
DTC B0079	9-62	DTC B3808	8-321
DTC B0080	9-62	DTC B3809	8-323
DTC B0081	9-62	DTC B3992	8-319
DTC B0082	9-62	DTC C0221-C0227	5-163
DTC B0090	9-68	DTC C0229	5-165
DTC B0091	9-70	DTC C0235-C0237	5-166
DTC B0100	9-72	DTC C0238	5-168
DTC B0101	9-72	DTC C0241-C0254	5-169
DTC B0102	9-72	DTC C0265	5-170
DTC B0103	9-72	DTC C0266	5-170
DTC B0104	9-72	DTC C0267	5-172
DTC B0105	9-72	DTC C0268	5-172
DTC B0540	8-457	DTC C0269	5-175
DTC B0560	8-459	DTC C0271-C0273	5-176
DTC B1000	8-20	DTC C0274	5-175
DTC B1001	8-21, 9-75	DTC C0279	5-177
DTC B1004	8-22	DTC C0281	5-178
DTC B1007	8-23	DTC C0283	5-180
DTC B1009	8-24	DTC C0284	5-176
DTC B1017	8-317	DTC C0287	5-182
DTC B1372	8-461	DTC C0290	5-184
DTC B1420	8-25	DTC C0292	5-184
DTC B1440	8-27	DTC C0297	5-184
DTC B1480	8-579	DTC C0298	5-185
DTC B1533	8-319	DTC C0609	5-166
DTC B1735	8-927	DTC List	1-74
DTC B1740	8-927	DTC P0068	6-469
DTC B1745	8-927	DTC P0101	6-472
DTC B1750	8-927	DTC P0102	6-476
DTC B1755	8-927	DTC P0103	6-481
DTC B1760	8-927	DTC P0106	6-484
DTC B1815	8-927	DTC P0107	6-488
DTC B1820	8-927	DTC P0108	6-491
DTC B1825, B1850, B1860, B2355, B2365, or B2375	8-928	DTC P0112	6-494
DTC B1830	8-927	DTC P0113	6-496
DTC B1835	8-927	DTC P0116	6-499
DTC B2425	8-930	DTC P0117	6-503
DTC B2430	8-930	DTC P0118	6-505
DTC B2435	8-932	DTC P0120	6-507
DTC B2440	8-932	DTC P0125	6-512
DTC B2527	8-581	DTC P0128	6-515
DTC B2530	8-583	DTC P0131	6-518
DTC B2550	8-585	DTC P0132	6-521
		DTC P0133	6-525

DTC P0134	6-528	DTC P0622	6-369
DTC P0135	6-531	DTC P0641	6-620
DTC P0136	6-535	DTC P0650	6-622
DTC P0137	6-539	DTC P0651	6-625
DTC P0138	6-543	DTC P0654	8-475
DTC P0140	6-547	DTC P0706	7-63
DTC P0141	6-531	DTC P0711	7-67
DTC P0151	6-518	DTC P0712	7-71
DTC P0152	6-521	DTC P0713	7-74
DTC P0153	6-525	DTC P0719	7-78
DTC P0154	6-528	DTC P0724	7-81
DTC P0155	6-531	DTC P0740	7-84
DTC P0156	6-535	DTC P0741	7-88
DTC P0157	6-539	DTC P0742	7-91
DTC P0158	6-543	DTC P0748	7-94
DTC P0160	6-547	DTC P0751	7-98
DTC P0161	6-531	DTC P0752	7-101
DTC P0171	6-550	DTC P0753	7-104
DTC P0172	6-553	DTC P0756	7-109
DTC P0174	6-550	DTC P0757	7-112
DTC P0175	6-553	DTC P0758	7-115
DTC P0200	6-556	DTC P0785	7-120
DTC P0218	7-53	DTC P0856	5-185
DTC P0220	6-559	DTC P0894	7-125
DTC P0230	6-564	DTC P1106	6-627
DTC P0300	6-566	DTC P1107	6-629
DTC P0315	6-570	DTC P1111	6-631
DTC P0325	6-571	DTC P1112	6-633
DTC P0327	6-572	DTC P1114	6-635
DTC P0332	6-572	DTC P1115	6-637
DTC P0335	6-575	DTC P1125	6-639
DTC P0336	6-578	DTC P1133	6-641
DTC P0341	6-580	DTC P1134	6-644
DTC P0342	6-582	DTC P1153	6-641
DTC P0343	6-585	DTC P1154	6-644
DTC P0351-P0358	6-588	DTC P1380	6-647
DTC P0420	6-590	DTC P1381	6-648
DTC P0430	6-590	DTC P1516	6-649
DTC P0442	6-593	DTC P1574	11-15
DTC P0443	6-596	DTC P1600	6-619
DTC P0446	6-598	DTC P1621	6-619
DTC P0449	6-602	DTC P1626	11-125
DTC P0452	6-604	DTC P1627	6-619
DTC P0453	6-606	DTC P1630	11-128
DTC P0455	6-608	DTC P1631	11-129
DTC P0461	8-464	DTC P1632	11-131
DTC P0462	8-465	DTC P1637	6-371
DTC P0463	8-467	DTC P1644	5-182
DTC P0480	6-323	DTC P1680	6-619
DTC P0481	6-323	DTC P1681	6-619
DTC P0496	6-613	DTC P1683	6-619
DTC P0502	7-56	DTC P1689	5-182
DTC P0503	7-59	DTC P1810	7-131
DTC P0506	6-615	DTC P2101	6-652
DTC P0507	6-617	DTC P2108	6-655
DTC P0522	8-469	DTC P2120	6-657
DTC P0523	8-471	DTC P2121	6-661
DTC P0530	1-79	DTC P2125	6-665
DTC P0562	6-367	DTC P2135	6-669
DTC P0563	6-368	DTC P2610	6-619
DTC P0567	11-11	DTC P2761	7-135
DTC P0568	11-13	DTC U0107	6-672
DTC P0601-P0607	6-619	DTC U1000 and U1255	8-281
DTC P0608	8-473	DTC U1001-U1254	8-285

DTC U1300	8-288
DTC U1301	8-288
DTC U1305	8-288

E

Electronic Brake Control Module		Engine Flywheel Replacement	
Replacement - ABS	5-192	Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-134
Electronic Component Description		Engine Front Cover	
4L60-E/4L65-E	7-240	Cleaning and Inspection	
Electronic Ignition (EI) System		Engine Mechanical - 4.8L, 5.3L,	
Description		and 6.0L	6-237
Engine Controls - 4.8L, 5.3L, 6.0L	6-824	Installation	
Diagnosis		Engine Mechanical - 4.8L, 5.3L,	
Engine Controls - 4.8L, 5.3L, 6.0L	6-729	and 6.0L	6-276
Eliminating Unwanted Odors in Vehicles		Removal	
Interior Trim	8-531	Engine Mechanical - 4.8L, 5.3L,	
Emblem Replacement		and 6.0L	6-172
Grille - Exterior Trim	8-396	Engine Front Cover Replacement	
Emblem/Nameplate Replacement		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-111
End Gate - Exterior Trim	8-395	Engine Gaskets, Replacing	
Emission Hose Routing Diagram		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-311
Engine Controls - 4.8L, 5.3L, 6.0L	6-414	Engine ID and Partial VIN Location	0-10
Enabling the Park Brake Cable Automatic		Engine Identification	
Adjuster	5-144	Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-32
Endgate Replacement	8-95	Engine Mechanical Specifications	
Engine and Transmission Usage	0-11	Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-9
Engine Block		Engine Mount Inspection	
Cleaning and Inspection		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-63
Engine Mechanical - 4.8L, 5.3L,		Engine Mount Replacement - Left	
and 6.0L	6-184	Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-64
Plug Installation		Engine Mount Replacement - Right	
Engine Mechanical - 4.8L, 5.3L,		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-68
and 6.0L	6-259	Engine Noise on Start-Up, but Only Lasting	
Plug Removal		a Few Seconds	
Engine Mechanical - 4.8L, 5.3L,		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-36
and 6.0L	6-181	Engine Noise Under Load	
Engine Component Description		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-38
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-306	Engine Oil and Oil Filter Replacement	
Engine Compression Test		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-151
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-41	Engine Oil Pressure Gage Inaccurate or	
Engine Coolant in Transmission		Inoperative - Instrument Panel,	
4L60-E/4L65-E	7-152	Gages, and Console	8-478
Engine Coolant Temperature Gage		Engine Oil Pressure Sensor and/or Switch	
Inaccurate or Inoperative	8-477	Replacement	
Engine Coolant Temperature (ECT) Sensor		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-124
Replacement		Engine Overheating - Engine Cooling	6-328
Engine Controls - 4.8L, 5.3L, 6.0L	6-745	Engine Prelubing	
Engine Cranks but Does Not Run		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-258
Engine Controls - 4.8L, 5.3L, 6.0L	6-704	Engine Rear Cover	
Engine Cranks Slowly - Engine Electrical	6-386	Cleaning and Inspection	
Engine Fails To Reach Normal Operating		Engine Mechanical - 4.8L, 5.3L,	
Temperature - Engine Cooling	6-332	and 6.0L	6-238
Engine Flywheel		Installation	
Cleaning and Inspection		Engine Mechanical - 4.8L, 5.3L,	
Engine Mechanical - 4.8L, 5.3L,		and 6.0L	6-273
and 6.0L	6-198	Removal	
Installation		Engine Mechanical - 4.8L, 5.3L,	
Engine Mechanical - 4.8L, 5.3L,		and 6.0L	6-172
and 6.0L	6-302	Engine Rear Cover Replacement	
Removal		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-114
Engine Mechanical - 4.8L, 5.3L,		Engine Replacement	
and 6.0L	6-155	Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-135
		Engine Sight Shield Replacement	
		Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-72
		Engine Starts in Gear	
		4L60-E/4L65-E	7-175

- Engine Valley Cover
 Cleaning and Inspection
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-238
 Installation
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-293
 Removal
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-162
 Engine Valley Cover Replacement
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-80
 Engine Will Not Crank - Crankshaft Will
 Not Rotate
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-39
 English/Metric Conversion Table 0-3
 Evaporative Emission (EVAP)
 Canister Purge Solenoid Valve
 Replacement
 Engine Controls - 4.8L, 5.3L, and 6.0L 6-792
 Canister Replacement
 Engine Controls - 4.8L, 5.3L, 6.0L 6-800
 Canister Vent Solenoid Valve
 Replacement
 Engine Controls - 4.8L, 5.3L, and 6.0L 6-794
 Control System Description
 Engine Controls - 4.8L, 5.3L, 6.0L 6-823
 Hose Routing Diagram
 Engine Controls 4.8L, 5.3L, 6.0L 6-415
 Hoses/Pipes Replacement - Canister Vent
 Engine Controls - 4.8L, 5.3L, and 6.0L 6-796
 Hoses/Pipes Replacement - Canister/
 Fuel Tank
 Engine Controls - 4.8L, 5.3L, 6.0L 6-800
 Hoses/Pipes Replacement - Chassis
 Engine Controls - 4.8L, 5.3L, and 6.0L 6-796
 Hoses/Pipes Replacement - Engine
 Engine Controls - 4.8L, 5.3L, 6.0L 6-795
 Evaporator Core Replacement - HVAC 1-44
 Evaporator Temperature Sensor
 Replacement - HVAC 1-39
 Exhaust Leakage Diagnosis - Engine
 Exhaust 6-832
 Exhaust Manifold
 Cleaning and Inspection
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-245
 Installation - Left
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-300
 Installation - Right
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-301
 Removal - Left
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-156
 Removal - Right
 Engine Mechanical - 4.8L, 5.3L,
 and 6.0L 6-157
 Exhaust Manifold Replacement - Left -
 Engine Exhaust 6-833
 Exhaust Manifold Replacement - Right -
 Engine Exhaust 6-835
 Exhaust Noise - Engine Exhaust 6-832
 Exhaust Seal Replacement - Engine
 Exhaust 6-838
 Exhaust System Description 6-853
 Explanation of Scheduled Services 0-38
 Exterior Lighting Systems Description
 and Operation 8-671
 Exterior Windnoise 0-115
- ## F
- Fascia Grille Replacement
 Bumpers 8-134
 Fascia Replacement
 Front Bumper 8-132
 Rear Bumper 8-137
 Fastener Tightening Specifications
 ABS 5-152
 Automatic Transmission
 4L60-E/4L65-E 7-13
 Body Front End 8-39
 Body Rear End 8-63
 Bumpers 8-132
 Disc Brakes 5-63
 Doors 8-295
 Engine Controls - 4.8L, 5.3L, 6.0L 6-411
 Engine Cooling 6-317
 Engine Electrical 6-360
 Engine Exhaust 6-829
 Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-7
 Entertainment 11-23
 Exterior Trim 8-395
 Frame and Underbody 8-409
 Front Suspension 3-20
 Horns 8-422
 HVAC 1-3
 Hydraulic Brakes 5-3
 Instrument Panel, Gages and Console 8-436
 Interior Trim 8-531
 Lighting Systems 8-546
 Park Brake 5-119
 Power Steering System 2-3
 Propeller Shaft 4-3
 Rear Drive Axle 4-14
 Rear Suspension 3-51
 Roof 8-715
 Fasteners 0-15
 Fender
 Replacement - Front 8-50
 Replacement - Front - Left 8-53
 Fender Rail
 Replacement
 Upper 8-247
 Sectioning
 Upper 8-249
 Fender Reinforcement
 Replacement - Lower 8-54
 Filler Tube and Seal
 Replacement
 4L60-E/4L65-E 7-197
 Filler Tube Replacement
 Engine Controls - 4.8L, 5.3L, 6.0L 6-770
 First Gear Range Only-No Upshift
 4L60-E/4L65-E 7-166

- Flexplate/Torque Converter Vibration Test
4L60-E/4L65-E 7-150
- Floor Carpet Drying
Interior Trim 8-534
- Floor Replacement
Rear 8-257, 8-264
- Floor Shift Control
Replacement
4L60-E/4L65-E 7-181
- Floor Shift Control Knob
Replacement
4L60-E/4L65-E 7-176
- Fluid and Lubricant Recommendations 0-33
- Fluid Capacity Specifications
4L60-E/4L65-E 7-15
- Fluid Leak Diagnosis
4L60-E/4L65-E 7-152
- Flushing - Engine Cooling 6-335
- Flushing - HVAC 1-24
- Flushing the Power Steering System 2-16
- Fog Lamp Aiming Procedure - Lighting
Systems 8-653
- Fog Lamp Bulb Replacement - Front -
Lighting Systems 8-652
- Fog Lamp Indicator Inoperative - Lighting
Systems 8-610
- Fog Lamp Replacement - Front - Lighting
Systems 8-650
- Fog Lamps Always On - Front - Lighting
Systems 8-611
- Fog Lamps Inoperative - Lighting Systems 8-612
- Folding Top
Rear Window Replacement - Roof 8-846
Replacement - Roof 8-842
Side Rail Assembly Replacement - Roof 8-849
Stowage Compartment Lid Hinge
Replacement - Roof 8-857
Stowage Compartment Lid Latch
Replace - Roof 8-813
Stowage Compartment Lid Release
Mechanism - Roof 8-859
Stowage Compartment Lid
Replacement - Roof 8-851
Stowage Compartment Lid Striker - Roof 8-816
- Frame
Brace Replacement 8-416
Cushion or Insulator Replacement 8-417
- Frame Sectioning
Front Full Frame 8-164
- Front End Assembly
Replacement - Kit 8-170
- Front Suspension General Description 3-49
- Fuel Filler Door
Replacement 8-93
- Fuel Filler Hose Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-777
- Fuel Filter Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-763
- Fuel Gage Inaccurate or Inoperative 8-479
- Fuel Hose/Pipes
Assembly Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-776
Replacement - Chassis
Engine Controls - 4.8L, 5.3L, 6.0L 6-774
- Fuel Hose/Pipes (cont.)
Routing Diagram
Engine Controls - 4.8L, 5.3L, and 6.0L 6-416
- Fuel Injector
Balance Test with Special Tool
Engine Controls - 4.8L, 5.3L, 6.0L 6-721
Balance Test with Tech 2
Engine Controls - 4.8L, 5.3L, 6.0L 6-724
Cleaning Procedure
Engine Controls - 4.8L, 5.3L, and 6.0L 6-790
Coil Test
Engine Controls - 4.8L, 5.3L, 6.0L 6-719
Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-789
- Fuel Level Sensor Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-769
- Fuel Level Specifications - Instrument
Panel, Gages and Console 8-436
- Fuel Pressure
Gage Installation and Removal
Engine Controls - 4.8L, 5.3L, 6.0L 6-758
Regulator Replacement
Engine Controls 4.8L, 5.3L, 6.0L 6-788
Relief Procedure
Engine Controls - 4.8L, 5.3L, 6.0L 6-757
- Fuel Pump
Electrical Circuit Diagnosis
Engine Controls - 4.8L, 5.3L, 6.0L 6-712
- Fuel Rail and Injectors
Installation
Engine Mechanical - 4.8L, 5.3L,
and 6.0L 6-298
Removal
Engine Mechanical - 4.8L, 5.3L,
and 6.0L 6-158
- Fuel Rail Assembly Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-778
- Fuel Rail Crossover Pipe
Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-785
- Fuel Rail Outlet Pipe
Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-786
- Fuel Sender Assembly
Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-773
- Fuel System
Cleaning
Engine Controls - 4.8L, 5.3L, 6.0L 6-777
Description
Engine Controls - 4.8L, 5.3L, 6.0L 6-819
Diagnosis
Engine Controls - 4.8L, 5.3L, 6.0L 6-715
- Fuel Tank
Draining Procedure
Engine Controls - 4.8L, 5.3L, 6.0L 6-764
Leak Test
Engine Controls - 4.8L, 5.3L, 6.0L 6-726
Pressure Sensor Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-769
Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-764

G

Gages Inoperative - All	8-481
Garage Door Opener	
Inoperative	11-72
Programming - Universal	11-73
Garage Door Opener Description and Operation	11-74
Garnish Molding Replacement	
Rear Upper - Interior Trim	8-544
Windshield Pillar - Interior Trim	8-543
Windshield Upper - Interior Trim	8-543
Gear Tooth Contact Pattern Inspection	
Rear Drive Axle	4-59
Generator	
Bracket Replacement - Engine Electrical	6-404
Replacement - Engine Electrical	6-405
Generator Noise Diagnosis - Engine Electrical	6-382
Generator Usage Specifications - Engine Electrical	6-360
GM Oil Life System - Resetting	0-44
Gouge or Puncture Repair - Plastic Panel Information and Repair	8-685
Ground Strap	
Replacement - Engine Electrical	6-400

H

Handle Replacement	
Endgate	8-116
Hard Start	
Engine Controls - 4.8L, 5.3L, 6.0L	6-679
Harsh Garage Shift	
4L60-E/4L65-E	7-170
Harsh or Slipping 1-2 Shift	
4L60-E/4L65-E	7-167
Harsh Shifts	
4L60-E/4L65-E	7-165
Hazard and Turn Signal Flasher	
Replacement - Lighting Systems	8-639
Hazard Lamps Always On - Lighting Systems	8-613
Hazard Lamps Inoperative - Lighting Systems	8-614
Headlamp Aiming - Lighting Systems	8-648
Headlamp Bulb Replacement - Lighting Systems	8-645
Headlamp Replacement - Lighting Systems	8-644
Headlamp Switch Replacement - Lighting Systems	8-636
Headlamps Always On - Low or High Beam - Lighting Systems	8-615
Headlamps Inoperative - Flash to Pass - Lighting Systems	8-620
Headlamps Inoperative - High Beam - Lighting Systems	8-617
Headlamps Inoperative - Low Beams - Lighting Systems	8-618
Heat Shield	
Replacement	
4L60-E/4L65-E	7-199

Heated Mirrors	
Inoperative - Doors	8-336
Heated Oxygen Sensor (HO2S)	
Replacement Bank 2 Sensor 2 Engine Controls - 4.8L, 5.3L, 6.0L	6-752
Heated Oxygen Sensor (HO2S) Replacement	
Bank 1 Sensor 1 Engine Controls - 4.8L, 5.3L, 6.0L	6-749
Bank 1 Sensor 2 Engine Controls - 4.8L, 5.3L, 6.0L	6-750
Bank 2 Sensor 1 Engine Controls - 4.8L, 5.3L, 6.0L	6-751
Heated Seat Switch Replacement - Front	8-978
Heater Core Replacement - HVAC	1-58
Heater Hose Replacement - Inlet - HVAC	1-46
Heater Hose Replacement - Outlet - HVAC	1-48
Heater Replacement	
Front Seat Back	8-979
Heating Performance Diagnostic	1-15
Hesitation or Lack of Power 4L60-E/4L65-E	7-175
Hesitation, Sag, Stumble	
Engine Controls - 4.8L, 5.3L, 6.0L	6-686
High Beam Indicator Always On - Lighting Systems	8-620
High Beam Indicator Inoperative - Lighting Systems	8-621
High Frequency Rattle Sound or Buzz Noise	
4L60-E/4L65-E	7-174
High Mounted Stop Lamp Replacement - Lighting Systems	8-663
Hinge Pillar Body	
Replacement	
Front Inner	8-189
Hinge Replacement	
Door	8-354
Endgate	8-99
Rear Compartment Lid	8-103
Hinge Shield Replacement Endgate	8-100
Hood Adjustment	8-40
Hood Bumper	
Replacement	8-40
Hood Hinge	
Replacement	8-43
Hood Hold-Open Rod	
Replacement	8-48
Hood Insulator	
Replacement	8-47
Hood Latch	
Adjustment	8-44
Replacement	8-45
Hood Latch Release Cable	
Replacement	8-45
Hood Replacement	8-41
Horn Replacement	8-434
Horns - Poor Tone	8-433
Horns Always On	8-430
Horns Inoperative	8-431
Horns System Description and Operation	8-435

- HVAC - Manual
- Component Views 1-65
 - Connector End Views 1-69
 - Diagnosis
 - A/C Compressor Clutch Does Not Disengage 1-86
 - A/C Compressor Clutch Does Not Engage 1-82
 - Air Delivery Improper 1-95
 - Scan Tool Data Definitions 1-74
 - Scan Tool Data List 1-74
 - Scan Tool Output Controls 1-74
 - Mode Actuator Replacement
 - Actuator Mode Replacement (A/C - Manual) 1-99
 - Special Tools 1-104
 - Specifications
 - Fastener Tightening 1-61
 - HVAC Module Assembly Replacement 1-43
 - HVAC Systems - Automatic
 - Diagnosis
 - Air Recirculation Malfunction 1-96
 - HVAC Systems - Manual
 - Description
 - Air Delivery Description and Operation 1-101
 - Air Temperature Description and Operation 1-102
 - Diagnosis
 - Blower Motor Inoperative 1-88
 - Blower Motor Malfunction 1-90
 - Diagnostic System Check - HVAC Systems - Manual 1-72
 - Re-Calibrating Actuators 1-97
 - Symptoms - HVAC Systems - Manual 1-81
 - Too Cold in Vehicle 1-93
 - Too Hot in Vehicle 1-91
 - Repair
 - Air Temperature Actuator Replacement 1-99
 - HVAC Control Module Replacement 1-98
 - Recirculation Actuator Replacement 1-100
 - Schematics
 - HVAC Schematics 1-62
 - Hydraulic Brake Component Operation
 - Visual Inspection 5-30
 - Hydraulic Brake System Description and Operation 5-61
 - Hydraulic Brake Warning System
 - Description and Operation 5-61
 - Hydraulic Brakes Disc Brake System
 - Diagnosis 5-17
- I**
- Identification, Vehicle 0-6
 - Ignition Coil(s) Replacement
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-802
 - Ignition Relay Diagnosis
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-706
 - Ignition System Specifications
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-410
 - Important, Caution and Notice, Definition of P-3
 - Inaccurate Shift Points
 - 4L60-E/4L65-E 7-166
 - Indicator/Warning Message Description and Operation 8-524
 - Inspection/Maintenance (I/M)
 - Catalyst System Set Procedure
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-736
 - Complete System Set Procedure
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-734
 - Evaporative Emission (EVAP) System Set Procedure
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-738
 - Heated Oxygen Sensor (HO2S) Heater System Set Procedure
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-742
 - Heated Oxygen Sensor/Oxygen Sensor (HO2S/O2S) System Set Procedure
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-740
 - System Check
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-733
 - System DTC Table
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-736
 - Instrument Panel
 - Carrier Replacement 8-510
 - Cluster Replacement 8-498
 - Instrument Panel Cluster Description and Operation 8-523
 - Instrument Panel (I/P) Air Outlet Ducts Replacement - HVAC 1-52
 - Instrument Panel (I/P) Compartment Lamp Always On - Lighting Systems 8-624
 - Instrument Panel (I/P) Compartment Lamp Bulb Replacement - Lighting Systems 8-641
 - Instrument Panel (I/P) Compartment Lamp Inoperative - Lighting Systems 8-623
 - Instrument Panel (I/P) Compartment Lamp Replacement - Lighting Systems 8-641
 - Intake Manifold
 - Cleaning and Inspection
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-242
 - Installation
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-296
 - Removal
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-159
 - Intake Manifold Replacement
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-74
 - Interior Backlighting Does Not Dim - Lighting Systems 8-622
 - Interior Backlighting Inoperative - Lighting Systems 8-623
 - Interior Lighting System Description and Operation 8-673
 - Interior Windnoise 0-115
 - Intermittent Conditions
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-677
 - Intermittent Noise
 - Rear Drive Axle 4-17

J

- Jacking and Lifting 0-28
- Jump Starting in Case of Emergency -
Engine Electrical 6-378

K

- Key Coding and Lock Cylinders 0-25
- Keyless Entry System Description and
Operation 11-89
- Keyless Entry System Inoperative 11-83
- Knee Bolster
Bracket Replacement
Left 8-492
- Replacement
Left 8-490
- Right 8-488
- Knock or Clunk Noise - Propeller Shaft 4-5
- Knock Sensor (KS)
Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-812
- System Description
Engine Controls - 4.8L, 5.3L, 6.0L 6-825

L

- Label - Service Parts ID 0-13
- Label - Vehicle Certification 0-7, 0-8
- Lack of Power or Hesitation
4L60-E/4L65-E 7-175
- Lack of Power, Sluggishness, or
Sponginess
Engine Controls - 4.8L, 5.3L, 6.0L 6-682
- Latch Release Cable
Adjustment RT/LT - Rear
Compartment Lid 8-109
- Replacement RT/LT - Rear
Compartment Lid 8-106
- Latch Release Handle
Replacement - Rear Compartment Lid 8-115
- Latch Replacement
Door 8-365
- Endgate 8-119
- Rear Compartment Lid 8-113
- Lead/Pull Description 3-18
- Leak at Front Slip Yoke - Propeller Shaft 4-4
- Leak Testing - HVAC 1-4
- License Lamp Bulb Replacement - Lighting
Systems 8-668
- License Lamp Replacement - Lighting
Systems 8-667
- License Lamps Inoperative - Lighting
Systems 8-624
- Lifting and Jacking 0-28
- Line Pressure
4L60-E/4L65-E 7-16
- Line Pressure Check Procedure
4L60-E/4L65-E 7-145
- Linkage Replacement
Endgate 8-119
- Lock Cylinder
Replacement
Door 8-362

- Lock Cylinder Latch Plate
Replacement - Rear Compartment Lid 8-105
- Lock Cylinder Latch Plate Cover
Replacement - Rear Compartment Lid 8-104
- Lock Cylinders and Key Coding 0-25
- Lock Pillar Gusset
Replacement - Rear Compartment 8-241
- Lock Striker Replacement
Endgate 8-120
- Loss of Coolant 6-329
- Low Fuel Indicator Inoperative 8-484
- Lower Engine Noise, Regardless of
Engine Speed
Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-38
- Lubricant and Fluid Recommendations 0-33
- Lubrication Description
Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-309

M

- Maintenance Items 0-34
- Malfunction Indicator Lamp (MIL)
Always On
Engine Controls - 4.8L, 5.3L, 6.0L 6-703
- Inoperative
Engine Controls - 4.8L, 5.3L, 6.0L 6-701
- Manifold Absolute Pressure (MAP) Sensor
Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-747
- Manual Shift Shaft Seal
Replacement
4L60-E/4L65-E 7-200
- Marker Lamp Bulb Replacement - Front
Side - Lighting Systems 8-655
- Marker Lamp Bulb Replacement - Rear
Side - Lighting Systems 8-658
- Marker Lamp Replacement - Front Side -
Lighting Systems 8-654
- Marker Lamp Replacement - Rear Side -
Lighting Systems 8-657
- Marker Lamps Inoperative - Lighting
Systems 8-625
- Mass Air Flow (MAF)/Intake Air
Temperature (IAT) Sensor
Replacement
Engine Controls - 4.8L, 5.3L, 6.0L 6-747
- Master Cylinder Bench Bleeding - Hydraulic
Brakes 5-40
- Master Cylinder Fluid Level Sensor
Replacement - Hydraulic Brakes 5-41
- Master Cylinder Overhaul - Hydraulic
Brakes 5-38
- Master Cylinder Replacement - Hydraulic
Brakes 5-35
- Master Cylinder Reservoir Filling - Hydraulic
Brakes 5-32
- Master Cylinder Reservoir Replacement -
Hydraulic Brakes 5-33
- Meanings of Abbreviations 0-18
- Memory Steer Description 3-19
- Memory Steer Diagnosis 3-6
- Metal Panel Bonding 8-273

Microphone Replacement - Radio Volume Compensator Interior - Entertainment	11-55
Mirror Face Replacement - Doors	8-389
Mirror Replacement Power - Doors	8-387
Mirrors - Outside Automatic Day-Night Feature Inoperative	8-334
Mode Actuator Replacement (A/C - Manual)	1-99
Mode Door Replacement - HVAC	1-54
Muffler Replacement - Engine Exhaust	6-849

N

New Product Information Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-307
No 2-3 Shift or 2-3 Shift Slips, Rough or Hunting 4L60-E/4L65-E	7-168
No 3-4 Shift, Slips or Rough 3-4 Shift 4L60-E/4L65-E	7-169
No Drive in All Ranges 4L60-E/4L65-E	7-174
No Drive in Drive Range 4L60-E/4L65-E	7-174
No First or Second Gear/No Third or Fourth Gear 4L60-E/4L65-E	7-168
No Fourth Gear or Slips in Fourth Gear 4L60-E/4L65-E	7-172
No Gear Selection 4L60-E/4L65-E	7-175
No Overrun Braking - Manual 3-2-1 4L60-E/4L65-E	7-170
No Park 4L60-E/4L65-E	7-173
No Part Throttle or Delayed Downshifts 4L60-E/4L65-E	7-170
No Reverse or Slips in Reverse 4L60-E/4L65-E	7-169
No Second, Fourth and Reverse Gear 4L60-E/4L65-E	7-168
No Third Gear 4L60-E/4L65-E	7-173
No Third or Fourth Gear/No First or Second Gear 4L60-E/4L65-E	7-168
No Torque Converter Clutch Apply 4L60-E/4L65-E	7-171
No Torque Converter Clutch Release 4L60-E/4L65-E	7-172
Noise and Vibration Analysis 4L60-E/4L65-E	7-151
Noise Diagnosis - HVAC Module	1-20
Noise in Random Ranges 4L60-E/4L65-E	7-174
Noisy in Drive Rear Drive Axle	4-17
Noisy on Turns Rear Drive Axle	4-18

Noisy When Coasting Rear Drive Axle	4-17
Notice, Caution and Important, Definition of	P-3

O

Odometer Trip/Reset Switch Inoperative	8-482
Odor Correction - HVAC	1-23
Odor Diagnosis - HVAC	1-21
Oil Consumption Diagnosis Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-42
Oil Filter and Adapter Installation Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-282
and Adapter Removal Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-169
Oil Filter Adapter Replacement Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-116
Oil Filter Bypass Valve Replacement Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-118
Oil Leak Diagnosis Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-43
Oil Level Indicator and Tube Installation Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-302
Removal Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-156
Oil Level Indicator and Tube Replacement Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-97
Oil Out the Vent 4L60-E/4L65-E	7-173
Oil Pan Cleaning and Inspection Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-240
Installation Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-279
Removal Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-170
Oil Pan Replacement Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-119
Oil Pressure Diagnosis and Testing Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-42
Oil Pressure High or Low 4L60-E/4L65-E	7-165
Oil Pump Assemble Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-235
Cleaning and Inspection Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-233
Disassemble Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-230

Oil Pump (cont.)	
Pump Screen and Deflector Installation	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-272
Pump Screen and Deflector Removal	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-173
Oil Pump, Pump Screen and Deflector Replacement	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-125
Outside Mirror Description and Operation	8-393, 8-394
Overlap/Backing Plate Sectioning	8-168, 8-169
Owner Checks and Services	0-44

P

Paint Gages	8-682
Paint Identification	8-680
Paint/Coatings	
Anti-Corrosion Treatment and Repair	8-677
Environmental Fallout	
Acid Rain	8-681
Panel Identification	8-142, 8-143, 8-144
Panel Replacement	
Body Rear Outer	8-270
Complete	8-693
Partial	8-689
Panic Mode Inoperative - Keyless Entry	11-82
Park Brake Actuator Replacement	5-145
Park Brake Adjustment	5-150
Park Brake Cable Replacement - Front	5-130
Park Brake Cable Replacement - Left Rear	5-135
Park Brake Cable Replacement - Right Rear	5-139
Park Brake Description and Operation	5-151
Park Brake Lever Assembly Replacement	5-127
Park Brake Shoe Inspection	5-122
Park Brake Shoe Replacement	5-124
Park Brake System Diagnosis	5-120
Park Brake Warning Lamp Switch Replacement	5-129
Park Brake Will Not Hold or Release	5-119
Park Lamps Inoperative - Lighting Systems	8-626
Park/Neutral Position Switch Adjustment	
4L60-E/4L65-E	7-184
Park/Neutral Position Switch Replacement	
4L60-E/4L65-E	7-183
Park/Turn Signal Lamp Bulb Replacement - Lighting Systems	8-661
Park/Turn Signal Lamp Replacement - Lighting Systems	8-660
Special Tools	
Roof	8-901
Personalization	
Description and Operation	11-91
Driver Personalization	11-91
Vehicle Personalization	11-91
Pickup Box	
Side Panel Brace Replacement	
Front	8-123
Rear	8-125
Pillar Lock Front Door Replacement - Inner	8-205
Ping, Snap, or Click Noise - Propeller Shaft	4-5
Pinion and Ring Gear Inspection	
Rear Drive Axle	4-52
Pinion Depth Adjustment	
Rear Drive Axle	4-53
Piston and Connecting Rod Assemble	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-206
Disassemble	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-199
Piston, Connecting Rod, and Bearing Cleaning and Inspection	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-200
Installation	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-266
Removal	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-176
Plastic Identification and Refinishing Systems	8-707
Plastic Panel Information and Repair	
Handling Precautions For Plastic	8-709
How to Identify Plastic Parts	8-707
Plastic Panels	8-684
Plastic Repair Instructions - General	8-684
Plastic Repair Precautions	8-710
Plastic Structure Repair - Plastic Panel Information and Repair	8-700
Poor Fuel Economy	
Engine Controls - 4.8L, 5.3L, 6.0L	6-691
Poor Fuel Fill Quality	
Engine Controls - 4.8L, 5.3L, 6.0L	6-694
Popping Noise	
4L60-E/4L65-E	7-173
Power Door Lock Inoperative	
Driver Door	8-329
Power Door Locks	
Inoperative	8-327
Passenger Door	8-331
Power Door Locks Description and Operation	8-392
Power Folding Top	
Adding Fluid	8-829
Inoperative	8-785
Power Folding Top Description and Operation	8-899
Power Mirror Switch Replacement - Doors	8-340
Power Mirrors	
Inoperative - Doors	8-332
Power Mode Mismatch Body Control System	8-31
Power Steering Cooler Replacement	2-22

Power Steering Gear	
Disassembled View	2-4
Replacement	2-28
Power Steering Hose	
Assembly Replacement	2-24
Power Steering Pulley Replacement	2-17
Power Steering Pump	
Disassembled View	2-5
Flow Control Valve Replacement - Off Vehicle	2-20
Replacement	2-18
Specifications	2-3
Power Steering Reservoir Replacement - Off Vehicle	2-19
Power Steering System Description and Operation	2-41
Power Steering System Fluid Leaks	2-9
Power Steering System Test Procedure	2-6
Power Window	
Inoperative	
From Master Switch - Doors	8-325
Power Windows Description and Operation	8-391
Powertrain Control Module (PCM)	
Description	
Engine Controls - 4.8L, 5.3L, 6.0L	6-816
Replacement	
Engine Controls - 4.8L, 5.3L, 6.0L	6-744
Pressure Cap Testing	
Engine Cooling	6-333
Pressure Regulator	
Replacement	
4L60-E/4L65-E	7-196
Pressure Relief Valve	
Replacement	8-126
Propeller Shaft Description and Operation	4-13
Propeller Shaft Replacement	4-6
Propeller Shaft Runout Specifications	0-47
Pull Handle	
Replacement - Doors	8-343

Q

Quarter Panel	
Replacement	
Outer	8-232, 8-236
Quarter Panel Protector	
Replacement	8-122
Quick Connect Fitting(s) Service	
Metal Collar	
Engine Controls - 4.8L, 5.3L, 6.0L	6-759
Plastic Collar	
Engine Controls - 4.8L, 5.3L, 6.0L	6-761

R

Rack and Pinion	
Boot Replacement - Off Vehicle - Power Steering System	2-31
Gear Rack Bearing Preload Adjustment - Off Vehicle - Power Steering System	2-31

Radiator	
Cleaning - Engine Cooling	6-335
Hose Replacement	
Inlet - Engine Cooling	6-337
Outlet - Engine Cooling	6-338
Replacement - Engine Cooling	6-352
Support Replacement - Engine Cooling	6-353
Radio Displays CAL ERR - Entertainment	11-48
Radio Displays LOC, LOCKED or CODE - Entertainment	11-48
Radio Poor Reception - Entertainment	11-46
Radio Replacement - Entertainment	11-52
Radio/Audio System Description and Operation - Entertainment	11-64
Rail Dust Damage Repair	8-682
Range Reference	
4L60-E/4L65-E	7-15
Range Selector Displays Incorrect Range	
4L60-E/4L65-E	7-141
RAP	
Diagnosis	
Diagnostic System Check	8-711
Ratcheting Noise	
4L60-E/4L65-E	7-173
Rattle, Clunk or Shudder Noise - Power Steering System	2-10
Rear Axle Brace Replacement	
Rear Suspension	3-56
Rear Axle Housing Cover and Gasket	
Replacement	4-28
Rear Axle Housing Replacement	4-51
Rear Axle Lubricant Leak Diagnosis	4-25
Rear Axle Shaft Replacement	4-29
Rear Axle Shaft Seal and/or Bearing	
Replacement	4-32
Rear Compartment	
Floor Rail Replacement	8-82
Rear Compartment Cover	
Assist Rod Replacement	8-72
Rear Compartment Endgate	
Access Panel Replacement	8-85
Hinge Mounting Bracket Replacement	8-86
Liner Replacement	8-81
Rear Compartment Lid	
Release Inoperative	8-69
Switch Replacement	8-88
Rear Compartment Lid Ajar Indicator	
Inoperative	8-71
Rear Compartment Lid Description and Operation	8-131
Rear Compartment Liner	
Replacement	8-75, 8-78
Rear Compartment Upper Rail	
Replacement	8-84
Rear Drive Axle Description and Operation	4-64
Rear Drive Axle Disassembled Views	4-15
Rear Drive Axle Noises	4-16
Rear Suspension General Description	3-65
Rearview Mirror	
Replacement	8-1004
Support Replacement	8-1005

Rearview Mirror Lamp Replacement - Lighting Systems	8-642
Recirculation Door Replacement - HVAC	1-56
Reduced Volume - One or More Speakers - Entertainment	11-51
Refrigerant Recovery and Recharging - HVAC	1-23
Refrigerant System Capacities - HVAC	1-3
Registered and Non-Registered Trademarks	0-24
Reinitialization of the Power Window	8-362
Repair Materials - Flexible Plastic Part - Plastic Panel Information and Repair	8-683
Repair Materials - Rigid Plastic Part - Plastic Panel Information and Repair	8-683
Restricted Exhaust - Engine Exhaust	6-830
Retained Accessory Power Description and Operation	8-714
Diagnosis Diagnostic Starting Point - Retained Accessory Power	8-711
RAP Inoperative	8-713
RAP On After Timeout	8-713
Scan Tool Data Definitions	8-712
Scan Tool Data List	8-712
Symptoms - Retained Accessory Power	8-712
Ride Diagnosis	3-3
Road Test Procedure 4L60-E/4L65-E	7-146
Rocker Panel Replacement Inner	8-202
Roof Mount Bracket Replacement	8-193
Rough, Unstable, or Incorrect Idle and Stalling Engine Controls - 4.8L, 5.3L, 6.0L	6-695
RPO Code List	0-14
RTV and Anaerobic Sealer, Use of Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-311

S

Scan Tool Data Definitions ABS	5-161
Automatic Transmission 4L60-E/4L65-E	7-49
Body Control System	8-19
Body Rear End	8-69
Cruise Control	11-8, 11-9
Doors	8-315
Engine Controls - 4.8L, 5.3L, 6.0L	6-457
Engine Cooling	6-322
Engine Electrical	6-366
Entertainment	11-40
Horns	8-427
Instrument Panel, Gages and Console	8-453
Keyless Entry	11-80
Lighting Systems	8-577
Roof	8-738

Scan Tool Data List ABS	5-160
Automatic Transmission 4L60-E/4L65-E	7-47
Body Control System	8-18
Body Rear End	8-68
Cruise Control	11-8
Doors	8-314
Engine Controls - 4.8L, 5.3L, 6.0L	6-453
Engine Cooling	6-322
Engine Electrical	6-366
Entertainment	11-40
Horns	8-427
Instrument Panel, Gages and Console	8-450
Keyless Entry	11-80
Lighting Systems	8-576
Roof	8-736
Scan Tool Does Not Communicate with Class 2 Device Data Link Communications	8-290
Scan Tool Does Not Power Up Data Link Communications	8-289
Scan Tool Output Controls ABS	5-159
Automatic Transmission 4L60-E/4L65-E	7-43
Body Control System	8-18
Body Rear End	8-68
Doors	8-314
Engine Controls - 4.8L, 5.3L, 6.0L	6-463
Engine Cooling	6-321
Horns	8-427
Instrument Panel, Gages and Console	8-450
Keyless Entry	11-80
Lighting Systems	8-576
Roof	8-736
Schematic Icons ABS	5-152
Automatic Transmission 4L60-E/4L65-E	7-17
Data Link Communications	8-274
Engine Controls - 4.8L, 5.3L, 6.0L	6-417
Entertainment	11-23
Instrument Panel, Gages and Console	8-437
Schematic Icons - Lighting Systems	8-546
Schematics ABS	5-153
Audible Warnings	8-443
Automatic Transmission Controls 4L60-E/4L65-E	7-18
Body Control System	8-12
Body Rear End	8-64
Cruise Control	11-4
Data Link Connector (DLC)	8-275
Defogger	8-992
Door Lock/Indicator	8-298
Driver Information System	8-442
Engine Controls - 4.8L, 5.3L, 6.0L	6-418
Engine Cooling	6-318
Exterior Lamps	8-551

- Schematics (cont.)
- Fog Lamps 8-550
 - Garage Door Opener 11-69
 - Ground Distribution 8-1095
 - Headlamps/Daytime Running Lamps (DRL) 8-547
 - Horns 8-423
 - Hydraulic Brake Warning System 5-4
 - Instrument Cluster 8-438
 - Interior Lamps 8-557
 - Interior Lamps Dimming 8-559
 - Keyless Entry 11-76
 - Outside Mirrors 8-300
 - Power Distribution 8-1079
 - Power Folding Top 8-716
 - Power Windows 8-296
 - Radio/Audio System - Entertainment 11-24
 - SIR 9-18
 - Starting and Charging 6-361
 - Steering Wheel Controls - Entertainment 11-26
 - Theft Deterrent 11-103
 - Scraping Noise - Propeller Shaft 4-5
 - Seal Replacement
 - Hood Rear 8-59
 - Sealers, Adhesives, and Lubricants
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-12
 - Propeller Shaft 4-3
 - Rear Drive Axle 4-15
 - Sealing Strip Replacement
 - Front Door Window Belt Outer 8-385
 - Sealing Washer Replacement - HVAC 1-30
 - Seat
 - Back Heater Replacement
 - Front 8-979
 - Seat Belt Buckle Replacement
 - Front 9-10
 - Seat Belt Guide Replacement
 - Front 8-988
 - Seat Belt Replacement
 - Front 9-10
 - Seat Belt Retractor Anchor Plate Replacement 9-15
 - Seat Belts
 - Component Views 9-5
 - Connector End Views 9-6
 - Description
 - Seat Belt System Description and Operation 9-16
 - Diagnosis
 - Diagnostic Starting Point - Seat Belts 9-6
 - Fasten Safety Belt Indicator Always On 9-7
 - Fasten Safety Belt Indicator Inoperative 9-8
 - Operational and Functional Checks 9-6
 - Seat Belt Service Precautions 9-9
 - Symptoms - Seat Belts 9-6
 - Repair
 - Repairs and Inspections Required After a Collision 9-9
 - Schematic
 - Icons 9-3
 - Schematics 9-4
 - Specifications
 - Fastener Tightening 9-3
- Seats
- Adjuster Mechanism Replacement
 - Power 8-974
 - Description
 - Heated Seats Description and Operation 8-989
 - Lumbar Support Description and Operation 8-989
 - Memory Seats Description and Operation 8-990
 - Power Seats Systems Description and Operation 8-989
 - Diagnosis
 - Diagnostic Starting Point - Seats 8-923
 - Diagnostic Trouble Code (DTC) List 8-926
 - Heated Seat Inoperative 8-943
 - Lumbar Support Inoperative 8-942
 - Memory Seat Inoperative 8-940
 - Power Seat Does Not Move Forward/Rearward 8-936
 - Power Seat Does Not Tilt Forward 8-937
 - Power Seat Does Not Tilt Rearward 8-939
 - Power Seat Inoperative 8-933, 8-934
 - Power Seat Systems Diagnostic System Check 8-923
 - Scan Tool Data Definitions 8-925
 - Scan Tool Data List 8-924
 - Symptoms - Seats 8-933
 - Front Seat Back
 - Panel Replacement
 - Front 8-968
 - Lumbar Replacement
 - Front Seat 8-971
 - Memory Seat Control Module
 - Replacement 8-976
 - Power Seat Switch Replacement 8-972
 - Power Seat Systems Component Views 8-909
 - Power Seat Systems Connector
 - End Views 8-915
 - Repair
 - EZ Entry Seat Manual Release
 - Knob Replacement 8-963
 - Seat Back Recliner Cable
 - Replacement - Front 8-964
 - Seat Cushion Cover and Pad
 - Replacement - Front 8-953
 - Seat Back Cover and Pad Replacement
 - Front 8-957
 - Seat Back Frame Replacement
 - Front 8-960
 - Seat Back Recliner Handle Replacement
 - Front 8-964
 - Seat Back Recliner Replacement
 - Front 8-960
 - Seat Cushion Frame Replacement
 - Front 8-947
 - Seat Cushion Trim Panel Replacement
 - Outer 8-951
 - Seat Replacement 8-946
 - Seat Switch Bezel Replacement 8-973
 - Specifications
 - Fastener Tightening 8-902
 - Seats Cushion Heater Element
 - Replacement - Front 8-982

- Second Gear Start
 - 4L60-E/4L65-E 7-173
- Second/Third Gear Only or First/Fourth Gear Only
 - 4L60-E/4L65-E 7-168
- Separating Parts
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-310
- Service Parts ID Label 0-13
- Service Port Valve Core
 - Replacement - HVAC 1-36
- Service Prior to Assembly
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-258
- Service Programming System (SPS) 10-8
- Shift Lever Indicates Wrong Gear
 - 4L60-E/4L65-E 7-174
- Shift Lock Control
 - Components
 - Automatic Transmission Shift Lock Control Component Views 7-7
 - Automatic Transmission Shift Lock Control Connector End Views 7-8
 - Description
 - Shift Lock Control Description and Operation 7-12
 - Diagnosis
 - Diagnostic Starting Point - Automatic Transmission Shift Lock Control 7-9
 - Park Lock Solenoid Inoperative 7-9
 - Shift Lever Can Be Moved with Brake Pedal Depressed 7-11
 - Shift Lever Does Not Move with Brake Pedal Depressed 7-10
 - Symptoms - Automatic Transmission Shift Lock Control 7-9
 - Schematics
 - Automatic Transmission Shift Lock Control Schematics 7-6
- Shift Solenoid Leak Test
 - 4L60-E/4L65-E 7-155
- Shift Solenoid Valve State and Gear Ratio
 - 4L60-E/4L65-E 7-16
- Shift Speed
 - 4L60-E/4L65-E 7-16
- Shims Inspection
 - Rear Drive Axle 4-52
- Shock Absorber
 - Disposal - Front 3-48
 - Disposal - Rear 3-62
 - Replacement - Rear 3-60
- Shock Module Replacement
 - Front Suspension 3-41
- Shock Module Yoke Replacement
 - Front Suspension 3-46
- Shock, Shock Component and/or Spring Replacement
 - Front Suspension 3-43
- Shoulder Belt Guide Bracket Replacement 9-13
- Shudder on Acceleration at Low Speed - Propeller Shaft 4-5
- SIR
 - Component Views 9-21
 - Connector End Views 9-32
 - Description
 - SIR Description and Operation 9-146
- SIR (cont.)
 - Diagnosis
 - A Diagnostic System Check 9-39
 - AIR BAG Indicator Circuit Malfunction 9-77
 - Diagnostic Starting Point - SIR 9-38
 - Diagnostic Trouble Code (DTC) List 9-41
 - Scan Tool Data Definitions 9-40
 - Scan Tool Data List 9-40
 - Symptoms - SIR 9-76
 - Inflatable Restraint Front Side Impact Module Replacement 9-112
 - Inflatable Restraint Instrument Panel Inflator Module Replacement 9-108
 - Inflatable Restraint I/P Module LED Replacement 9-115
 - Inflatable Restraint I/P Module Switch Replacement 9-113
 - Inflatable Restraint Sensing and Diagnostic Module Replacement 9-100
 - Inflatable Restraint Side Impact Sensor Replacement 9-99
 - Inflatable Restraint Steering Wheel Module Coil Replacement 9-103
 - Inflatable Restraint Steering Wheel Module Replacement 9-102
 - Inflator Module Handling and Scrapping 9-120
 - Pretensioner Handling and Scrapping 9-137
 - Repairs and Inspections Required After an Accident 9-119
 - Schematics 9-18
 - Icons 9-17
 - Service Precautions 9-81
 - Special Tools 9-150
 - Specifications
 - Fastener Tightening 9-17
- Slip/Flare in Any Gear
 - 4L60-E/4L65-E 7-173
- Slipping or Harsh 1-2 Shift
 - 4L60-E/4L65-E 7-167
- Slips in First Gear
 - 4L60-E/4L65-E 7-166
- Slips in Fourth Gear or No Fourth Gear
 - 4L60-E/4L65-E 7-172
- Slips in Reverse or No Reverse
 - 4L60-E/4L65-E 7-169
- Slips or Rough 3-4 Shift, No 3-4 Shift
 - 4L60-E/4L65-E 7-169
- Soap Suds or Bubble Test 0-114
- Spark Plug
 - Inspection
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-806
 - Replacement
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-809
 - Wire Inspection
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-804
 - Wire Replacement
 - Engine Controls - 4.8L, 5.3L, 6.0L 6-805
- Speaker Replacement - Front Lower - Entertainment 11-59
- Speaker Replacement - Front Upper - Entertainment 11-61
- Speaker Replacement - Rear - Entertainment 11-63

- Speaker Replacement Reference -
 - Entertainment 11-51
- Speakers Inoperative - One or More -
 - Entertainment 11-51
- Special Tools
 - ABS 5-209
 - Air/Wind Noise 0-115
 - Automatic Transmission
 - 4L60-E/4L65-E 7-244
 - Body Front End 8-62
 - Body Rear End 8-131
 - Disc Brakes 5-118
 - Doors 8-394
 - Engine Controls 4.8L, 5.3L, 6.0L 6-826
 - Engine Cooling 6-359
 - Engine Electrical 6-409
 - Engine Exhaust 6-853
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-312
 - Entertainment 11-67
 - Exterior Trim 8-408
 - Front Suspension 3-50
 - Garage Door Opener 11-74
 - General Information 0-32
 - HVAC 1-59
 - HVAC - Manual 1-104
 - Hydraulic Brakes 5-62
 - Instrument Panel, Gages and Console 8-530
 - Keyless Entry 11-90
 - Lighting Systems 8-674
 - Park Brake 5-151
 - Power Steering 2-42
 - Propeller Shaft 4-13
 - Rear Drive Axle 4-65
 - Rear Suspension 3-65
 - SIR 9-150
 - Stationary Windows 8-1019
 - Steering Wheel and Column 2-98
 - Suspension General Diagnosis 3-13
 - Theft Deterrent 11-142
 - Tires and Wheels 3-75
 - Wipers/Washer Systems 8-1044
 - Wiring Systems 8-1212
- Special Tools Ordering Information 0-5
- Specifications
 - Fastener Tightening
 - HVAC - Manual 1-61
 - Seat Belts 9-3
 - Seats 8-902
 - SIR 9-17
 - Steering Wheel and Column 2-43
 - Tires and Wheels 3-66
 - Wheel Alignment 3-14
 - Wipers/Washer System 8-1020
 - Wiring Systems 8-1045
 - Propeller Shaft Runout 0-47
 - Tire and Wheel Runout 0-47
 - Wheel Alignment 3-14
- Speedometer and/or Odometer Inaccurate
 - or Inoperative 8-482
- Splash Shield
 - Replacement - Engine 8-60
- Squeak Noise - Propeller Shaft 4-5
- Squeaks and Rattles
 - Diagnosis
 - Squeaks and Rattles 0-116
 - Tools
 - Special Tools 0-116
- Stabilizer Shaft
 - Insulator Replacement
 - Front Suspension 3-23
 - Rear Suspension 3-59
 - Link Replacement
 - Front Suspension 3-22
 - Rear Suspension 3-59
 - Replacement
 - Front Suspension 3-21
 - Rear Suspension 3-57
- Starter Motor
 - Noise Diagnosis - Engine Electrical 6-387
 - Replacement - Engine Electrical 6-401
 - Shield Replacement - Engine Electrical 6-403
- Starter Motor Usage Specifications - Engine
 - Electrical 6-360
- Starter Solenoid Clicks, Engine Does Not
 - Crank - Engine Electrical 6-386
- Starter Solenoid Does Not Click - Engine
 - Electrical 6-383
- Starting System Description and Operation 6-408
- Stationary Windows
 - Component Views 8-994
 - Connector End Views 8-996
 - Description
 - Adhesive Service Kit Description 8-1017
 - Automatic Day-Night Mirror Description
 - and Operation 8-1018
 - Full-Cut Method Description 8-1017
 - General 8-1017
 - Rear Window Defogger Description and
 - Operation 8-1018
 - Diagnosis
 - Automatic Day-Night Mirrors
 - Inoperative 8-1000
 - Defogger Grid Lines 8-1000
 - Defogger Inoperative - Rear 8-997
 - Diagnostic Starting Point - Stationary
 - Windows 8-996
 - Symptoms - Stationary Windows 8-996
 - Repair
 - Stationary Window Reveal Molding
 - Repair 8-1003
 - Urethane Installation of Stationary
 - Windows 8-1010
 - Schematics
 - Defogger 8-992
 - Inside Rearview Mirror Schematics 8-993
 - Special Tools 8-1019
- Steering Effort Easy in One or Both
 - Directions - Power Steering
 - System 2-12
- Steering Effort Hard in One or Both
 - Directions - Power Steering
 - System 2-12

- Steering Gear Cylinder Pipe Assemblies/
O-Ring Seals Replacement - Off
Vehicle 2-36
- Steering Gear Stub Shaft Seals and
Bearing Replacement - Off
Vehicle 2-38
- Steering Knuckle Replacement
Front Suspension 3-27
- Steering Wheel and Column
Components
Wheel/Column Component Views 2-46
Wheel/Column Connector End Views 2-48
- Description
Steering Wheel and Column Description
and Operation 2-97
- Diagnosis
High Lock Effort 2-53
High Shift Effort 2-54
Ignition Can/Cannot Be Turned Off with
Transmission in Any Gear 2-49
Key Cannot Be Removed in the Off
Lock Position 2-52
Lock System Does Not Lock 2-51
Lock System Does Not Unlock 2-51
Lock System Sticks in Start 2-52
Looseness in Steering Column 2-55
Noise in Steering Column 2-53
Steering Column Tilt Function
Inoperative 2-49
Symptoms - Steering Wheel and
Column 2-48
- Repair
Column Replacement 2-89
Ignition Lock Cylinder Case
Replacement 2-70
Ignition Lock Cylinder Replacement 2-68
Ignition Switch Replacement 2-65
Inflatable Restraint Steering Wheel
Module Coil Centering 2-95
Intermediate Steering Shaft
Replacement - Lower 2-58
Intermediate Steering Shaft
Replacement - Upper 2-56
Multifunction Turn Signal Switch
Housing Replacement 2-71
Multifunction, Turn Signal Switch
Replacement 2-73
Steering Column Jacket Replacement 2-92
Steering Column Shaft Replacement 2-92
Steering Column Tilt Head Housing
Replacement 2-84
Steering Column Wire Harness
Assembly Replacement 2-93
Steering Wheel Control Switch
Assembly Replacement 2-76
Steering Wheel Replacement 2-78
- Schematic
Column/Ignition Lock 2-44
- Special Tools 2-98
- Specifications
Fastener Tightening 2-43
- Steering Wheel and Column (cont.)
Steering Column Accident Damage
Inspection 2-61
Steering Column Trim Covers
Replacement 2-62
Visual Identification
Disassembled View 2-45
- Steering Wheel Controls Inoperative -
Entertainment 11-50
- Stop Lamps Always On - Lighting Systems 8-626
- Stop Lamps Inoperative - Lighting Systems 8-627
- Storage Compartment Replacement -
Instrument Panel 8-497
- Strategy Based Diagnosis 0-30
- Striker Replacement
Doors 8-370
- Structure Adhesive - Identification 8-149
- Structure Foam
Identification 8-152
Replacement 8-160
- Structure Identification 8-146
- Struts or Shock Absorbers
Diagnosis
On-Vehicle Testing 3-11
- Sunshade Anchor Replacement -
Interior Trim 8-542
- Sunshade Replacement - Interior Trim 8-541
- Support Cable
Replacement - Endgate 8-111
- Surge Tank
Replacement - Engine Cooling 6-336
- Surge Tank Hose/Pipe
Replacement
Inlet - Engine Cooling 6-337
- Surges/Chuggles
Engine Controls - 4.8L, 5.3L, 6.0L 6-681
- Suspension
Diagnosis
Body Leans or Sways in Corners 3-5
Memory Steer 3-6
Noise - Front Suspension 3-8
Noise - Rear Suspension 3-9
Poor Directional Stability 3-7
Ride Diagnosis 3-3
Struts or Shock Absorbers On-Vehicle
Testing 3-11
Suspension Bottoms 3-5
Symptoms 3-3
Vehicle Leads/Pulls Diagnosis
Vehicle Leads/Pulls 3-4
Wheel Bearings 3-11
Special Tools Diagnosis 3-13
- Suspension General Diagnosis
Diagnosis
Ball Joint Inspection 3-10
Diagnostic Starting Point 3-3
- Switch
Power Seat Switch Replacement 8-972
Steering Wheel Control Switch Assembly
Replacement 2-76
- Switch Replacement
Side Window and Multi-Function
Doors 8-337

Symptoms

ABS	5-187
Automatic Transmission	
4L60-E/4L65-E	7-139
Body Control System	8-31
Body Rear End	8-69
Cruise Control	11-16
Data Link Communications	8-288
Doors	8-324
Engine Controls - 4.8L, 5.3L, 6.0L	6-676
Engine Cooling	6-325
Engine Electrical	6-372
Engine Exhaust	6-830
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-33
Entertainment	11-44
Garage Door Opener	11-71
Horns	8-429
Hydraulic Brakes	5-7
Instrument Panel, Gages and Console	8-476
Keyless Entry	11-82
Lighting Systems	8-603
Park Brake	5-119
Power Steering System	2-6
Propeller Shaft	4-4
Rear Drive Axle	4-16
Roof	8-784

T

Tachometer Inaccurate or Inoperative	8-483
Tail Lamp Bulb Replacement - Lighting	
Systems	8-670
Tail Lamp Replacement - Lighting Systems	8-669
Tail Lamps Inoperative - Lighting Systems	8-628
Tail, Marker, and License Lamps Always	
On - Lighting Systems	8-629
Tail, Marker, Land License Lamps	
Inoperative - Lighting Systems	8-630
Temperature vs Resistance	
Engine Controls - 4.8L, 5.3L, 6.0L	6-410
Theft Deterrent	
Component Views	11-105
Connector End Views	11-106
Description	
Content Theft Deterrent (CTD)	
Description and Operation	11-139
Theft Systems Description and	
Operation	11-139
Vehicle Theft Deterrent (VTD)	
Description and Operation	11-140
Diagnosis	
Content Theft Deterrent Alarm Mode	
Inoperative	11-133
Content Theft Deterrent Does Not	
Disarm with Key Lock	11-134
Diagnostic Starting Point - Theft	
Deterrent	11-106
Diagnostic System Check	11-107
Diagnostic Trouble Code (DTC) List	11-110
Horn Inoperative in CDT Alarm Mode	11-135
Lights Inoperative in CDT Alarm Mode	11-136

Theft Deterrent (cont.)

Diagnosis (cont.)	
Scan Tool Data Definitions	11-109
Scan Tool Data List	11-108
Security Indicator Always On or	
Flashing	11-136
Security Indicator Inoperative	11-137
Symptoms - Theft Deterrent	11-132
Repair	
Adding Keys	11-138
Programming Theft Deterrent System	
Components	11-138
Replacing Keys	11-138
Schematics	11-103
Special Tools	11-142
Thermal Expansion Valve	
Replacement - HVAC	1-37
Thermostat	
Replacement - Engine Cooling	6-343
Thermostat Diagnosis - Engine Cooling	6-331
Thermostat Housing	
Replacement - Engine Cooling	6-341
Third Gear Only	
4L60-E/4L65-E	7-168
Thread Inserts	0-18
Thread Repair	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-247
Thread Repair Specifications	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-13
Throttle Actuator Control (TAC) Module	
Replacement	
Engine Controls - 4.8L, 5.3L, 6.0L	6-744
Throttle Actuator Control (TAC) System	
Description	
Engine Controls - 4.8L, 5.3L, 6.0L	6-818
Throttle Body	
Assembly Replacement	
Engine Controls - 4.8L, 5.3L, 6.0L	6-754
Cleaning Procedure	
Engine Controls - 4.8L, 5.3L, 6.0L	6-757
Installation	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-299
Removal	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-158
Tie Bar	
Replacement	
Upper	8-177
Replacement - Upper	8-57
Tie Rod End Replacement - Outer - On	
Vehicle	2-21
Tie Rod Replacement	
Rear Axle	3-55
Tie Rod Replacement - Inner - Power	
Steering	2-33
Timing Chain	
and Sprockets Cleaning and Inspection	
Engine Mechanical - 4.8L, 5.3L,	
and 6.0L	6-216

- Timing Chain and Sprockets
 - Installation
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-270
 - Removal
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-174
- Timing Chain and Sprockets Replacement
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-128
- Tire
 - Inflation Description 3-73
 - Mounting and Dismounting 3-72
 - Rotation 3-72
- Tire and Wheel Runout Specifications 0-47
- Tire Inflation Pressure Specifications 0-34
- Tire Repair 3-72
- Tires and Wheels
 - Description
 - All Seasons Tires Description 3-74
 - General 3-72
 - Inflation 3-73
 - Metric Wheel Nuts and Bolts 3-73
 - P-Metric Sized Tires 3-74
 - Replacement Wheels 3-75
 - Tread Wear Indicators 3-73
 - Diagnosis
 - Irregular or Premature Wear 3-66
 - Radial Tire Lead/Pull Correction 3-69
 - Waddle Complaint 3-67
 - Wheel Mounting Surface Check 3-67
 - Special Tools 3-75
 - Specifications
 - Fastener Tightening 3-66
 - Wheel Removal and Installation 3-70
- Toe Adjustment, Front 3-16
- Tools and Equipment
 - Engine Mechanical - 4.8L, 5.3L, and 6.0L 6-312
- Torque Converter
 - End Play Specifications
 - 4L60-E/4L65-E 7-15
- Torque Converter Clutch
 - Intermittent - OK Cold/Slips Hot
 - 4L60-E/4L65-E 7-172
- Torque Converter Clutch Pulse Width
 - Modulation (TCC PWM)
 - Solenoid, TCC Solenoid and Wiring Harness
 - 4L60-E/4L65-E 7-213
- Torque Converter Clutch Shudder
 - 4L60-E/4L65-E 7-171
- Torque Converter Clutch Slip
 - 100 RPM Slip
 - 4L60-E/4L65-E 7-172
 - with Stall/Stumble
 - 4L60-E/4L65-E 7-172
- Torque Converter Diagnosis Procedure
 - 4L60-E/4L65-E 7-149
- Tracing Powder or Chalk Test 0-114
- Traction Control Switch Replacement - ABS 5-201
- Traction Off Indicator
 - Always On - ABS 5-190
 - Inoperative - ABS 5-191
- Trailer Hitch Replacement 8-418
- Training Information 0-5
- Transmission
 - Replacement
 - 4L60-E/4L65-E 7-229
- Transmission Adaptive Functions
 - 4L60-E/4L65-E 7-239
- Transmission and Engine Usage 0-11
- Transmission Component and System
 - Description
 - 4L60-E/4L65-E 7-239
- Transmission Extension Housing Assembly
 - Replacement
 - 4L60-E/4L65-E 7-225
- Transmission Extension Housing Rear Oil
 - Seal Replacement
 - 4L60-E/4L65-E 7-224
- Transmission Fluid Checking Procedure
 - 4L60-E/4L65-E 7-144
- Transmission Fluid Cooler Hose/Pipe
 - Replacement
 - 4L60-E/4L65-E 7-188
- Transmission Fluid Pressure Manual Valve
 - Position Switch Logic
 - 4L60-E/4L65-E 7-16
- Transmission Fluid Temperature Sensor
 - Specifications
 - 4L60-E/4L65-E 7-13
- Transmission General Information
 - 4L60-E/4L65-E 7-234
- Transmission General Specifications
 - 4L60-E/4L65-E 7-14
- Transmission ID and VIN Derivative
 - Location 0-12
- Transmission Identification Information
 - 4L60-E/4L65-E 7-236
- Transmission Mount
 - Replacement
 - 4L60-E/4L65-E 7-226
- Transmission Oil Cooler Line
 - Quick Connect Fitting
 - 4L60-E/4L65-E 7-189
- Transmission Overheats
 - 4L60-E/4L65-E 7-164
- Transmission Range Switch Logic
 - 4L60-E/4L65-E 7-16
- Transmission Support Replacement 8-411
- Transmitter
 - Battery Replacement - Keyless Entry 11-87
 - Programming - Keyless Entry 11-89
 - Synchronization - Keyless Entry 11-88
- Trim Height Inspection Procedure 3-12
- Trim Height Specifications 3-3
- Trim Panel
 - Replacement
 - Door 8-345
- Trim Panel Replacement
 - Instrument Panel Center 8-495
 - Instrument Panel Left 8-507
 - Instrument Panel Right 8-508
 - Instrument Panel Upper 8-494
- Trim Plate Replacement
 - Console Upper 8-516
 - Instrument Panel Upper 8-493

Trim Replacement	
Hinge Pillar - Interior Trim	8-532
Lock Pillar - Interior Trim	8-532
Turn Signal Lamps and/or Indicators Aways	
On or Flashing - Lighting Systems	8-631
Turn Signal Lamps and/or indicators	
Inoperative - Lighting Systems	8-632

U

Universal Joint Noise - Propeller Shaft	4-4
Universal Joint Replacement - External	
Snap Ring - Propeller Shaft	4-10
Universal Joint Replacement - Nylon	
Injected Ring - Propeller Shaft	4-7
Upper Engine Noise, Regardless of Engine	
Speed	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-37

V

Vacuum Brake Booster Check Valve and/or	
Hose Replacement - Hydraulic Brakes	5-60
Vacuum Brake Booster Replacement -	
Hydraulic Brakes	5-58
Valve Body and Pressure Switch	
Replacement	
4L60-E/4L65-E	7-201
Valve Guide Reaming/Valve and Seat	
Grinding	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-224
Valve Lifter	
Installation	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-283
Removal	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-168
Valve Lifter Replacement	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-106
Valve Lifters and Guides Cleaning and	
Inspection	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-218
Valve Rocker Arm	
Push Rod Installation	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-289
Push Rod Removal	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-166
Push Rods Cleaning and Inspection	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-217
Cover Cleaning and Inspection	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-239
Cover Installation - Left	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-291
Cover Installation - Right	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-292

Valve Rocker Arm (cont.)	
Cover Removal - Left	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-164
Cover Removal - Right	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-165
Valve Rocker Arm and Push Rod	
Replacement	
Engine Mechanical 4.8L, 5.3L, and 6.0L	6-90
Valve Rocker Arm Cover	
Replacement - Left	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-82
Valve Rocker Arm Cover	
Replacement - Right	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-86
Valve Stem Oil Seal and Valve Spring	
Replacement	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-93
Vanity Mirror Lamp Bulb Replacement -	
Lighting Systems	8-643
Vanity Mirror Lamp(s) Inoperative - Lighting	
Systems	8-634
Vehicle Certification Label	0-7, 0-8
Vehicle Identification	0-6
Vehicle Speed Sensor	
Replacement	
4L60-E/4L65-E	7-226
Vent Hose Replacement	
Rear Drive Axle	4-27
Vibration	
Special Tools	0-112
Vibration Diagnosis and Correction	
Description	
Electronic Vibration Analyzer (EVA)	
Description, Setup, and Operation	0-109
Reed Tachometer Description	0-111
Vibrate Software Description and Operation	0-111
Vibration Theory and Terminology	0-100
Diagnosis	
Brake Rotor/Drum Balance Inspection	0-81
Component Rotational Speed	
Calculation	0-51
Diagnostic Starting Point - Vibration	
Diagnosis and Correction	0-48
Driveline Working Angles Measurement	0-88
Engine Order Classification	0-62
Hub/Axle Flange and Wheel Stud	
Runout Inspection	0-82
Pinion Flange Runout Measurement	0-87
Propeller Shaft Phasing Inspection	0-89
Propeller Shaft Runout Measurement	0-85
Symptoms - Vibration Diagnosis and Correction	0-75
Tire and Wheel Assembly Isolation Test	0-83
Tire and Wheel Assembly Runout	
Measurement - Off-Vehicle	0-78
Tire and Wheel Assembly Runout	
Measurement - On-Vehicle	0-77
Tire and Wheel Inspection	0-76
Vehicle-to-Vehicle Diagnostic	
Comparison	0-76

Vibration Diagnosis and Correction (cont.)

Diagnosis (cont.)	
Vibration Analysis - Driveline	0-81
Vibration Analysis - Engine	0-61
Vibration Analysis - Engine Balance	0-70
Vibration Analysis - Engine/Accessory Isolation	0-65
Vibration Analysis - Hub and/or Axle Input	0-59
Vibration Analysis - Road Testing	0-49
Vibration Analysis - Tire and Wheel	0-53
Vibration Diagnostic Aids	0-72
Vibration Diagnostic Aids - Vibration Duplicated, Appears to be Potential Operating Characteristic	0-74
Vibration Diagnostic Aids - Vibration Duplicated, Component Not Identified	0-74
Vibration Diagnostic Aids - Vibration Duplicated, Difficult to Isolate/ Balance Component	0-74
Vibration Diagnostic Aids - Vibration Intermittent or Not Duplicated	0-72
Vibration in Service-Stall Test (Non-Torque Sensitive)	0-84
Vibration in Service-Stall Test (Torque Sensitive)	0-84
Repair	
Driveline System Balance Adjustment	0-96
Driveline Working Angles Adjustment	0-98
Propeller Shaft Phasing Correction	0-99
Tire and Wheel Assembly Balancing - Off-Vehicle	0-90
Tire and Wheel Assembly Balancing - On-Vehicle	0-94
Tire and Wheel Assembly-to-Hub/Axle Flange Match-Mounting	0-95
Tire-to-Wheel Match-Mounting (Vectoring)	0-94
Vibration in Reverse and Whining Noise in Park	
4L60-E/4L65-E	7-173
VIN Derivative	0-6
VIN, Partial, Location and Engine ID	0-10

W

Wander Description	3-19
Washer	
Pump Replacement	8-1036
Solvent Container Replacement	8-1035
Water Deflector Replacement	
Front Door	8-349
Water Management Description and Operation	8-62
Water Pump	
Cleaning and Inspection	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-247

Water Pump (cont.)

Installation	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-300
Removal	
Engine Mechanical - 4.8L, 5.3L, and 6.0L	6-157
Replacement - Engine Cooling	6-347
Waterleaks	
Body Waterleak Repair	0-120
Diagnosis	
Air Hose Test	0-119
Dust Leaks	0-118
Test Preparation	0-117
Water Hose Test	0-119
Stationary Window Waterleak Repair	0-121
Weatherstrip Replacement	
Door	8-387
Endgate - Bottom	8-127
Endgate - Mocket Side	8-128
Endgate - Side	8-127
Rear Compartment Lid	8-129
Rear Compartment Opening	8-130
Wheel	
Removal and Installation	3-70
Wheel Alignment	
Description	
Camber	3-17
Caster	3-17
Lead/Pull	3-18
Memory Steer	3-19
Scrub Radius	3-19
Setback	3-18
Thrust Angles	3-18
Toe	3-18
Wander	3-19
Front Caster and Camber Adjustment	3-15
Front Toe Adjustment	3-16
Measuring	3-14
Specifications	3-14
Fastener Tightening	3-14
Wheel Bearing Diagnosis	3-11
Wheel Bearing, Hub, Knuckle, and Seal Replacement	
Front	3-39
Wheel Bearing Wear	
Rear Drive Axle	4-18, 4-20
Wheel Hub, Bearing, Knuckle, and Seal Replacement	
Front	3-39
Wheel Speed Sensor	
Replacement - ABS	5-196
Wheel Stud Replacement	
Front Suspension	3-38
Rear Suspension	3-64
Wheelhouse Liner	
Replacement - Front	8-55
Wheelhouse Liner Panel	
Replacement - Rear	8-92

- Wheelhouse Replacement
 - Front 8-180
 - Rear Outer 8-224, 8-227
- Wheels
 - Replacement Wheels Description 3-75
- Whine Noise Varying with RPM or Fluid Pressure
 - 4L60-E/4L65-E 7-174
- Whine or Growl Noise - Power Steering System 2-11
- Whining Noise in Park and Vibration in Reverse
 - 4L60-E/4L65-E 7-173
- Window Height Adjustment
 - Door Minor 8-376
- Window Regulator
 - Motor Replacement
 - Door 8-381
 - Replacement
 - Doors 8-378
- Window Replacement
 - Door 8-382
- Window Tip-In Adjustment - Door 8-374
- Windshield Frame Header Panel
 - Replacement
 - Front 8-196
 - Front Inner 8-199
- Windshield Glass Cleaning 8-1043
- Windshield Replacement 8-1007
- Wiper
 - Arm Blade Replacement 8-1040
 - Arm Replacement 8-1039
 - Blade Element Cleaning 8-1043
 - Blade Element Replacement 8-1041
 - Chatter Repair 8-1043
 - Motor Replacement 8-1041
 - Transmission Replacement 8-1042
 - Washer Nozzle Replacement 8-1038
- Wipers/Washer Systems
 - Component Views 8-1022
 - Connector End Views 8-1024
 - Description
 - Wiper/Washer System Description and Operation 8-1044
 - Diagnosis
 - Diagnostic System Check 8-1025
 - Washer Always On 8-1026
 - Washers Inoperative 8-1028
 - Wiper Arm Tip Pressure Check 8-1034
 - Wiper Blade Element Check 8-1034
 - Wipers Always On 8-1030
 - Wipers Inoperative - All Modes 8-1031
 - Wipers Inoperative - One or More Modes 8-1032
 - Schematics
 - Wiper/Washer System Schematics 8-1021
 - Special Tools 8-1044
 - Specifications
 - Fastener Tightening 8-1020
- Wiper/Washer Systems
 - Diagnosis
 - Diagnostic Starting Point - Wiper/Washer Systems 8-1025
 - Symptoms - Wiper/Washer Systems 8-1026
 - Repair
 - Hose Replacement - Windshield Washer 8-1038
- Wiring Harness
 - Replacement
 - Front Door 8-370
- Wiring Systems
 - Components
 - Splice Pack Connector End Views 8-1201
 - Description
 - Inline Harness Connector End Views 8-1173
 - Master Electronic Component List 8-1124
 - Diagnosis
 - Checking Aftermarket Accessories 8-1054
 - Circuit Protection
 - Circuit Breakers 8-1061
 - Fuses 8-1061
 - Fusible Links 8-1061
 - Circuit Testing 8-1055
 - Connector Position Assurance Locks 8-1069
 - Connector Repairs 8-1069
 - Electrical Symbols 8-1047
 - Flat Wire Repairs 8-1062
 - General Electrical Diagnosis
 - Procedures 8-1054
 - HO2S Wiring Repairs 8-1062
 - Inducing Intermittent Fault Conditions 8-1059
 - Measuring Frequency 8-1057
 - Measuring Voltage 8-1056
 - Measuring Voltage Drop 8-1057
 - Probing Electrical Connectors 8-1055
 - Pull to Seat Connectors 8-1071
 - Push to Seat Connectors 8-1070
 - Repairing Connector Terminals 8-1077
 - Repairing Damaged Wire Insulation 8-1062
 - Scan Tool Snapshot Procedure 8-1060
 - SIR Wiring Repairs 8-1067
 - Splicing Copper Wire Using
 - Splice Clips 8-1062
 - Splicing Copper Wire Using Splice Sleeves 8-1064
 - Splicing Inline Harness Diodes 8-1066
 - Splicing Twisted or Shielded Cable 8-1065
 - Terminal Position Assurance Locks 8-1069
 - Testing for Continuity 8-1057
 - Testing for Electrical Intermittents 8-1060
 - Testing for Poor Connections 8-1058
 - Testing for Short to Ground 8-1057
 - Testing for Short to Voltage 8-1058
 - Troubleshooting with a Digital Multimeter 8-1056
 - Troubleshooting with a Test Light 8-1056
 - Truck Zoning 8-1046
 - Using Connector Test Adapters 8-1055
 - Using Fused Jumper Wires 8-1056
 - Weather Pack Connectors 8-1077
 - Wiring Repairs 8-1062

Wiring Systems (cont.)		Wiring Systems (cont.)	
Electrical Center Identification	8-1154	Schematics	
Power and Grounding		Ground Distribution	8-1095
Component Views	8-1143	Harness Routing Views	8-1103
Power and Grounding Connector		Power and Grounding Schematic Icons ...	8-1078
End Views	8-1172	Power Distribution	8-1079
Repair		Special Tools	8-1212
Console Electrical Center Replacement ...	8-1207	Specifications	
Rear Electrical Center Replacement	8-1210	Fastener Tightening	8-1045
Relay Replacement	8-1203, 8-1204	Work Sheets, Diagnostic	0-5
Underhood Electrical Center			
Replacement	8-1205		