

SERVICE MANUAL



SSR

2002

ST TRUCK

INCLUDES:

**General Information, HVAC, Steering,
Suspension, Driveline/Axle,
Brakes, Engine**



GMT/06-SSR-1

Volume 1 of 2

CAUTION

Caution: In order to reduce the chance of personal injury and/or property damage, carefully observe the instructions that follow:

The service manuals of General Motors Corporation are intended for use by professional, qualified technicians. Attempting repairs or service without the appropriate training, tools, and equipment could cause injury to you or others. This could also damage the vehicle, or cause the vehicle to operate improperly.

Proper vehicle service and repair are important to the safety of the service technician and to the safe, reliable operation of all motor vehicles. If you need to replace a part, use the same part number or an equivalent part. Do not use a replacement part of lesser quality.

The service procedures we recommend and describe in this service manual are effective methods of performing service and repair. Some of the procedures require the use of tools that are designed for specific purposes.

Accordingly, any person who intends to use a replacement part, a service procedure, or a tool that is not recommended by General Motors, must first establish that there is no jeopardy to personal safety or the safe operation of the vehicle.

This manual contains various "Cautions" and "Notices" that you must observe carefully in order to reduce the risk of personal injury during service or repair. Improper service or repair may damage the vehicle or render the vehicle unsafe. These "Cautions" and "Notices" are not exhaustive. General Motors can not possibly warn of all the potentially hazardous consequences of your failure to follow these instructions.

This manual covers service procedures to vehicles that are equipped with a Supplemental Inflatable Restraint (SIR). Refer to the "Cautions" in Cautions and Notices and in Restraints. Refer to SIR component and wiring location views in Restraints before performing a service on or around SIR components or wiring. Failure to follow these "Cautions" could cause air bag deployment, personal injury, or otherwise unneeded SIR repairs.

In order to help avoid accidental air bag deployment and personal injury, whenever you service a vehicle that requires repair of the SIR and another vehicle system, we recommend that you first repair the SIR, then go on to the other system.

2006 Chevrolet SSR Service Manual

Volume 1

This manual provides information on the diagnosis, the service procedures, the adjustments, and the specifications for the 2006 Chevrolet SSR.

Information on transmission unit repair (overhaul) can be found in the 2006 Transmission/Transaxle/Transfer Case Unit Repair Manual (TURM), available separately. The TURM contains information on automatic and manual transmissions, including the fluid flow and circuit description information.

The technicians who understand the material in this manual and in the appropriate Dealer Service Bulletins better serve the vehicle owners.

When this manual refers to a brand name, a part number, or a specific tool, you may use an equivalent product in place of the recommended item. All information, illustrations, and specifications in this manual are based on the latest product information available at the time of publication approval. General Motors reserves the right to make changes at any time without notice.

Published by
**North American Operations
General Motors Corporation
Warren, Michigan 48090**




TABLE OF CONTENTS

Volume 1

Preface	P-1
Cautions and Notices	P-3
General Information	0-1
General Information	0-3
Maintenance and Lubrication	0-25
Vibration Diagnosis and Correction	0-26
Air/Wind Noise	0-90
Squeaks and Rattles	0-92
Waterleaks	0-93
HVAC	1-1
Heating, Ventilation and Air Conditioning	1-3
HVAC Systems - Manual	1-61
Steering	2-1
Power Steering System	2-3
Steering Wheel and Column	2-41
Suspension	3-1
Suspension General Diagnosis	3-3
Wheel Alignment	3-13
Front Suspension	3-19
Rear Suspension	3-52
Tires and Wheels	3-67
Driveline/Axle	4-1
Propeller Shaft	4-3
Rear Drive Axle	4-14
Brakes	5-1
Hydraulic Brakes	5-3
Disc Brakes	5-61
Park Brake	5-118
Antilock Brake System	5-150
Engine	6-1
Engine Mechanical - 6.0L	6-7
Engine Cooling	6-272
Engine Electrical	6-318
Engine Controls - 6.0L	6-371
Engine Exhaust	6-811
Index	INDEX-1

Volume 2

Preface	P-1
Cautions and Notices	P-3
Transmission/Transaxle	7-1
Manual Transmission - Tremec 6-Speed	7-5
Shift Lock Control	7-49
Automatic Transmission - 4L60-E/ 4L65-E/4L70-E	7-57
Clutch	7-318
Body	8-1
Body Front End	8-11
Body Rear End	8-33
Bumpers	8-99
Collision Repair	8-110
Doors	8-241
Exterior Trim	8-338
Frame and Underbody	8-352
Horns	8-364
Instrument Panel, Gages, and Console	8-378
Interior Trim	8-491
Lighting Systems	8-506
Paint/Coatings	8-637
Plastic Panel Information and Repair	8-642
Roof	8-646
Seats	8-835
Stationary Windows	8-923
Wipers/Washer Systems	8-953
Wiring Systems	8-978
Restraints	9-1
Seat Belts	9-3
SIR	9-17
Vehicle Control Systems	10-1
Vehicle DTC Information	10-3
Computer/Integrating Systems	10-20
Programming and Setup	10-79
Accessories	11-1
Cruise Control	11-3
Entertainment	11-19
Garage Door Opener	11-64
Keyless Entry	11-71
Personalization	11-82
Power Outlets	11-85
Theft Deterrent	11-94
Index	INDEX-1