

1-2 Shift	
Slipping or Harsh	
4L60-E/4L65-E	7-237
2-3 Shift	
No 2-3 Shift or 2-3 Shift Slips, Rough	
or Hunting	
4L60-E/4L65-E	7-238
2-4 Servo	7-264
4L60-E/4L65-E	7-264
3-2 Flare or Tie-Up	
4L60-E/4L65-E	7-238
3-4 Shift	
No 3-4 Shift, Slips or Rough 3-4 Shift	
4L60-E/4L65-E	7-239

A

Abbreviations and Their Meanings	0-13
ABS Automated Bleed Procedure	5-186
ABS Description and Operation	5-200
ABS Indicator	
Always On	5-184
Inoperative	5-184
Accelerator Pedal with Position (APP)	
Sensor	
Replacement	
Engine Controls - 6.0L	6-741
Accessory Power Receptacle	
Replacement - Cigar Lighter Housing	
or 12 Volt	
Power Outlets	11-90
Accumulator Assembly, Spacer Plate	
and Gaskets	
4L60-E/4L65-E	7-289
Actuator	
Cylinder Replacement	
Clutch Concentric	7-331
Replacement	
Park Brake	5-143
Adhesive Service Kit Description	
Stationary Windows	8-950
Adjustable Exhaust Hanger	
Replacement - Left	
Engine Exhaust	6-827
Aftermarket Accessories, Checking	
Wiring Systems	8-987
AIR BAG Indicator	
Circuit Malfunction	
SIR	9-78
Air Conditioning (A/C)	
Diagnostics - Pressure Zone A	1-8
Diagnostics - Pressure Zone B	1-10
Diagnostics - Pressure Zone C	1-12
Diagnostics - Pressure Zone D	1-13
Refrigerant Pressure Sensor Replacement	1-38
System Performance Test	1-5
Air Delivery	
Description and Operation	
HVAC Systems - Manual	1-102
Improper	
HVAC Systems - Manual	1-95
Air Distributor Duct	
Replacement	
HVAC	1-50

Air Hose Test	
Waterleaks	0-95
Air Inlet Grille Panel	
Replacement	8-28
Air Outlet	
Replacement - Instrument Panel	
HVAC	1-51
Air Pressure Test	0-90
Air Recirculation Malfunction	
HVAC Systems - Manual	1-97
Air Temperature	
Actuator Replacement	
HVAC Systems - Manual	1-100
Description and Operation	
HVAC Systems - Manual	1-103
Display Inaccurate or Inoperative, Outside	
Instrument Panel, Gages, and Console	8-429
Air/Wind Noise Diagnosis	0-90
All Seasons Tires Description	3-75
Aluminum Wheel	
Porosity Repair	3-70
Refinishing	3-70
Ambient Air Temperature	
Gage Sensor Replacement	8-433
Ambient Light Sensor	
Replacement	
Lighting Systems	8-599
Amplifier Replacement	
Entertainment	11-48
Antenna	
Cable Replacement	
Entertainment	11-52
Module Replacement	
Entertainment	11-51
Anti-Corrosion Treatment and Repair	
Paint/Coatings	8-639
Applique	
Replacement - Windshield Frame	
Exterior Trim	8-348
Arrows and Symbols	0-4
Ashtray	
Replacement	
Instrument Panel, Gages, and Console	8-446
Assist Rod	
Replacement - Hood	8-20
Assist Step	
Replacement	
Frame and Underbody	8-362
Audible Warnings Description and Operation	
Instrument Panel, Gages, and Console	8-489
Audio	
System Troubleshooting Hints	
Entertainment	11-41
Automatic Day-Night Feature	
Inoperative - Outside Mirrors	8-278
Automatic Day-Night Mirror	
Description and Operation	8-951
Inoperative	8-933
Automatic Transmission	
Oil Cooler Flushing and Flow Test	
4L60-E/4L65-E	7-226, 7-231
Shift Lock Control Description and	
Operation	7-56

- Automatic Transmission Electronic Component Views
 - 4L60-E/4L65-E 7-64
- Axle Housing Inspection
 - Rear Drive Axle 4-53
- Axle Housing Replacement
 - Rear Drive Axle 4-52
- Axle Preload and Backlash Specifications
 - Rear Drive Axle 4-14
- Axle Replacement - Rear
 - Rear Drive Axle 4-52

- B**
- Backfire
 - Engine Controls - 6.0L 6-701
- Backlash Adjustment
 - Rear Drive Axle 4-58
- Backup Lamp
 - Bulb Replacement
 - Lighting Systems 8-628
 - Replacement
 - Lighting Systems 8-627
 - Switch Replacement
 - Tremec 6 Speed 7-39
- Backup Lamps
 - Always On
 - Lighting Systems 8-567
 - Inoperative
 - Lighting Systems 8-568
- Ball Joint
 - Inspection
 - Suspension General Diagnosis 3-9
 - Replacement - Lower
 - Front Suspension 3-25
 - Replacement - Upper
 - Front Suspension 3-24
- Base Engine Misfire with
 - Abnormal Internal Lower Engine Noises
 - Engine Mechanical - 6.0L 6-28
 - Abnormal Valve Train Noise
 - Engine Mechanical - 6.0L 6-29
 - Coolant Consumption
 - Engine Mechanical - 6.0L 6-29
 - Excessive Oil Consumption
 - Engine Mechanical - 6.0L 6-29
- Base Engine Misfire without Internal Engine Noises
 - Engine Mechanical - 6.0L 6-27
- Basecoat/Clearcoat Paint Systems
 - Paint/Coatings 8-639
- Battery Charging - Engine Electrical 6-335
- Battery Common Causes of Failure -
 - Engine Electrical 6-338
- Battery Description and Operation 6-368
- Battery Electrical Drain/Parasitic Load Test 6-336
- Battery Inspection/Test - Engine Electrical 6-333
- Battery Negative Cable
 - Disconnect/Connect Procedure
 - Engine Electrical 6-348
 - Replacement - Engine Electrical 6-349
- Battery Positive Cable
 - Replacement - Engine Electrical 6-349, 6-351
- Battery Replacement - Engine Electrical 6-353
- Battery Tray
 - Replacement - Engine Electrical 6-356
- Battery Usage Specifications
 - Engine Electrical 6-318
- Bearings Inspection
 - Rear Drive Axle 4-53
- Bezel Replacement
 - Console Shift Lever 8-479
 - Seat Switch 8-905
- Bleeding the Power Steering System 2-16
- Blower Motor
 - Always On
 - HVAC Systems - Manual 1-90
 - Inoperative
 - HVAC Systems - Manual 1-90
 - Malfunction
 - HVAC Systems - Manual 1-92
 - Replacement
 - HVAC 1-50
 - Resistor Assembly Replacement
 - HVAC 1-49
- Body Control Module
 - Programming/RPO Configuration
 - Computer/Integrating Systems 10-76
 - Replacement
 - Computer/Integrating Systems 10-73
- Body Control System Description and Operation
 - Computer/Integrating Systems 10-77
- Body Leans or Sways in Corners
 - Suspension General Diagnosis 3-5
- Body Side Panel
 - Replacement - Outer
 - Collision Repair 8-176
 - Sectioning - Outer
 - Collision Repair 8-181, 8-187
- Bosch Connectors
 - Wiring Systems 8-1011, 8-1012, 8-1013
- Brake Assist System
 - Description and Operation
 - Hydraulic Brakes 5-59
 - Diagnosis
 - Hydraulic Brakes 5-24
- Brake Caliper
 - Bracket Replacement - Front
 - Disc Brakes 5-95
 - Bracket Replacement - Rear
 - Disc Brakes 5-99
 - Inspection
 - Disc Brakes 5-64
 - Overhaul - Front
 - Disc Brakes 5-81
 - Overhaul - Rear
 - Disc Brakes 5-83
 - Replacement - Front
 - Disc Brakes 5-77
 - Replacement - Rear
 - Disc Brakes 5-79
- Brake Component Specifications
 - Hydraulic Brakes 5-3
- Brake Fluid
 - Loss
 - Hydraulic Brakes 5-15

- Brake Hose
 - Replacement - Front
 - Hydraulic Brakes 5-46
 - Replacement - Rear
 - Hydraulic Brakes 5-49
 - Brake Pad
 - Inspection
 - Disc Brakes 5-63
 - Brake Pads
 - Replacement - Front
 - Disc Brakes 5-67
 - Replacement - Rear
 - Disc Brakes 5-72
 - Brake Pedal
 - Assembly Replacement
 - Hydraulic Brakes 5-40
 - Excessive Effort
 - Hydraulic Brakes 5-13
 - Excessive Travel
 - Hydraulic Brakes 5-13
 - Pulsation
 - Hydraulic Brakes 5-10
 - Pushrod Inspection
 - Hydraulic Brakes 5-29
 - Travel Measurement and Inspection
 - Hydraulic Brakes 5-26
 - Brake Pipe
 - Replacement
 - Hydraulic Brakes 5-42
 - Brake Pipe and Hose Inspection
 - Hydraulic Brakes 5-29
 - Brake Pressure Modulator Valve
 - Replacement
 - ABS 5-189
 - Brake Rotor
 - Refinishing
 - Disc Brakes 5-116
 - Replacement - Front
 - Disc Brakes 5-104
 - Replacement - Rear
 - Disc Brakes 5-108
 - Surface and Wear Inspection
 - Disc Brakes 5-62
 - Thickness Measurement
 - Disc Brakes 5-62
 - Brake Rotor/Drum Balance Inspection
 - Vibration Diagnosis and Correction 0-60
 - Brake System
 - External Leak Inspection
 - Hydraulic Brakes 5-27
 - Internal Leak Test
 - Hydraulic Brakes 5-27
 - Noise
 - Hydraulic Brakes 5-11
 - Slow Release
 - Hydraulic Brakes 5-15
 - Specifications
 - Hydraulic Brakes 5-3
 - Vacuum Source Test
 - Hydraulic Brakes 5-26
 - Vehicle Road Test
 - Hydraulic Brakes 5-25
 - Brake Warning Indicator
 - Always On
 - Hydraulic Brakes 5-8
 - Inoperative
 - Hydraulic Brakes 5-9
 - Brake Warning System
 - Description and Operation
 - Hydraulic Brakes 5-59
 - Brakes
 - Drag
 - Hydraulic Brakes 5-14
 - Braking
 - No Overrun Braking - Manual 3-2-1
 - 4L60-E/4L65-E 7-240
 - Braking Action Uneven
 - Front to Rear
 - Hydraulic Brakes 5-12
 - Pulls to One Side
 - Hydraulic Brakes 5-11
 - Bumper
 - Replacement - Front 8-104
 - Replacement - Front Seat Back Cushion
 - Interior Trim 8-505
 - Burnishing Pads and Rotors
 - Disc Brakes 5-76
- C**
- Cable Adjustment
 - Folding Top Latch - Rear 8-734
 - Cable Replacement
 - Folding Top Latch - Rear 8-732
 - Seat Back
 - Recliner - Front 8-897
 - Calibration Procedure
 - Memory Seat 8-910
 - Camber Description
 - Wheel Alignment 3-16
 - Camshaft
 - Replacement
 - Engine Mechanical - 6.0L 6-111
 - Capacities - Approximate Fluid
 - Maintenance and Lubrication 0-25
 - Cargo Box
 - Side Panel Replacement - Inner
 - Collision Repair 8-222
 - Cargo Box Cover Hinge Bracket
 - Replacement 8-42
 - Carpet
 - Replacement Front
 - Interior Trim 8-494
 - Replacement Rear
 - Interior Trim 8-495
 - Case Porosity Repair
 - 4L60-E/4L65-E 7-225
 - Caster and Camber Adjustment
 - Front
 - Wheel Alignment 3-14
 - Caster Description
 - Wheel Alignment 3-16
 - Catalytic Converter
 - Replacement
 - Engine Exhaust 6-822

- Caution, Notice and Important, Definition of P-3
- Change Engine Oil Indicator
 - Always On
 - Instrument Panel, Gages, and Console 8-426
- Charge Indicator
 - Always On - Engine Electrical 6-341
 - Inoperative - Engine Electrical 6-341
- Charging System Description and Operation 6-369
- Charging System Test - Engine Electrical 6-339
- Checking and Adding Fluid
 - Power Steering System 2-16
- Chime Always On
 - Instrument Panel, Gages and Console 8-430
- Chime Inoperative
 - Instrument Panel, Gages and Console 8-432
- Circuit Protection
 - Circuit Breakers
 - Wiring Systems 8-996
 - Fuses
 - Wiring Systems 8-995
 - Fusible Links
 - Wiring Systems 8-996
- Circuit Testing
 - Wiring Systems 8-987
- Cladding Replacement
 - Rocker Panel - Front
 - Exterior Trim 8-344
 - Rocker Panel - Rear
 - Exterior Trim 8-346
- Clearcoat
 - Repair without Repainting
 - Paint/Coatings 8-640
 - Thickness
 - Paint/Coatings 8-641
- Clearcoat Repair Specifications
 - 3M Products
 - Paint/Coatings 8-637
 - Meguiar Products
 - Paint/Coatings 8-638
- Clutch
 - Assembly Replacement 7-330
 - Drag Hard Shifting 7-319
 - Frequent Adjustments 7-324
 - Grabbing (Chattering) 7-322
 - Noisy 7-323
 - Pedal Hard to Push 7-324
 - Pedal Spongy Low Pedal Effort 7-323
 - Plate Diagnosis
 - 4L60-E/4L65-E 7-221
 - Rattle (Trans Click) 7-323
 - Slipping 7-321
 - System Description and Operation 7-333
 - Vibration 7-325
- Coding Keys and Lock Cylinders 0-20
- Coil Spring
 - Replacement
 - Rear Suspension 3-63
- Coin Holder Replacement
 - Instrument Panel Compartment 8-451
- Cold
 - Too Cold in Vehicle
 - HVAC Systems - Manual 1-94
- Compartment
 - Lid Replacement - Rear 8-67
 - Lid Trim Replacement - Rear 8-59
 - Sill Plate Replacement - Rear 8-58
- Compartment Replacement
 - Body Accessory - Rear
 - Roof 8-716
- Component List
 - Master Electrical 8-1070
- Component Location
 - 4L60-E/4L65-E 7-79
- Component Resistance
 - 4L60-E/4L65-E 7-61
- Component Rotational Speed Calculation
 - Vibration Diagnosis and Correction 0-30
- Component Specifications
 - Disc Brakes 5-61
- Component Views
 - ABS 5-153
 - Automatic Transmission Shift Lock Control 7-51
 - Body Rear End 8-35
 - Computer/Integrating Systems 10-25
 - Cruise Control 11-6
 - Engine Controls - 6.0L 6-391
 - Engine Cooling 6-274
 - Engine Electrical 6-322
 - Entertainment 11-25
 - Garage Door Opener 11-66
 - Horns 8-366
 - HVAC Systems - Manual 1-65
 - Hydraulic Brakes 5-5
 - Instrument Panel, Gages, and Console 8-386
 - Keyless Entry 11-73
 - Lighting Systems 8-520
 - Power and Grounding 8-1089
 - Power Door Systems 8-247
 - Power Outlets 11-87
 - Power Roof Systems 8-651
 - Power Seat Systems 8-842
 - Seat Belts 9-5
 - SIR 9-21
 - Stationary Windows 8-926
 - Steering Wheel and Column 2-45
 - Theft Deterrent 11-97
 - Wipers/Washer Systems 8-955
- Compressor
 - Hose Assembly Replacement
 - HVAC 1-31
 - Oil Balancing
 - HVAC 1-27
 - Relay Replacement
 - HVAC 1-35
 - Replacement
 - HVAC 1-28
- Condenser
 - Replacement
 - HVAC 1-40
- Connector Description
 - Automatic Transmission Inline 20-Way
 - 4L60-E/4L65-E 7-315

- Connector End Views
 - ABS 5-154
 - Automatic Transmission Inline 20-Way
 - 4L60-E/4L65-E 7-83
 - Automatic Transmission Internal
 - 4L60-E/4L65-E 7-84
 - Automatic Transmission Related
 - 4L60-E/4L65-E 7-87
 - Automatic Transmission Shift Lock Control 7-52
 - Body Rear End 8-37
 - Computer/Integrating Systems 10-29
 - Engine Control Module (ECM)
 - Engine Controls - 6.0L 6-399
 - Engine Controls - 6.0L 6-401
 - Engine Cooling 6-275
 - Engine Electrical 6-324
 - Entertainment 11-29
 - Garage Door Opener 11-67
 - Horns 8-368
 - HVAC Systems - Manual 1-69
 - Hydraulic Brakes 5-7
 - Inline Harness 8-1117
 - Instrument Panel, Gages, and Console 8-390
 - Keyless Entry 11-74
 - Lighting Systems 8-527
 - Power and Grounding 8-1116
 - Power Door Systems 8-252
 - Power Outlets 11-88
 - Power Roof Systems 8-655
 - Power Seat Systems 8-848
 - Seat Belts 9-6
 - SIR 9-32
 - Splice Pack 8-1146
 - Stationary Windows 8-928
 - Steering Wheel and Column 2-47
 - Theft Deterrent 11-98
 - Tremec 6 Speed 7-7
 - Wipers/Washer Systems 8-957
- Connector Position Assurance Locks
 - Wiring Systems 8-1011
- Connector Repairs
 - Wiring Systems 8-1008
- Connector Terminals, Repairing
 - Wiring Systems 8-1026
- Connector Test Adapters, Using
 - Wiring Systems 8-987
- Console
 - Armrest Replacement
 - Front Floor 8-482
 - Compartment Door
 - Hinge Replacement 8-472
 - Latch Replacement 8-474
 - Lock Cylinder Replacement 8-472
 - Replacement 8-480
 - Shift Lever Bezel Replacement 8-479
 - Trim Plate Replacement - Upper 8-476
- Content Theft Deterrent (CTD)
 - Alarm Mode Inoperative 11-119
 - Description and Operation 11-125
 - Does Not Disarm with Key Lock 11-120
- Continuity, Testing for
 - Wiring Systems 8-990
- Control and Shift Solenoids
 - Replacement
 - 4L60-E/4L65-E 7-281
- Control Arm
 - Bracket Replacement - Lower
 - Front Suspension 3-37
 - Replacement - Lower
 - Front Suspension 3-32
 - Replacement - Rear Axle Lower
 - Rear Suspension 3-54
 - Replacement - Rear Axle Upper
 - Rear Suspension 3-53
 - Replacement - Upper
 - Front Suspension 3-30
- Control Lever
 - Handle Assembly Replacement
 - Tremec 6 Speed 7-38
- Control Module References
 - Computer/Integrating Systems 10-71
- Control Module Replacement
 - Folding Top 8-794
 - Memory Seat 8-909
- Conversion Table, English/Metric 0-3
- Coolant Air Bleed Hose
 - Replacement 6-305
- Coolant Air Bleed Pipe
 - Assembly Replacement 6-304
- Coolant Heater
 - Cord Replacement 6-314
 - Inoperative 6-286
 - Replacement 6-313
- Cooling Fan
 - Always On 6-280
 - Inoperative 6-281
 - Relay Replacement 6-301, 6-302
 - Replacement - Electric 6-301
- Cooling System
 - Description and Operation 6-315
 - Leak Testing 6-288
- Courtesy Lamp
 - Always On
 - Lighting Systems 8-569
 - Inoperative
 - Lighting Systems 8-570
- Cover and Pad Replacement
 - Seat Back
 - Front 8-889
 - Seat Cushion
 - Front 8-885
- Crankcase Ventilation
 - Hoses/Pipes Replacement
 - Engine Mechanical - 6.0L 6-61
 - System
 - Engine Mechanical - 6.0L 6-39
- Crankshaft Balancer
 - Replacement
 - Engine Mechanical - 6.0L 6-88
- Crankshaft Front Oil Seal
 - Replacement
 - Engine Mechanical - 6.0L 6-91
- Crankshaft Rear Oil Seal
 - Replacement
 - Engine Mechanical - 6.0L 6-93

- Cross Bar No. 5
Replacement - Floor Panel
Collision Repair 8-211
- Crossmember Brace Replacement - Front
Frame and Underbody 8-356
- Crossmember Replacement
Front Steering Gear
Frame and Underbody 8-356
- Radiator
Frame and Underbody 8-355
- Rear Steering Gear
Frame and Underbody 8-358
- Cruise Control
Description and Operation 11-17
Inoperative/Malfunctioning 11-14
- Cup Holder Replacement
Instrument Panel, Gages, and Console 8-447
- Cuts Out, Misses
Engine Controls - 6.0L 6-692
- Cylinder Head
Replacement - Left
Engine Mechanical - 6.0L 6-78
Replacement - Right
Engine Mechanical - 6.0L 6-82
- D**
- Data Link Communications Description and
Operation
Computer/Integrating Systems 10-76
- Data Link References
Computer/Integrating Systems 10-72
- Daytime Running Lamps (DRL)
Always On
Lighting Systems 8-571
- Diode Replacement
Lighting Systems 8-600
- Inoperative
Lighting Systems 8-572
- Decimal and Metric Equivalents 0-3
- Definition of Caution, Notice and Important P-3
- Definitions and Abbreviations
4L60-E/4L65-E 7-305
- Defogger
Description and Operation - Rear Window ... 8-951
- Grid Lines Diagnosis
Stationary Windows 8-932
- Inoperative - Rear
Stationary Windows 8-929
- Defroster
Door Replacement
HVAC 1-53
- Duct Replacement - Windshield
HVAC 1-52
- Defrosting
Insufficient
HVAC 1-17
- Detonation/Spark Knock
Engine Controls - 6.0L 6-689
- Diagnostic Starting Point
4L60-E/4L65-E 7-89
- ABS 5-155
- Automatic Transmission Shift Lock Control 7-52
- Body Rear End 8-38
- Clutch 7-319
- Computer/Integrating Systems 10-33
- Cruise Control 11-7
- Disc Brakes 5-61
- Doors 8-259
- Engine Controls - 6.0L 6-411
- Engine Cooling 6-276
- Engine Electrical 6-324
- Engine Exhaust 6-811
- Engine Mechanical - 6.0L 6-25
- Entertainment 11-36
- Garage Door Opener 11-67
- Horns 8-368
- HVAC 1-4
- Hydraulic Brakes 5-7
- Instrument Panel, Gages, and Console 8-392
- Keyless Entry 11-74
- Lighting Systems 8-537
- Park Brake 5-118
- Power Steering System 2-6
- Propeller Shaft 4-4
- Rear Drive Axle 4-16
- Roof 8-665
- Seat Belts 9-7
- Seats 8-857
- SIR 9-40
- Stationary Windows 8-928
- Steering Wheel Controls
Steering Wheel and Column 2-47
- Suspension General Diagnosis 3-3
- Theft Deterrent 11-98
- Tremec 6 Speed 7-8
- Vehicle DTC Information 10-3
- Vibration Diagnosis and Correction 0-26
- Wiper/Washer Systems 8-958
- Diagnostic System Check
Vehicle DTC Information 10-3
- Diagnostic Trouble Code (DTC) Clearing
HVAC Systems - Manual 1-73
- Diagnostic Trouble Code (DTC) Displaying
HVAC Systems - Manual 1-73
- Diagnostic Trouble Code (DTC) List
4L60-E/4L65-E 7-98
Vehicle DTC Information 10-5
- Diagnostic Trouble Code (DTC) List/Type
Tremec 6 Speed 7-10
- Diagnostic Trouble Code (DTC) Type
Definitions
4L60-E/4L65-E 7-97
Tremec 6 Speed 7-10
- Diagnostic Trouble Code (DTC) Types
Engine Controls - 6.0L 6-373
- Diagnostic Work Sheets 0-5
- Dieseling, Run-On
Engine Controls - 6.0L 6-701

- Differential
 - Adjustment Shim Specifications
 - Rear Drive Axle 4-14
 - Inspection
 - Rear Drive Axle 4-53
 - Replacement
 - Rear Drive Axle 4-46
 - Side Bearing Preload Adjustment
 - Rear Drive Axle 4-56
 - Side Bearings Replacement
 - Rear Drive Axle 4-50
- Digital Multimeter, Troubleshooting with
 - Wiring Systems 8-989
- Dimensions
 - Body - Collision Repair 8-110, 8-111, 8-112, 8-113, 8-114, 8-115
- Disassembled View
 - Power Steering Gear 2-4
- Disassembled Views
 - 4L60-E/4L65-E 7-68
 - Driveline - Propeller Shaft 4-3
 - Folding Top 8-663
 - Power Steering Pump 2-5
 - Rear Drive Axle 4-15
 - Steering Wheel and Column 2-44
- Disc Brake
 - Backing Plate Replacement
 - Rear 5-112
 - Hardware Replacement
 - Front 5-86
 - Rear 5-90
 - Splash Shield Replacement
 - Front 5-111
 - System Diagnosis
 - Hydraulic Brakes 5-15
- Door
 - Replacement 8-295
 - Sill Plate Replacement
 - Interior Trim 8-493
- Door Adjustment 8-294
- Door Ajar Indicator
 - Description and Operation 8-336
 - Malfunction 8-272
- Door Check Link
 - Replacement 8-300
- Door Handle
 - Bezel Replacement 8-286
 - Replacement - Inside 8-303
 - Replacement - Outside 8-302
- Drain Cock
 - Replacement - Engine Cooling 6-309
- Drain Cups Replacement
 - Folding Top Stowage Compartment Lid
 - Lock Pillar 8-792
- Draining and Filling Cooling System 6-289, 6-290
- Drive
 - Delay in Drive and Reverse
 - 4L60-E/4L65-E 7-245
 - Drives in Neutral
 - 4L60-E/4L65-E 7-243
 - No Drive in All Ranges
 - 4L60-E/4L65-E 7-244
 - No Drive in Drive Range
 - 4L60-E/4L65-E 7-244
- Drive Belt
 - Chirping Diagnosis
 - Engine Mechanical - 6.0L 6-39
 - Excessive Wear Diagnosis
 - Engine Mechanical - 6.0L 6-47
 - Falls Off Diagnosis
 - Engine Mechanical - 6.0L 6-45
 - Idler Pulley Replacement
 - Engine Mechanical - 6.0L 6-49
 - Replacement - Accessory
 - Engine Mechanical - 6.0L 6-48
 - Replacement - Air Conditioning
 - Engine Mechanical - 6.0L 6-49
 - Rumbling Diagnosis
 - Engine Mechanical - 6.0L 6-43
 - Squeal Diagnosis
 - Engine Mechanical - 6.0L 6-41
 - System Description
 - Engine Mechanical - 6.0L 6-259
 - Tensioner
 - Engine Mechanical - 6.0L 6-47
 - Tensioner Replacement - Accessory
 - Engine Mechanical - 6.0L 6-50
 - Tensioner Replacement - Air Conditioning
 - Engine Mechanical - 6.0L 6-51
 - Vibration Diagnosis
 - Engine Mechanical - 6.0L 6-44
 - Whine Diagnosis
 - Engine Mechanical - 6.0L 6-42
- Drive Pinion
 - And Ring Gear Replacement
 - Rear Drive Axle 4-37
 - Bearings Replacement
 - Rear Drive Axle 4-42
 - Flange/Yoke and/or Oil Seal Replacement
 - Rear Drive Axle 4-33
- Driveline
 - System Balance Adjustment
 - Vibration Diagnosis and Correction 0-75
 - Working Angles Adjustment
 - Vibration Diagnosis and Correction 0-77
 - Working Angles Measurement
 - Vibration Diagnosis and Correction 0-67
- Driver Information Center
 - Description and Operation 8-487
 - Switches Inoperative
 - Instrument Panel, Gages, and Console 8-427
- Driver Personalization 11-82
- DTC 001 1-75
- DTC 100 1-75
- DTC 1025 11-38
- DTC 1035 11-38
- DTC 1045 11-38
- DTC 1055 11-38
- DTC 2763 7-196
- DTC B0012 9-42
- DTC B0013 9-42
- DTC B0014 9-42
- DTC B0016 9-42
- DTC B0017 9-42
- DTC B0018 9-42
- DTC B0022 9-45
- DTC B0024 9-45
- DTC B0026 9-45

DTC B0028	9-48	DTC B1835	8-859
DTC B0029	9-48	DTC B2425	8-863
DTC B0030	9-48	DTC B2430	8-863
DTC B0040	9-51	DTC B2435	8-865
DTC B0041	9-51	DTC B2440	8-865
DTC B0042	9-45	DTC B2527	8-543
DTC B0043	9-45	DTC B2530	8-545
DTC B0044	9-45	DTC B2550	8-547
DTC B0045	9-51	DTC B2575	8-548
DTC B0051	9-54	DTC B2580	8-550
DTC B0053	9-55	DTC B2585	8-552
DTC B0057	9-56	DTC B2600	8-554
DTC B0058	9-56	DTC B2610	8-556
DTC B0059	9-56	DTC B2615	8-558
DTC B0064	9-59	DTC B2620	8-560
DTC B0065	9-59	DTC B2645	8-563
DTC B0066	9-59	DTC B2752	8-370
DTC B0077	9-62	DTC B2815	11-39
DTC B0078	9-62	DTC B2947	11-101
DTC B0079	9-62	DTC B2948	11-103
DTC B0080	9-62	DTC B2957	11-105
DTC B0081	9-62	DTC B2958	11-107
DTC B0082	9-62	DTC B2960	11-110
DTC B0083 or B0084	9-65	DTC B2961	8-404
DTC B0090	9-68	DTC B3031	11-112
DTC B0091	9-71	DTC B3033	11-114
DTC B0100	9-73	DTC B3602	8-686
DTC B0101	9-73	DTC B3665	8-688
DTC B0102	9-73	DTC B3666	8-691
DTC B0103	9-73	DTC B3667	8-694
DTC B0104	9-73	DTC B3674	8-696
DTC B0105	9-73	DTC B3675	8-698
DTC B0540	8-399	DTC B3676	8-700
DTC B0560	8-401	DTC B3677	8-702
DTC B1000	10-34	DTC B3681	8-704
DTC B1001	9-76	DTC B3682	8-706
DTC B1004	10-35	DTC B3683	8-708
DTC B1007	10-36	DTC B3685	8-710
DTC B1009	10-37	DTC B3802	8-565
DTC B1017	8-262	DTC B3808	8-266
DTC B1296	8-670	DTC B3809	8-268
DTC B1300	8-672	DTC C0221-C0227	5-159
DTC B1306	8-674	DTC C0229	5-161
DTC B1310	8-676	DTC C0235-C0237	5-162
DTC B1311	8-678	DTC C0238	5-164
DTC B1323	8-680	DTC C0241-C0254	5-165
DTC B1372	8-403	DTC C0265	5-166
DTC B1420	10-38	DTC C0266	5-166
DTC B1440	10-40	DTC C0267	5-168
DTC B1480	8-541	DTC C0268	5-168
DTC B1517	8-683	DTC C0269	5-171
DTC B1518	8-685	DTC C0271-C0273	5-172
DTC B1533 or B3992	8-264	DTC C0274	5-171
DTC B1735	8-859	DTC C0279	5-173
DTC B1740	8-859	DTC C0281	5-174
DTC B1745	8-859	DTC C0283	5-176
DTC B1750	8-859	DTC C0284	5-172
DTC B1755	8-859	DTC C0287	5-178
DTC B1760	8-859	DTC C0290	5-180
DTC B1815	8-859	DTC C0292	5-180
DTC B1820	8-859	DTC C0297	5-180
DTC B1825, B1850, B1860, B2355, B2365, or B2375	8-861	DTC C0298	5-181
DTC B1830	8-859	DTC C0550	10-43
		DTC C0609	5-162

- Engine Compression Test
 Engine Mechanical - 6.0L 6-34
 Engine Control Module (ECM)
 Description
 Engine Controls - 6.0L 6-799
 Replacement
 Engine Controls - 6.0L 6-729
 Engine Coolant
 Temperature Gage Inaccurate or Inoperative
 Instrument Panel, Gages, and Console 8-420
 Water in Transmission
 4L60-E/4L65-E 7-222
 Engine Cranks but Does Not Run
 Engine Controls - 6.0L 6-706
 Engine Cranks Slowly - Engine Electrical 6-346
 Engine Fails To Reach Normal Operating
 Temperature - Engine Cooling 6-287
 Engine Flywheel
 Replacement
 Engine Mechanical - 6.0L 6-114
 Engine Front Cover
 Replacement
 Engine Mechanical - 6.0L 6-92
 Engine Mechanical Specifications
 Engine Mechanical - 6.0L 6-9
 Engine Mount
 Inspection
 Engine Mechanical - 6.0L 6-51
 Replacement - Left
 Engine Mechanical - 6.0L 6-52
 Replacement - Right
 Engine Mechanical - 6.0L 6-56
 Engine Noise
 Lower Engine Noise, Regardless of Engine Speed
 Engine Mechanical - 6.0L 6-30
 On Start-Up, but Only Lasting a Few Seconds
 Engine Mechanical - 6.0L 6-29
 Under Load
 Engine Mechanical - 6.0L 6-31
 Upper Engine Noise, Regardless of Engine Speed
 Engine Mechanical - 6.0L 6-30
 Engine Oil
 Pressure Gage Inaccurate or Inoperative
 Instrument Panel, Gages, and Console 8-421
 Pressure Sensor and/or Switch
 Replacement
 Engine Mechanical - 6.0L 6-103
 Engine Oil and Oil Filter
 Replacement
 Engine Mechanical - 6.0L 6-125
 Engine Order Classification
 Vibration Diagnosis and Correction 0-40
 Engine Overheating - Engine Cooling 6-282
 Engine Rear Cover
 Replacement
 Engine Mechanical - 6.0L 6-94
 Engine Replacement
 Engine Mechanical - 6.0L 6-115
 Engine Sight Shield Replacement
 Engine Mechanical - 6.0L 6-60
 Engine Valley Cover
 Replacement
 Engine Mechanical - 6.0L 6-66
 Engine Will Not Crank - Crankshaft
 Will Not Rotate
 Engine Mechanical - 6.0L 6-32
 English/Metric Conversion Table 0-3
 Environmental Fallout (Acid Rain)
 Paint/Coatings 8-640
 Evaporator
 Core Replacement
 HVAC 1-44
 Temperature Sensor Replacement
 HVAC 1-39
 Exhaust Leakage
 Engine Exhaust 6-814
 Exhaust Manifold
 Heat Shield Replacement - Left
 Engine Exhaust 6-835
 Heat Shield Replacement - Right
 Engine Exhaust 6-834
 Replacement - Left
 Engine Exhaust 6-815
 Replacement - Right
 Engine Exhaust 6-817
 Exhaust Noise
 Engine Exhaust 6-814
 Exhaust Seal Replacement
 Engine Exhaust 6-820
 Exhaust System
 Description 6-836
 Exterior Lighting Systems Description and
 Operation 8-633
- ## F
- Fascia
 Grille Replacement
 Bumpers 8-102
 Replacement - Front Bumper 8-100
 Replacement - Rear Bumper 8-105
 Fastener Tightening Specifications
 4L60-E/4L65-E 7-57
 ABS 5-150
 Body Front End 8-11
 Body Rear End 8-33
 Bumpers 8-99
 Clutch 7-318
 Disc Brakes 5-61
 Doors 8-241
 Engine Controls - 6.0L 6-372
 Engine Cooling 6-272
 Engine Electrical 6-318
 Engine Exhaust 6-811
 Engine Mechanical - 6.0L 6-7
 Entertainment 11-19
 Exterior Trim 8-338
 Frame and Underbody 8-352
 Front Suspension 3-19
 Horns 8-364
 HVAC 1-3
 HVAC Systems - Manual 1-61
 Hydraulic Brakes 5-3
 Instrument Panel, Gages, and Console 8-378

- Fastener Tightening Specifications (cont.)
- Interior Trim 8-491
 - Lighting Systems 8-506
 - Park Brake 5-118
 - Power Steering System 2-3
 - Propeller Shaft 4-3
 - Rear Drive Axle 4-14
 - Rear Suspension 3-52
 - Roof 8-646
 - Seat Belts 9-3
 - Seats 8-835
 - SIR 9-17
 - Stationary Windows 8-923
 - Steering Wheel and Column 2-41
 - Tires and Wheels 3-67
 - Tremec 6-Speed 7-5
 - Wheel Alignment 3-13
 - Wipers/Washer System 8-953
 - Wiring Systems 8-978
- Fasteners 0-9
- Fender
- Rail Replacement - Upper
 - Collision Repair 8-214
 - Rail Sectioning - Upper
 - Collision Repair 8-216
 - Replacement - Front 8-22
- Fender Reinforcement
- Replacement - Lower 8-24
- Filler Tube and Seal
- Replacement
 - 4L60-E/4L65-E 7-268
- First Gear
- First/Fourth Gear Only
 - 4L60-E/4L65-E 7-238
 - No First or Second Gear/No Third or Fourth Gear
 - 4L60-E/4L65-E 7-238
 - Slips
 - 4L60-E/4L65-E 7-236
- First Gear Range Only-No Upshift
- 4L60-E/4L65-E 7-236
- Flat Wire Repairs
- Wiring Systems 8-996
- Flexplate/Torque Converter Vibration Test
- 4L60-E/4L65-E 7-220
- Floor Carpet Drying
- Interior Trim 8-494
- Floor Replacement
- Rear
 - Collision Repair 8-224, 8-231
- Floor Shift Control
- Knob Replacement
 - 4L60-E/4L65-E 7-247
 - Replacement
 - 4L60-E/4L65-E 7-252
- Fluid and Lubricant Recommendations 0-25
- Fluid Capacity Specifications
- 4L60-E/4L65-E 7-59
- Fluid Leak Diagnosis
- 4L60-E/4L65-E 7-222
- Flushing
- HVAC 1-24
 - The Power Steering System 2-16
- Flushing - Engine Cooling 6-296
- Fog Lamp
- Aiming Procedure
 - Lighting Systems 8-615
 - Always On - Front
 - Lighting Systems 8-574
 - Bulb Replacement - Front
 - Lighting Systems 8-614
 - Indicator Inoperative
 - Lighting Systems 8-573
 - Inoperative
 - Lighting Systems 8-574
 - Replacement - Front
 - Lighting Systems 8-612
- Folding Top
- Clearance Gap Specifications
 - Roof 8-646
 - Manual Operation 8-828
 - Rear Window Replacement - Roof 8-776
 - Replacement - Roof 8-772
 - Stowage Compartment Lid Release
 - Mechanism - Roof 8-789
- Fourth Gear
- First/Fourth Gear Only
 - 4L60-E/4L65-E 7-238
 - No First or Second Gear/No Third or Fourth Gear
 - 4L60-E/4L65-E 7-238
 - No Fourth Gear or Slips in Fourth Gear
 - 4L60-E/4L65-E 7-242
 - No Second, Fourth and Reverse Gear
 - 4L60-E/4L65-E 7-218
 - No Second, Fourth and Reverse Gear
 - 4L60-E/4L65-E 7-238
- Frame
- Brace Replacement
 - Frame and Underbody 8-358
 - Cushion or Insulator Replacement
 - Frame and Underbody 8-359
 - Sectioning - Front Full Frame
 - Collision Repair 8-131
- Frame Replacement
- Seat Back
 - Front 8-892
 - Seat Cushion - Front 8-879
- Frequency, Measuring
- Wiring Systems 8-990
- Front End Assembly
- Replacement - Kit
 - Collision Repair 8-137
- Front Suspension General Description 3-50
- Fuel Filler
- Door Replacement 8-62
- Fuel Filter Replacement
- Engine Controls - 6.0L 6-755
- Fuel Gage
- Inaccurate or Inoperative 8-422
- Fuel Hose/Pipes
- Replacement - Chassis
 - Engine Controls - 6.0L 6-762

- Fuel Injector
 Balance Test with Special Tool
 Engine Controls - 6.0L 6-716
 Balance Test with Tech 2
 Engine Controls - 6.0L 6-718
 Coil Test
 Engine Controls - 6.0L 6-714
 Replacement
 Engine Controls - 6.0L 6-773
 Fuel Level Sensor Replacement
 Engine Controls - 6.0L 6-756
 Fuel Level Specifications
 Instrument Panel, Gages, and Console 8-378
 Fuel Pressure
 Relief Procedure
 Engine Controls - 6.0L 6-744
 Fuel Pump
 Electrical Circuit Diagnosis
 Engine Controls - 6.0L 6-709
 Fuel Rail
 Assembly Replacement
 Engine Controls - 6.0L 6-767
 Fuel System
 Description
 Engine Controls - 6.0L 6-801
 Diagnosis
 Engine Controls - 6.0L 6-712
 Fuel Tank
 Pressure Sensor Replacement
 Engine Controls - 6.0L 6-756
 Replacement
 Engine Controls - 6.0L 6-750
 Full-Cut Method Description
 Stationary Window 8-950
 Fused Jumper Wires, Using
 Wiring Systems 8-989
- G**
- Gages Inoperative - All 8-424
 Garage Door Opener
 Inoperative 11-68
 Programming - Universal 11-69
 Garage Door Opener Description and
 Operation 11-70
 Garnish Molding Replacement
 Rear Upper - Interior Trim 8-504
 Windshield Pillar
 Interior Trim 8-503
 Windshield Upper
 Interior Trim 8-503
 Gear
 Engine Starts in Gear
 4L60-E/4L65-E 7-245
 No Gear Selection
 4L60-E/4L65-E 7-245
 Slip/Flare in Any Gear
 4L60-E/4L65-E 7-242
 Tooth Contact Pattern Inspection
 Rear Drive Axle 4-60
 Transmission Does Not Shift into
 One Gear
 Tremec 6 Speed 7-30
- Gear (cont.)
 Transmission Gear Clash When
 Shifting Gears
 Tremec 6 Speed 7-25
 Transmission Jumps Out of
 Tremec 6 Speed 7-28
 Transmission Locked in One Gear
 Tremec 6 Speed 7-31
 General Description
 Tires and Wheels 3-74
 General Specifications
 4L60-E/4L65-E 7-58
 Generator
 Bracket Replacement - Engine Electrical 6-364
 Noise Diagnosis - Engine Electrical 6-342
 Replacement - Engine Electrical 6-365
 Usage Specifications - Engine Electrical 6-318
 GM Oil Life System - Resetting
 Maintenance and Lubrication 0-25
 GMLAN Wiring Repairs
 Wiring Systems 8-996
 Grille
 Applique Molding Replacement - Upper
 Exterior Trim 8-341, 8-342
 Ground Strap
 Replacement - Engine Electrical 6-360
 Guide Replacement
 Seat Belt - Front 8-920
- H**
- Handle Replacement
 Endgate 8-85
 Seat Back Recliner - Front 8-896
 Hard Start
 Engine Controls - 6.0L 6-683
 Harness Routing Views
 Wiring Systems 8-1051
 Harsh Garage Shift
 4L60-E/4L65-E 7-240
 Harsh Shifts
 4L60-E/4L65-E 7-235
 Hazard and Turn Signal Flasher
 Replacement
 Lighting Systems 8-601
 Hazard Lamps
 Always On
 Lighting Systems 8-576
 Inoperative
 Lighting Systems 8-576
 Headlamp
 Aiming
 Lighting Systems 8-610
 Always On - Low or High Beam
 Lighting Systems 8-577
 Bulb Replacement
 Lighting Systems 8-607
 Replacement
 Lighting Systems 8-606
 Switch Replacement
 Lighting Systems 8-598

- Headlamps
 - Inoperative - Flash to Pass
 - Lighting Systems 8-582
 - Inoperative - High Beam
 - Lighting Systems 8-579
 - Inoperative - Low Beams
 - Lighting Systems 8-580
- Heat Shield
 - Replacement
 - 4L60-E/4L65-E 7-270
- Heated Mirrors
 - Inoperative
 - Doors 8-280
- Heated Oxygen Sensor (HO2S)
 - Wiring Repairs 8-1001
- Heated Seat
 - Inoperative 8-876
- Heated Seats
 - Description and Operation 8-921
- Heater
 - Core Replacement
 - HVAC 1-58
 - Hose Replacement - Inlet
 - HVAC 1-46
 - Hose Replacement - Outlet
 - HVAC 1-48
- Heater Element Replacement
 - Seat Back - Front 8-911
 - Seat Cushion Front 8-914
- Heating
 - Performance Diagnostic 1-15
- Hesitation or Lack of Power
 - 4L60-E/4L65-E 7-245
- Hesitation, Sag, Stumble
 - Engine Controls - 6.0L 6-690
- High Beam Indicator
 - Always On
 - Lighting Systems 8-582
 - Inoperative
 - Lighting Systems 8-583
- High Mounted Stop Lamp
 - Replacement
 - Lighting Systems 8-625
- High Shift Effort
 - Steering Wheel and Column 2-56
- High Temperature Wiring Repairs
 - Wiring Systems 8-999
- Hinge Pillar
 - Body Replacement - Front Inner
 - Collision Repair 8-156
- Hinge Replacement
 - Door 8-298
 - Endgate 8-68
 - Extension Panel - Folding Top Stowage
 - Compartment Lid 8-786
 - Rear Compartment Lid 8-72
 - Stowage Compartment Lid - Folding
 - Top - Roof 8-787
- Hinge Shield Replacement
 - Endgate 8-69
- Hood Adjustment 8-12
- Hood Bumper
 - Replacement 8-12
- Hood Hinge
 - Replacement 8-15
- Hood Insulator
 - Replacement 8-19
- Hood Latch
 - Adjustment 8-16
 - Release Cable Replacement 8-17
 - Replacement 8-17
- Hood Replacement 8-13
- Horn
 - Always On 8-371
 - Inoperative 8-372
 - Inoperative in Content Theft
 - Deterrent (CTD) Alarm Mode 11-122
 - Poor Tone 8-375
 - Replacement 8-376
 - Switch Replacement
 - Steering Wheel and Column 2-77
 - System Description and Operation 8-377
- Hose Replacement
 - Folding Top Hydraulic Cylinder - All
 - Roof 8-806
- Hot
 - Too Hot in Vehicle
 - HVAC Systems - Manual 1-93
- Hub/Axle Flange and Wheel Stud
 - Runout Inspection
 - Vibration Diagnosis and Correction 0-60
- HVAC Compressor
 - Clutch Does Not Disengage
 - HVAC Systems - Manual 1-88
 - Clutch Does Not Engage
 - HVAC Systems - Manual 1-84
- HVAC Control
 - Module Replacement
 - HVAC Systems - Manual 1-99
- HVAC Module
 - Assembly Replacement 1-43
- Hydraulic Brake
 - Component Operation Visual Inspection 5-28
 - System Bleeding 5-52, 5-53
 - System Description and Operation 5-59
 - System Diagnosis 5-20
 - System Flushing 5-54
- Hydraulic Clutch
 - Bleeding 7-327
 - Hose/Pipe Replacement 7-327
- Hydraulic Cylinder Replacement
 - Folding Top - Roof 8-766
 - Folding Top Stowage Compartment Latch 8-754
 - Folding Top Stowage Compartment Lid 8-751
- Hydraulic System Bleeding Procedure
 - Folding Top - Roof 8-765

- I**
- Ignition
 - Can/Cannot Be Turned Off with Transmission in Any Gear
 - Steering Wheel and Column 2-51
 - Lock Cylinder Case Replacement
 - Steering Wheel and Column 2-72
 - Lock Cylinder Replacement
 - Steering Wheel and Column 2-70
 - Switch Replacement
 - Steering Wheel and Column 2-67
 - Ignition Key
 - Cannot be Removed from the Ignition Lock Cylinder
 - Steering Wheel and Column 2-54
 - Cannot Turn or Sticks in Any Position
 - Steering Wheel and Column 2-54
 - Important, Caution and Notice, Definition of P-3
 - Inaccurate Shift Points
 - 4L60-E/4L65-E 7-236
 - Indicator/Warning Message Description and Operation
 - Instrument Panel, Gages, and Console 8-484
 - Inflatable Restraint
 - Front End Sensor Replacement 9-92
 - Instrument Panel (I/P) Module Disable Switch LED Replacement
 - SIR 9-110
 - Instrument Panel (I/P) Module Disable Switch Replacement
 - SIR 9-108
 - Instrument Panel Module Replacement
 - SIR 9-103
 - Seat Position Sensor Replacement 9-106
 - Sensing and Diagnostic Module Replacement
 - SIR 9-95
 - Side Impact Module Replacement - Front
 - SIR 9-107
 - Side Impact Sensor Replacement
 - SIR 9-94
 - Steering Wheel Module Coil Centering
 - Steering Wheel and Column 2-97
 - Steering Wheel Module Coil Replacement
 - SIR 9-98
 - Steering Wheel Module Replacement
 - SIR 9-97
 - Inflator
 - Module Handling and Scrapping
 - SIR 9-115
 - Inspection/Maintenance (I/M)
 - System Check
 - Engine Controls - 6.0L 6-726
 - System DTC Table
 - Engine Controls - 6.0L 6-728
 - Instrument Panel
 - Compartment Lamp Always On
 - Lighting Systems 8-586
 - Compartment Lamp Inoperative
 - Lighting Systems 8-585
 - Instrument Panel Cluster
 - Description and Operation 8-483
 - Replacement 8-444
 - Instrument Panel (I/P)
 - Air Outlet Ducts Replacement
 - HVAC 1-52
 - Carrier Replacement 8-457
 - Carrier Support Replacement 8-459
 - Compartment Lamp Bulb Replacement
 - Lighting Systems 8-603
 - Compartment Lamp Replacement
 - Lighting Systems 8-603
 - Intake Manifold
 - Replacement
 - Engine Mechanical - 6.0L 6-62
 - Interior Backlighting
 - Does Not Dim
 - Lighting Systems 8-584
 - Inoperative
 - Lighting Systems 8-585
 - Interior Lighting System Description and Operation 8-635
 - Intermediate Steering Shaft
 - Replacement - Lower
 - Steering Wheel and Column 2-60
 - Replacement - Upper
 - Steering Wheel and Column 2-58
 - Intermittent Fault Conditions, Inducing Wiring Repairs 8-993
- J**
- Jump Starting in Case of Emergency - Engine Electrical 6-338
- K**
- Key Coding and Lock Cylinders 0-20
 - Keyless Entry System
 - Description and Operation 11-80
 - Inoperative 11-77
 - Keys
 - Adding
 - Theft Deterrent 11-124
 - Replacing
 - Theft Deterrent 11-124
 - Knee Bolster
 - Bracket Replacement - Left
 - Instrument Panel Gages, and Console 8-438
 - Replacement - Left
 - Instrument Panel, Gages, and Console 8-436
 - Replacement - Right
 - Instrument Panel, Gages, and Console 8-434
 - Knob Replacement
 - EZ Entry Seat Manual Release 8-895
- L**
- Lack of Power or Hesitation
 - 4L60-E/4L65-E 7-245
 - Lack of Power, Sluggishness, or Sponginess
 - Engine Controls - 6.0L 6-687

- Latch Adjustment
 Folding Top - Center
 Roof 8-723
 Folding Top - Rear
 Roof 8-728
 Folding Top - Rear Upper
 Roof 8-736
 Latch Release Cable
 Adjustment RT/LT - Rear
 Compartment Lid 8-78
 Replacement RT/LT - Rear
 Compartment Lid 8-75
 Latch Release Handle
 Replacement - Rear Compartment Lid 8-84
 Latch Replacement
 Door 8-309
 Endgate 8-88
 Folding Top - Center 8-725
 Folding Top - Rear 8-729
 Folding Top - Rear Upper 8-736
 Folding Top - Side 8-720
 Instrument Panel Ash Tray 8-446
 Rear Compartment Lid 8-82
 Stowage Compartment Lid - Folding
 Top - Roof 8-742
 Lead/Pull Description
 Wheel Alignment 3-18
 Leak at Front Slip Yoke - Propeller Shaft 4-4
 Leak Testing
 HVAC 1-4
 License Lamp
 Bulb Replacement
 Lighting Systems 8-630
 Inoperative
 Lighting Systems 8-587
 Replacement
 Lighting Systems 8-629
 License, Marker, and Tail Lamps
 Always On
 Lighting Systems 8-591
 Inoperative
 Lighting Systems 8-592
 Lid Replacement
 Stowage Compartment - Folding
 Top - Roof 8-781
 Lifting and Jacking the Vehicle 0-21
 Lights
 Inoperative in Content Theft
 Deterrent (CTD) Alarm Mode 11-123
 Line Pressure
 4L60-E/4L65-E 7-60
 Line Pressure Check Procedure
 4L60-E/4L65-E 7-215
 Linkage Replacement
 Endgate 8-88
 Liquid Line
 Replacement
 HVAC 1-34
 Lock Cylinder
 Replacement - Door 8-306
 Lock Cylinder Latch Plate
 Replacement - Rear Compartment Lid 8-74
 Lock Cylinder Latch Plate Cover
 Replacement - Rear Compartment Lid 8-73
 Lock Cylinders and Key Coding 0-20
 Lock Pillar
 Gusset Replacement - Rear Compartment
 Collision Repair 8-208
 Lock Striker Replacement
 Endgate 8-89
 Lock System
 Does Not Lock
 Steering Wheel and Column 2-53
 Does Not Unlock
 Steering Wheel and Column 2-50
 Sticks in Start
 Steering Wheel and Column 2-53
 Looseness in Steering Column
 Steering Wheel and Column 2-57
 Loss of Coolant 6-283
 Low Fuel Indicator
 Inoperative 8-427
 Lower Engine Noise, Regardless of
 Engine Speed
 Engine Mechanical - 6.0L 6-30
 Lubricant
 Leak Diagnosis
 Rear Drive Axle 4-24
 Level Inspection
 Rear Drive Axle 4-26
 Replacement
 Rear Drive Axle 4-26
 Lubricant and Fluid Recommendations 0-25
 Lubrication Specifications
 Tremec 6-Speed 7-5
 Luggage Compartment Description and
 Operation 8-98
 Lumbar Replacement
 Front Seat 8-903
 Lumbar Support
 Inoperative
 Seats 8-874
 Lumbar Support Description and Operation 8-921
- ## M
- Mainshaft
 Rear Oil Seal Replacement
 Tremec 6 Speed 7-39
 Maintenance Items
 Maintenance and Lubrication 0-25
 Maintenance Schedule 0-25
 Malfunction Indicator Lamp (MIL)
 Always On
 Engine Controls - 6.0L 6-705
 Inoperative
 Engine Controls - 6.0L 6-703
 Manual Shift
 Shaft Seal Replacement
 4L60-E/4L65-E 7-271
 Manual Transmission Description and
 Operation
 Tremec 6-Speed 7-46

- Marker Lamp
 Bulb Replacement - Front Side
 Lighting Systems 8-617
 Bulb Replacement - Rear Side
 Lighting Systems 8-620
 Replacement - Front Side
 Lighting Systems 8-616
 Replacement - Rear Side
 Lighting Systems 8-619
 Marker Lamps
 Inoperative
 Lighting Systems 8-587
 Marker, Tail, and License Lamps
 Always On
 Lighting Systems 8-591
 Inoperative
 Lighting Systems 8-592
 Master Cylinder
 Bench Bleeding
 Hydraulic Brakes 5-38
 Fluid Level Sensor Replacement
 Hydraulic Brakes 5-39
 Overhaul
 Hydraulic Brakes 5-36
 Replacement
 Clutch 7-326
 Hydraulic Brakes 5-33
 Reservoir Filling
 Hydraulic Brakes 5-30
 Reservoir Replacement
 Hydraulic Brakes 5-31
 Meanings of Abbreviations 0-13
 Mechanism Replacement
 Seat Adjuster - Power 8-906
 Memory Seat
 Feature Inoperative 8-873
 Memory Seats Description and Operation 8-922
 Memory Steer
 Suspension General Diagnosis 3-6
 Memory Steer Description
 Wheel Alignment 3-18
 Metal Panel Bonding
 Collision Repair 8-240
 Metric Wheel Nuts and Bolts Description
 Tires and Wheels 3-74
 Microphone
 Replacement - Radio Volume
 Compensator Interior
 Entertainment 11-51
 Mirror
 Face Replacement
 Doors 8-332
 Replacement - Power
 Doors 8-330
 Mode Actuator Replacement
 HVAC Systems - Manual 1-100
 Mode Door
 Replacement
 HVAC 1-54
 Mounting and Hardware Inspection
 Front
 Disc Brakes 5-65
 Rear
 Disc Brakes 5-65
 Muckets Replacement
 Folding Top Stowage Compartment Lid
 Lock Pillar 8-790
 Muffler Replacement
 Engine Exhaust 6-828
 Multifunction
 Turn Signal Switch Housing Replacement
 Steering Wheel and Column 2-73
 Turn Signal Switch Replacement
 Steering Wheel and Column 2-75

N

 Noise
 Brake System
 Hydraulic Brakes 5-11
 Buzz or High Frequency Rattle Sound
 4L60-E/4L65-E 7-244
 Clutch 7-323
 Constant Noise
 Rear Drive Axle 4-18
 Diagnosis, Front Suspension
 Suspension General Diagnosis 3-8
 Diagnosis, Rear Suspension
 Suspension General Diagnosis 3-8
 Exterior Wind Noise 0-91
 In Random Ranges
 4L60-E/4L65-E 7-244
 In Steering Column 2-55
 Interior Windnoise 0-91
 Intermittent
 Rear Drive Axle 4-17
 Knock or Clunk
 Propeller Shaft 4-5
 Noise and Vibration Analysis
 4L60-E/4L65-E 7-221
 Noisy in Drive
 Rear Drive Axle 4-17
 Noisy on Turns
 Rear Drive Axle 4-18
 Noisy When Coasting
 Rear Drive Axle 4-17
 Ping, Snap, or Click
 Propeller Shaft 4-5
 Popping
 4L60-E/4L65-E 7-244
 Ratcheting Noise
 4L60-E/4L65-E 7-243
 Rattle, Clunk or Shudder
 Power Steering System 2-9
 Rear Drive Axle 4-16
 Scraping
 Propeller Shaft 4-5
 Squeak
 Propeller Shaft 4-5
 Transmission
 Tremec 6 Speed 7-27
 Transmission Clunk on Acceleration or
 Deceleration
 Tremec 6 Speed 7-32
 Universal Joint
 Propeller Shaft 4-4
 Whine or Growl
 Power Steering System 2-11

Noise (cont.)	
Whine Varying with RPM or Fluid Pressure	
4L60-E/4L65-E	7-244
Whining in Park and Vibration in Reverse	
4L60-E/4L65-E	7-243
Noise Compensated Volume Inoperative	
Entertainment	11-44
Noise Diagnosis	
Air Conditioning (A/C) System	1-18
Blower Motor	1-18
HVAC Module	1-20
Notice, Caution and Important, Definition of	P-3

O

Odometer	
Trip/Reset Switch Inoperative	
Instrument Panel, Gages, and Console	8-425
Odor Correction	
HVAC	1-22
Odor Diagnosis	
HVAC	1-21
Odors	
Eliminating Unwanted Odors in Vehicles	
Interior Trim	8-491
Oil Consumption Diagnosis	
Engine Mechanical - 6.0L	6-35
Oil Filter	
Adapter Replacement	
Engine Mechanical - 6.0L	6-97
Bypass Valve Replacement	
Engine Mechanical - 6.0L	6-98
Oil Leak Diagnosis	
Engine Mechanical - 6.0L	6-37
Oil Level Indicator and Tube	
Replacement	
Engine Mechanical - 6.0L	6-77
Oil Out the Vent	
4L60-E/4L65-E	7-243
Oil Pan	
Replacement	
Engine Mechanical - 6.0L	6-100
Oil Pressure	
Diagnosis and Testing	
Engine Mechanical - 6.0L	6-35
High or Low	
4L60-E/4L65-E	7-235
Oil Pressure Relief Valve	
Diagnosis and Testing	
Engine Mechanical - 6.0L	6-36
Oil Pump, Screen and Crankshaft Oil	
Deflector	
Installation	
Engine Mechanical - 6.0L	6-225
Removal	
Engine Mechanical - 6.0L	6-145
Replacement	
Engine Mechanical - 6.0L	6-105
Outside Air Temperature Display Inaccurate or Inoperative	
Instrument Panel, Gages, and Console	8-429

Outside Mirror Description and Operation	8-336, 8-337
Overlap/Backing Plate - Sectioning	
Collision Repair	8-135 8-136

P

Paint Gages	
Paint/Coatings	8-641
Paint Identification	
Paint/Coatings	8-640
Panel Adjustment	
Folding Top - Front	8-802
Folding Top - Rear	8-805
Panel Identification	
Collision Repair	8-116, 8-117, 8-118
Panel Replacement	
Body Rear Outer	
Collision Repair	8-237
Finish - Front Seat, Front	8-879
Folding Top - Front	8-799
Folding Top - Rear	8-803
Folding Top Stowage Compartment Lid	
Extension	8-784
Folding Top Stowage Compartment Lid	
Hydraulic Cylinder Extension	8-747
Seat Back - Front	8-901
Seat Back Cushion Side Bolster	8-900
Seat Cushion Outer Trim	8-883
Panic Mode	
Inoperative	
Keyless Entry	11-76
Park	
No Park	
4L60-E/4L65-E	7-243
Vibration in Reverse and Whining Noise in Park	
4L60-E/4L65-E	7-243
Park Brake	
Adjustment	5-148
Cable Automatic Adjuster	
Disabling	5-142
Enabling	5-143
Cable Replacement - Front	5-129
Cable Replacement - Left Rear	5-134
Cable Replacement - Right Rear	5-138
Description and Operation	5-149
Lever Assembly Replacement	5-126
Shoe Inspection	5-121
System Diagnosis	5-119
Warning Lamp Switch Replacement	5-128
Will Not Hold or Release	5-118
Park Lamps	
Inoperative	
Lighting Systems	8-588
Park Lock	
Solenoid Inoperative	
Shift Lock Control	7-53
Park/Neutral Position Switch	
Adjustment	
4L60-E/4L65-E	7-255
Replacement	
4L60-E/4L65-E	7-253

- Park/Turn Signal
 - Lamp Bulb Replacement
 - Lighting Systems 8-623
 - Lamp Replacement
 - Lighting Systems 8-622
- Pedal
 - Replacement
 - Clutch 7-326
- Pedal Position Switch
 - Replacement
 - Clutch 7-328
- Pickup Box
 - Side Panel Brace Replacement
 - Front 8-92
 - Rear 8-93
- Pillar Lock
 - Front Door Replacement - Inner
 - Collision Repair 8-173
- Pilot Bearing
 - Replacement
 - Clutch 7-329
- Pin Replacement
 - Folding Top Hydraulic Cylinder Pivot
 - Roof 8-771
- Pinion
 - Depth Adjustment
 - Rear Drive Axle 4-54
 - Flange Runout Measurement
 - Vibration Diagnosis and Correction 0-66
- Pinion and Ring Gear Inspection
 - Rear Drive Axle 4-53
- Plastic Identification and Refinishing
 - Systems 8-644
- Plastic Parts
 - How to Identify
 - Plastic Panel Information and Repair 8-643
- Plastic Repair Instructions - General
 - Plastic Panel Information and Repair 8-643
- P-Metric Sized Tires Description
 - Tires and Wheels 3-76
- Poor Connections, Testing for
 - Wiring Systems 8-991
- Poor Directional Stability
 - Suspension General Diagnosis 3-7
- Poor Fuel Economy
 - Engine Controls - 6.0L 6-695
- Poor Fuel Fill Quality
 - Engine Controls - 6.0L 6-697
- Power Door Locks
 - Description and Operation 8-335
 - Inoperative 8-272
 - Inoperative - Driver Door 8-274
 - Inoperative - Passenger Door 8-276
- Power Folding Top
 - Adding Fluid 8-759
 - Inoperative 8-712
- Power Folding Top Description and Operation 8-832
- Power Mirror Switch
 - Replacement
 - Doors 8-284
- Power Mirrors
 - Inoperative
 - Doors 8-277
- Power Mode
 - Mismatch
 - Computer/Integrating Systems 10-67
- Power Seat
 - Does Not Move Forward/Rearward 8-869
 - Does Not Tilt Forward 8-870
 - Does Not Tilt Rearward 8-872
 - Inoperative 8-867, 8-868
- Power Seats Systems Description and Operation 8-921
- Power Steering
 - Bleeding the System 2-16
 - Checking and Adding Fluid 2-16
 - Cooler Replacement 2-23
 - Flushing the System 2-16
 - Gear Replacement 2-28
 - Hose Assembly Replacement 2-25
 - Reservoir Replacement - Off Vehicle 2-19
- Power Steering Pump
 - Drive Shaft Seal Replacement -
 - Off Vehicle 2-21
 - Flow Control Valve Replacement -
 - Off Vehicle 2-20
 - Replacement 2-18
 - Specifications 2-3
- Power Steering System
 - Description and Operation 2-39
 - Fluid Leaks 2-9
 - Test Procedure 2-6
- Power Window
 - Inoperative from Master Switch
 - Doors 8-270
- Power Windows
 - Description and Operation 8-334
- Pressure Cap Testing
 - Engine Cooling 6-287
- Pressure Plate Adjustment
 - Clutch 7-332
- Pressure Regulator
 - Replacement
 - 4L60-E/4L65-E 7-267
- Pressure Relief Valve
 - Replacement 8-95
- Pretensioner Handling and Scrapping
 - SIR 9-132
- Propeller Shaft
 - Description and Operation 4-13
 - Knock or Clunk Noise 4-5
 - Phasing Correction
 - Vibration Diagnosis and Correction 0-78
 - Phasing Inspection
 - Vibration Diagnosis and Correction 0-68
- Ping, Snap, or Click Noise 4-5
- Replacement 4-6
- Runout Measurement
 - Vibration Diagnosis and Correction 0-64
- Runout Specifications
 - Vibration Diagnosis and Correction 0-26
- Scrapping Noise 4-5
- Squeak Noise 4-5
- Pull Handle
 - Replacement
 - Doors 8-287

Pulley Replacement	
Power Steering System	2-17
Pump with Motor Replacement	
Folding Top	8-760

Q

Quarter Panel	
Replacement - Outer	
Collision Repair	8-199, 8-203
Quarter Panel Protector	
Replacement	8-90

R

Rack and Pinion	
Boot Replacement - Off Vehicle	
Power Steering System	2-31
Gear Rack Bearing Preload Adjustment -	
Off Vehicle	
Power Steering System	2-30
Inner Tie Rod Replacement - Off Vehicle	
Power Steering System	2-33
Radiator	
Cleaning - Engine Cooling	6-296
Hose Replacement	
Inlet - Engine Cooling	6-299
Outlet - Engine Cooling	6-300
Replacement - Engine Cooling	6-310
Support Replacement - Engine Cooling	6-311
Radio	
Poor Reception	
Entertainment	11-42
Replacement	
Entertainment	11-47
Radio Displays	
CAL ERR	
Entertainment	11-44
LOC, LOCKED or CODE	
Entertainment	11-43
Radio/Audio	
System Description and Operation	
Entertainment	11-60
Rail Assembly Replacement	
Side - Folding Top - Roof	8-779
Rail Dust Damage Repair	
Paint/Coatings	8-641
Range Reference	
4L60-E/4L65-E	7-59
Range Selector	
Cable Adjustment	
4L60-E/4L65-E	7-250
Cable Bracket Replacement	
4L60-E/4L65-E	7-249
Cable Replacement	
4L60-E/4L65-E	7-247
Displays Incorrect Range	
4L60-E/4L65-E	7-211
Rattle, Clunk or Shudder Noise	
Power Steering System	2-9

Rear Axle	
Brace Replacement	
Rear Suspension	3-57
Housing Cover and Gasket Replacement	
Rear Drive Axle	4-28
Shaft Replacement	
Rear Drive Axle	4-29
Shaft Seal and/or Bearing Replacement	
Rear Drive Axle	4-32
Rear Compartment	
Floor Rail Replacement	8-51
Rear Compartment Endgate	
Access Panel Replacement	8-54
Hinge Mounting Bracket Replacement	8-55
Liner Replacement	8-50
Rear Compartment Lid	
Release Inoperative	8-39
Switch Replacement	8-57
Rear Compartment Lid Ajar Indicator	
Inoperative	8-41
Rear Compartment Liner	
Replacement	8-44, 8-47
Rear Compartment Upper Rail	
Replacement	8-53
Rear Drive Axle	
Constant Noise	4-18
Description and Operation	4-66
Intermittent Noise	4-17
Noises	4-16
Noisy in Drive	4-17
Noisy on Turns	4-18
Noisy When Coasting	4-17
Rear Suspension	
General Description	3-66
Rearview Mirror	
Lamp Replacement	
Lighting Systems	8-604
Replacement	8-937
Support Replacement	8-938
Re-Calibrating Actuators	
HVAC Systems - Manual	1-98
Recirculation Actuator Replacement	
HVAC Systems - Manual	1-101
Recirculation Door	
Replacement	
HVAC	1-56
Recliner Replacement	
Seat Back - Front	8-892
Reduced Volume - One or More Speakers	
Entertainment	11-45
Reed Tachometer Description	
Vibration Diagnosis and Correction	0-88
Refrigerant	
Recovery and Recharging	
HVAC	1-23
System Capacities	
HVAC	1-3
Registered and Non-Registered Trademarks	0-19
Rely Replacement	
Wiring Systems	8-1148, 8-1149

- Repair Materials
 Flexible Plastic Part
 Plastic Panel Information and Repair 8-642
 Rigid Plastic Part
 Plastic Panel Information and Repair 8-642
 Restricted Exhaust
 Engine Exhaust 6-812
 Retained Accessory Power
 Description and Operation
 Computer/Integrating Systems 10-78
 Inoperative
 Computer/Integrating Systems 10-70
 On After Timeout
 Computer/Integrating Systems 10-69
 Retainer Replacement
 Folding Top Rear Panel
 Weatherstrip - Rear 8-821
 Folding Top Weatherstrip - Side Front 8-818
 Reveal Molding
 Repair
 Stationary Window 8-936
 Reverse
 No Reverse or Slips in Reverse
 4L60-E/4L65-E 7-239
 No Second, Fourth and Reverse Gear
 4L60-E/4L65-E 7-218, 7-238
 Vibration in Reverse and Whining Noise
 in Park
 4L60-E/4L65-E 7-243
 Reverse Inhibit Description and Operation
 Tremec 6 Speed 7-47
 Reverse Lockout Solenoid Replacement
 Tremec 6 Speed 7-41
 Ride Diagnosis
 Suspension General Diagnosis 3-3
 Road Test Procedure
 4L60-E/4L65-E 7-215
 Rocker Panel
 Replacement - Inner
 Collision Repair 8-169
 Roof
 Mounting Bracket Replacement
 Collision Repair 8-160
 Room Temperature Vulcanizing (RTV) and
 Anaerobic Sealer, Use of
 Engine Mechanical - 6.0L 6-266
 Rough, Unstable, or Incorrect Idle and
 Stalling
 Engine Controls - 6.0L 6-698
 RPO Code List 0-8
- S**
- Scan Tool
 Does Not Communicate with Class 2
 Device
 Computer/Integrating Systems 10-62
 Does Not Communicate with High Speed
 GMLAN Device
 Computer/Integrating Systems 10-64
 Does Not Power Up
 Computer/Integrating Systems 10-61
- Scan Tool Data Definitions
 4L60-E/4L65-E 7-95
 ABS 5-157
 Body Rear End 8-39
 Computer/Integrating Systems 10-33
 Cruise Control 11-7, 11-8
 Doors 8-261
 Engine Controls - 6.0L 6-416
 Engine Cooling 6-276
 Engine Electrical 6-325
 Entertainment 11-37
 Horns 8-369
 HVAC Systems - Manual 1-74
 Instrument Panel, Gages, and Console 8-396
 Keyless Entry 11-75
 Lighting Systems 8-539
 Manual Transmission
 Tremec 6 Speed 7-9
 Roof 8-668
 Seats 8-858
 SIR 9-41
 Theft Deterrent 11-100
 Scan Tool Data List
 4L60-E/4L65-E 7-93
 ABS 5-156
 Body Rear End 8-38
 Computer/Integrating Systems 10-33
 Cruise Control 11-7
 Doors 8-259
 Engine Controls - 6.0L 6-411
 Engine Cooling 6-276
 Engine Electrical 6-325
 Entertainment 11-36
 Horns 8-369
 HVAC Systems - Manual 1-74
 Instrument Panel, Gages, and Console 8-393
 Keyless Entry 11-75
 Lighting Systems 8-538
 Roof 8-666
 Seats 8-857
 SIR 9-40
 Theft Deterrent 11-99
 Tremec 6 Speed 7-8
 Scan Tool Output Controls
 4L60-E/4L65-E 7-90
 ABS 5-155
 Body Rear End 8-38
 Computer/Integrating Systems 10-33
 Doors 8-259
 Engine Controls - 6.0L 6-422
 Engine Cooling 6-276
 Engine Electrical 6-325
 Horns 8-368
 HVAC Systems - Manual 1-74
 Instrument Panel, Gages, and Console 8-393
 Keyless Entry 11-74
 Lighting Systems 8-538
 Roof 8-666
 Tremec 6 Speed 7-9
 Scan Tool Snapshot Procedure
 Wiring Systems 8-995

- Schematic Icons
 4L60-E/4L65-E 7-61
 ABS 5-150
 Computer/Integrating Systems 10-20
 Engine Controls - 6.0L 6-378
 Entertainment 11-19
 Instrument Panel, Gages, and Console 8-379
 Lighting Systems 8-506
 Power and Grounding 8-1026
 Seat Belts 9-3
 SIR 9-17
 Steering Wheel and Column 2-41
 Tremec 6 Speed 7-5
- Schematics
 ABS 5-151
 Audible Warnings 8-385
 Automatic Transmission Controls
 4L60-E/4L65-E 7-62
 Automatic Transmission Shift Lock Control 7-50
 Body Control System
 Computer/Integrating Systems 10-21
 Body Rear End 8-34
 Cigar Lighter/Auxiliary Outlets 11-86
 Column/Ignition Lock
 Steering Wheel and Column 2-42
 Cruise Control 11-4
 Data Link Connector
 Computer/Integrating Systems 10-24
 Defogger 8-924
 Door Lock/Indicator 8-243
 Driver Information System 8-384
 Driver Seat 8-836
 Engine Controls - 6.0L 6-379
 Engine Cooling 6-273
 Exterior Lamps 8-511
 Fog Lamps 8-510
 Garage Door Opener 11-65
 Ground Distribution 8-1043
 Headlamps/Daytime Running
 Lamps (DRL) 8-507
 Horns 8-365
 HVAC Systems - Manual 1-62
 Hydraulic Brake Warning System 5-4
 Inside Rearview Mirror 8-925
 Instrument Cluster 8-380
 Interior Lamps 8-517
 Interior Lamps Dimming 8-519
 Keyless Entry 11-72
 Outside Mirrors 8-245
 Passenger Seat 8-840
 Power Distribution 8-1027
 Power Folding Top 8-647
 Power Windows 8-242
 Radio/Audio System 11-20
 Seat Belts 9-4
 SIR 9-18
 Starting and Charging 6-319
 Steering Wheel 2-43
 Theft Deterrent 11-95
 Tremec 6 Speed 7-6
 Wipers/Washer Systems 8-954
- Scrub Radius Description
 Wheel Alignment 3-18
- Seal Replacement
 Folding Top Stowage Compartment
 Lid Hinge 8-786
 Folding Top Stowage Compartment
 Lid Latch 8-745
 Hood Rear 8-29
- Sealers, Adhesives and Lubricants
 Clutch 7-318
- Sealers, Adhesives, and Lubricants
 Engine Mechanical - 6.0L 6-12
 Propeller Shaft 4-3
 Rear Drive Axle 4-15
- Sealing Strip
 Replacement - Front Door Window Belt
 Outer 8-328
- Sealing Washer Replacement
 HVAC 1-30
- Seat
 Replacement 8-878
- Seat Belt
 Buckle Replacement
 Front 9-10
 Indicator Circuit Malfunction 9-8
 Operational and Functional Checks 9-7
 Repairs and Inspections Required After a
 Collision 9-9
 Replacement
 Front 9-10
 Retractor
 Anchor Plate Replacement 9-15
 Retractor Pretensioner Replacement -
 Front 9-111
 Service Precautions 9-8
 System Description and Operation 9-16
- Seats
 Power Seat Switch Replacement 8-905
- Second Gear
 No Second, Fourth and Reverse Gear
 4L60-E/4L65-E 7-218, 7-238
 No Third or Fourth Gear/No First or
 Second Gear
 4L60-E/4L65-E 7-238
 Second/Third Gear Only
 4L60-E/4L65-E 7-238
- Start
 4L60-E/4L65-E 7-243
- Security Indicator
 Inoperative
 Theft Deterrent 11-123
- Service Port
 Valve Core Replacement
 HVAC 1-36
- Service Programming System (SPS) 10-79
- Setback Description
 Wheel Alignment 3-17

- Shift
 - Clutch Drag Hard Shifting 7-319
 - Hard
 - Tremec 6 Speed 7-23
 - Harsh
 - 4L60-E/4L65-E 7-235
 - Harsh Garage Shift
 - 4L60-E/4L65-E 7-240
 - Inaccurate Shift Points
 - 4L60-E/4L65-E 7-236
 - No 2-3 Shift or 2-3 Shift Slips, Rough or Hunting
 - 4L60-E/4L65-E 7-238
 - No 3-4 Shift, Slips or Rough 3-4 Shift
 - 4L60-E/4L65-E 7-239
 - No Part Throttle or Delayed Downshifts
 - 4L60-E/4L65-E 7-240
- Shift Control
 - Assembly Replacement
 - Tremec 6 Speed 7-38
 - Boot Replacement
 - Tremec 6 Speed 7-38
- Shift Lever
 - Can Be Moved with Brake Pedal Depressed
 - Shift Lock Control 7-55
 - Does Not Move with Brake Pedal Depressed
 - Shift Lock Control 7-53
 - Indicates Wrong Gear
 - 4L60-E/4L65-E 7-245
- Shift Lock Control
 - Description and Operation 7-56
- Shift Solenoid
 - Leak Test
 - 4L60-E/4L65-E 7-225
 - Valve State and Gear Ratio
 - 4L60-E/4L65-E 7-60
- Shift Speed
 - 4L60-E/4L65-E 7-60
- Shims Inspection
 - Rear Drive Axle 4-53
- Shock Absorber
 - Disposal
 - Front Suspension 3-49
 - Rear Suspension 3-63
 - Replacement
 - Rear Suspension 3-61
- Shock Absorbers
 - Or Struts On-Vehicle Testing
 - Suspension General Diagnosis 3-10
- Shock Module
 - Replacement
 - Front Suspension 3-41
 - Yoke Replacement
 - Front Suspension 3-47
- Shock, Shock Component and/or Spring
 - Replacement
 - Front Suspension 3-44
- Shoe Replacement
 - Park Brake 5-123
- Short to Ground, Testing for
 - Wiring Systems 8-991
- Short to Voltage, Testing for
 - Wiring Systems 8-991
- Shoulder Belt
 - Guide Bracket Replacement 9-13
- Shudder on Acceleration at Low Speed
 - Propeller Shaft 4-5
- SIR
 - Disabling and Enabling Zone 1 9-81
 - Disabling and Enabling Zone 2 9-82
 - Disabling and Enabling Zone 3 9-83
 - Disabling and Enabling Zone 5 9-85
 - Disabling and Enabling Zone 6 9-86
 - Disabling and Enabling Zone 7 9-87
 - Disabling and Enabling Zone 8 9-89
 - Disabling and Enabling Zone 9 9-90
 - Disabling and Enabling Zones 9-79
 - Repairs and Inspections Required After a Collision 9-114
 - System Description and Operation 9-142
 - Zone Identification Views 9-31
- SIR/SRS Wiring Repairs
 - Wiring Systems 8-1006
- Skip Shift Description and Operation
 - Tremec 6 Speed 7-47
- Soap Suds or Bubble Test 0-90
- Speaker Replacement
 - Front Lower
 - Entertainment 11-55
 - Front Upper
 - Entertainment 11-57
 - Rear
 - Entertainment 11-59
 - Reference
 - Entertainment 11-46
- Speakers Inoperative
 - One or More
 - Entertainment 11-46
- Special Tools
 - 4L60-E/4L65-E 7-316
 - ABS 5-204
 - Air/Wind Noise 0-91
 - Body Front End 8-32
 - Body Rear End 8-98
 - Clutch 7-334
 - Disc Brakes 5-117
 - Doors 8-337
 - Engine Controls - 6.0L 6-808
 - Engine Cooling 6-317
 - Engine Electrical 6-370
 - Engine Exhaust 6-836
 - Engine Mechanical - 6.0L 6-267
 - Entertainment 11-63
 - Exterior Trim 8-351
 - Front Suspension 3-51
 - Garage Door Opener 11-70
 - General Information 0-24
 - HVAC 1-59
 - HVAC Systems - Manual 1-105
 - Hydraulic Brakes 5-60
 - Instrument Panel, Gages, and Console 8-490
 - Keyless Entry 11-81
 - Lighting Systems 8-636
 - Ordering Information 0-5

- Special Tools (cont.)
- Park Brake 5-149
 - Power Outlets 11-93
 - Power Steering System 2-40
 - Propeller Shaft 4-13
 - Rear Drive Axle 4-67
 - Rear Suspension 3-66
 - Roof 8-834
 - SIR 9-145
 - Squeaks and Rattles 0-92
 - Stationary Windows 8-952
 - Steering Wheel and Column 2-100
 - Suspension General Diagnosis 3-12
 - Theft Deterrent 11-128
 - Tires and Wheels 3-76
 - Tremec 6-Speed 7-48
 - Vibration Diagnosis and Correction 0-88
 - Wipers/Washer Systems 8-977
 - Wiring Systems 8-1157
- Speedometer and/or Odometer
- Inaccurate or Inoperative
 - Instrument Panel, Gages, and Console 8-425
- Splash Shield
- Replacement - Engine 8-30
- Splicing
- Copper Wire Using Splice Clips
 - Wiring Systems 8-1001
 - Copper Wire Using Splice Sleeves
 - Wiring Systems 8-1003
 - Inline Harness Diodes
 - Wiring Systems 8-1005
 - Twisted or Shielded Cable
 - Wiring Systems 8-1004
- Squeaks and Rattles 0-92
- Stabilizer Shaft
- Insulator Replacement
 - Front Suspension 3-23
 - Rear Suspension 3-60
 - Link Replacement
 - Front Suspension 3-22
 - Rear Suspension 3-60
 - Replacement
 - Front Suspension 3-20
 - Rear Suspension 3-58
- Starter Motor
- Noise Diagnosis - Engine Electrical 6-347
 - Replacement - Engine Electrical 6-361
 - Shield Replacement - Engine Electrical 6-364
- Starter Solenoid
- Clicks, Engine Does Not Crank - Engine
 - Electrical 6-346
 - Does Not Click - Engine Electrical 6-343
- Starting System Description and Operation 6-370
- Stationary Window
- Description 8-950
 - Waterleak Repair 0-97
- Steering
- Effort Easy in One or Both Directions
 - Power Steering System 2-11
 - Effort Hard in One or Both Directions
 - Power Steering System 2-11
 - Gear Cylinder Pipe Assemblies/O-Ring
 - Seals Replacement - Off Vehicle
 - Power Steering System 2-36
- Steering Column
- Accident Damage Inspection
 - Steering Wheel and Column 2-63
 - Jacket Replacement
 - Steering Wheel and Column 2-93
 - Replacement
 - Steering Wheel and Column 2-91
 - Shaft Replacement
 - Steering Wheel and Column 2-94
 - Tilt Function Inoperative
 - Steering Wheel and Column 2-51
 - Tilt Head Housing Replacement
 - Steering Wheel and Column 2-86
 - Trim Covers Replacement
 - Steering Wheel and Column 2-64
 - Wire Harness Assembly Replacement
 - Steering Wheel and Column 2-95
- Steering Knuckle
- Replacement
 - Front Suspension 3-27
- Steering Wheel
- Control Switch Assembly Replacement
 - Steering Wheel and Column 2-78
 - Controls Description and Operation 2-99
 - Replacement
 - Steering Wheel and Column 2-80
 - Theft Deterrent Lock Replacement
 - Steering Wheel and Column 2-82
- Steering Wheel and Column Description and Operation 2-99
- Stop Lamp
- Switch Replacement
 - Lighting Systems 8-597
- Stop Lamps
- Always On
 - Lighting Systems 8-588
 - Inoperative
 - Lighting Systems 8-589
- Storage Compartment
- Replacement - Instrument Panel 8-443
- Stowage Compartment Lid Striker
- Folding Top- Roof 8-745
- Strategy Based Diagnosis 0-22
- Striker Replacement
- Doors 8-314
 - Latch - Folding Top Panel, Front 8-738
- Strikers Replacement
- Folding Top - Rear Upper 8-740
- Structure Adhesive - Identification
- Collision Repair 8-119
- Structure Foam
- Identification
 - Collision Repair 8-122
 - Replacement
 - Collision Repair 8-127
- Structure Identification
- Collision Repair 8-124
- Strut Replacement
- Folding Top Lift Assist 8-793
- Struts
- Or Shock Absorbers On-Vehicle Testing
 - Suspension General Diagnosis 3-10

- Sunshade
 Anchor Replacement
 Interior Trim 8-502
 Replacement
 Interior Trim 8-501
 Support Cable
 Replacement - Endgate 8-80
 Support Replacement
 Head Restraint - Seats 8-919
 Surge Tank
 Replacement - Engine Cooling 6-297
 Surge Tank Hose/Pipe
 Replacement
 Inlet - Engine Cooling 6-298
 Surges/Chuggles
 Engine Controls - 6.0L 6-685
 Suspension
 Bottoms
 Suspension General Diagnosis 3-5
 Switch
 Power Seat Switch Replacement 8-905
 Switch Replacement
 Heated Seat
 Front 8-910
 Side Window and Multi-Function
 Doors 8-281
 Symptoms
 4L60-E/4L65-E 7-209
 ABS 5-183
 Automatic Transmission Shift Lock Control 7-52
 Body Rear End 8-39
 Clutch 7-319
 Computer/Integrating Systems 10-60
 Cruise Control 11-13
 Doors 8-270
 Engine Controls - 6.0L 6-682
 Engine Cooling 6-279
 Engine Electrical 6-332
 Engine Exhaust 6-811
 Engine Mechanical - 6.0L 6-26
 Entertainment 11-40
 Garage Door Opener 11-67
 Horns 8-371
 HVAC Systems - Manual 1-84
 Hydraulic Brakes 5-7
 Instrument Panel, Gages, and Console 8-419
 Keyless Entry 11-76
 Lighting Systems 8-566
 Park Brake 5-118
 Power Steering System 2-6
 Propeller Shaft 4-4
 Rear Drive Axle 4-16
 Roof 8-712
 Seat Belts 9-7
 Seats 8-866
 SIR 9-77
 Stationary Windows 8-928
 Steering Wheel Controls
 Steering Wheel and Column 2-50
 Suspension General Diagnosis 3-3
 Theft Deterrent 11-118
 Tremec 6 Speed 7-23
- Symptoms (cont.)
 Vehicle DTC Information 10-17
 Vibration Diagnosis and Correction 0-53
 Wiper/Washer Systems 8-958
- ## T
- Tachometer
 Inaccurate or Inoperative
 Instrument Panel, Gages, and Console 8-426
 Tail Lamp
 Bulb Replacement
 Lighting Systems 8-632
 Replacement
 Lighting Systems 8-631
 Tail Lamps
 Inoperative
 Lighting Systems 8-590
 Tail, Marker, and License Lamps
 Always On
 Lighting Systems 8-591
 Inoperative
 Lighting Systems 8-592
 Temperature vs Resistance
 Engine Controls - 6.0L 6-371
 Terminal Position Assurance Locks
 Wiring Systems 8-1011
 Test Light, Troubleshooting with a
 Wiring Systems 8-989
 Testing for
 Continuity
 Wiring Systems 8-990
 Electrical Intermittents
 Wiring Systems 8-994
 Poor Connections
 Wiring Systems 8-991
 Short to Ground
 Wiring Systems 8-991
 Short to Voltage
 Wiring Systems 8-991
 Theft Deterrent System
 Components, Programming 11-124
 Theft Systems Description and Operation
 Theft Deterrent 11-125
 Thermal Expansion Valve
 Replacement
 HVAC 1-37
 Thermostat
 Diagnosis - Engine Cooling 6-286
 Housing Replacement - Engine Cooling 6-303
 Third Gear
 No First or Second Gear/No Third or
 Fourth Gear
 4L60-E/4L65-E 7-238
 No Third Gear
 4L60-E/4L65-E 7-242
 Only
 4L60-E/4L65-E 7-238
 Second/Third Gear Only
 4L60-E/4L65-E 7-238
 Thread Inserts 0-13
 Thrust Angles Description
 Wheel Alignment 3-17

- Tie Bar
 - Replacement - Upper 8-27
 - Collision Repair 8-144
- Tie Rod
 - End Replacement - Outer - On Vehicle
 - Power Steering System 2-22
 - Replacement
 - Rear Axle 3-56
- Tilt Lever Replacement
 - Steering Wheel and Column 2-76
- Tilt Spring Replacement
 - Steering Wheel and Column 2-83
- Timing Chain and Sprockets
 - Replacement
 - Engine Mechanical - 6.0L 6-108
- Tire
 - Description - All Season 3-75
 - Diagnosis
 - Irregular or Premature Wear 3-67
 - Waddle Complaint 3-68
 - Inflation Description 3-75
 - Lead/Pull Correction - Radial 3-70
 - Mounting and Dismounting 3-74
 - Repair 3-73
 - Rotation 3-74
- Tire and Wheel
 - Assembly Balancing - Off-Vehicle
 - Vibration Diagnosis and Correction 0-69
 - Assembly Isolation Test
 - Vibration Diagnosis and Correction 0-62
 - Assembly Runout Measurement - Off-Vehicle
 - Vibration Diagnosis and Correction 0-56
 - Assembly Runout Measurement - On-Vehicle
 - Vibration Diagnosis and Correction 0-56
 - Assembly-to-Hub/Axle Flange Match-Mounting
 - Vibration Diagnosis and Correction 0-74
 - Inspection
 - Vibration Diagnosis and Correction 0-55
 - Runout Specifications
 - Vibration Diagnosis and Correction 0-26
- Tire and Wheel Assembly Balancing - On-Vehicle
 - Vibration Diagnosis and Correction 0-73
- Tires and Wheels
 - General Description 3-74
 - Removal and Installation 3-72
- Tire-to-Wheel Match-Mounting (Vectoring)
 - Vibration Diagnosis and Correction 0-73
- Toe Adjustment
 - Front
 - Wheel Alignment 3-15
- Toe Description
 - Wheel Alignment 3-17
- Tools and Equipment
 - Engine Mechanical - 6.0L 6-266
- Torque Converter
 - Clutch Intermittent - OK Cold/Slips Hot
 - 4L60-E/4L65-E 7-242
- Torque Converter (cont.)
 - Clutch Pulse Width Modulation Solenoid, TCC Solenoid and Wiring Harness
 - 4L60-E/4L65-E 7-284
 - Clutch Shudder
 - 4L60-E/4L65-E 7-241
 - Clutch Slip - 100 RPM Slip
 - 4L60-E/4L65-E 7-242
 - Clutch Slip With Stall/Stumble
 - 4L60-E/4L65-E 7-242
 - End Play Specifications
 - 4L60-E/4L65-E 7-59
 - No Torque Converter Clutch Apply
 - 4L60-E/4L65-E 7-241
 - No Torque Converter Clutch Release
 - 4L60-E/4L65-E 7-242
- Tracing Powder or Chalk Test 0-90
- Traction Control
 - Switch Replacement
 - ABS 5-196
- Traction Off Indicator
 - Always On
 - ABS 5-185
 - Inoperative
 - ABS 5-186
- Trailer Hitch
 - Replacement
 - Frame and Underbody 8-360
- Training 0-5
- Transmission
 - Clunk on Acceleration or Deceleration
 - Tremec 6 Speed 7-32
 - Does Not Shift into One Gear
 - Tremec 6 Speed 7-30
 - Fluid Checking Procedure
 - 4L60-E/4L65-E 7-213
 - Fluid Leak Diagnosis
 - Tremec 6 Speed 7-33
 - Fluid Level Inspection
 - Tremec 6 Speed 7-36
 - Fluid Pressure Manual Valve Position
 - Switch Logic
 - 4L60-E/4L65-E 7-60
 - Fluid Replacement
 - Tremec 6 Speed 7-41
 - Fluid Temperature Sensor Specifications
 - 4L60-E/4L65-E 7-57
 - Fluid/Filter Replacement
 - 4L60-E/4L65-E 7-256
 - Gear Clash When Shifting Gears
 - Tremec 6 Speed 7-25
 - High Frequency Rattle Sound or Buzz
 - Noise
 - 4L60-E/4L65-E 7-244
 - Jumps Out of Gear
 - Tremec 6 Speed 7-28
 - Locked in One Gear
 - Tremec 6 Speed 7-31
 - Noise
 - Tremec 6 Speed 7-27

- Transmission (cont.)
- Noise in Random Ranges
 - 4L60-E/4L65-E 7-244
 - Overheats
 - 4L60-E/4L65-E 7-234
 - Popping Noise
 - 4L60-E/4L65-E 7-244
 - Range Switch Logic
 - 4L60-E/4L65-E 7-60
 - Replacement
 - 4L60-E/4L65-E 7-300
 - Tremec 6 Speed 7-43
 - Shifts Hard
 - Tremec 6 Speed 7-23
 - Support Replacement
 - Frame and Underbody 8-353
 - Vent Tube Replacement
 - Tremec 6 Speed 7-42
 - Whine Varying with RPM or Fluid Pressure
 - 4L60-E/4L65-E 7-244
 - Transmission Adaptive Functions
 - 4L60-E/4L65-E 7-310
 - Transmission Component and System Description
 - 4L60-E/4L65-E 7-310
 - Transmission Extension Housing Assembly Replacement
 - 4L60-E/4L65-E 7-296
 - Rear Oil Seal Replacement
 - 4L60-E/4L65-E 7-295
 - Transmission Fluid Cooler
 - Hose/Pipe Replacement
 - 4L60-E/4L65-E 7-259
 - Transmission General Information
 - 4L60-E/4L65-E 7-305
 - Transmission Identification Information
 - 4L60-E/4L65-E 7-307
 - Transmission Mount
 - Replacement
 - 4L60-E/4L65-E 7-297
 - Transmission Oil Cooler Line
 - Quick Connect Fitting
 - 4L60-E/4L65-E 7-260
 - Transmitter
 - Battery Replacement
 - Keyless Entry 11-78
 - Programming
 - Keyless Entry 11-80
 - Tread Wear Indicators Description
 - Tire and Wheels 3-74
 - Trim Height
 - Inspection Procedure
 - Suspension General Diagnosis 3-11
 - Specifications
 - Suspension General Diagnosis 3-3
 - Trim Panel
 - Replacement
 - Instrument Panel - Left 8-454
 - Instrument Panel - Right 8-455
 - Replacement - Door 8-289
 - Trim Panel Replacement
 - Instrument Panel Center 8-441
 - Instrument Panel Upper 8-440
 - Retractable Roof Headliner
 - Interior Trim 8-500
 - Retractable Roof Headliner - Front
 - Interior Trim 8-497
 - Retractable Roof Headliner - Side
 - Interior Trim 8-499
 - Trim Plate
 - Replacement
 - Instrument Panel Upper 8-439
 - Trim Plate Replacement
 - Console Upper 8-476
 - Trim Replacement
 - Chrome Head Restraint - Seats 8-919
 - Hinge Pillar
 - Interior Trim 8-492
 - Lock Pillar
 - Interior Trim 8-492
 - Troubleshooting with a Digital Multimeter
 - Wiring Systems 8-989
 - Test Light
 - Wiring Systems 8-989
 - Truck Zoning
 - Wiring Systems 8-978
 - Turn Signal
 - Cancel Cam and Steering Shaft Upper Bearing Spring Replacement
 - Steering Wheel and Column 2-73
 - Cancel Cam and Upper Bearing Thrust Washer
 - Steering Wheel and Column 2-88
 - Turn Signal Lamps and/or Indicators
 - Always On or Flashing
 - Lighting Systems 8-593
 - Inoperative
 - Lighting Systems 8-594
 - Tyco/AMP Connectors
 - Wiring Systems 8-1022, 8-1023, 8-1024
- ## U
- Universal Joint
 - Noise
 - Propeller Shaft 4-4
 - Universal Joint Replacement
 - External Snap Ring
 - Propeller Shaft 4-10
 - Nylon Injected Ring
 - Propeller Shaft 4-7
 - Upper Engine Noise, Regardless of Engine Speed
 - Engine Mechanical - 6.0L 6-30
 - Urethane Adhesive Installation of Stationary Windows 8-943

V

Vacuum Brake Booster	
Check Valve and/or Hose Replacement	
Hydraulic Brakes	5-58
Replacement	
Hydraulic Brakes	5-56
Valve Body and Pressure Switch	
Replacement	
4L60-E/4L65-E	7-272
Valve Lifter	
Replacement	
Engine Mechanical - 6.0L	6-86
Valve Rocker Arm	
Cover Replacement - Left	
Engine Mechanical - 6.0L	6-67
Cover Replacement - Right	
Engine Mechanical - 6.0L	6-68
Valve Rocker Arm and Push Rod	
Replacement	
Engine Mechanical 6.0L	6-72
Valve Stem Oil Seal and Valve Spring	
Replacement	
Engine Mechanical - 6.0L	6-74
Vanity Mirror	
Lamp Bulb Replacement	
Lighting Systems	8-605
Lamps Inoperative	
Lighting Systems	8-596
Vehicle Leads/Pulls	
Suspension General Diagnosis	3-4
Vehicle Personalization	11-82
Vehicle Speed Sensor (VSS)	
Replacement	
4L60-E/4L65-E	7-297
Tremec 6 Speed	7-40
Vehicle Theft Deterrent (VTD) Description	
and Operation	11-126
Vehicle-to-Vehicle Diagnostic Comparison	
Vibration Diagnosis and Correction	0-54
Vent Hose	
Replacement	
Rear Drive Axle	4-27
Vibrate Software Description and Operation	
Vibration Diagnosis and Correction	0-88
Vibration	
Clutch	7-325
In Reverse and Whining Noise in Park	
4L60-E/4L65-E	7-243
Noise and Vibration Analysis	
4L60-E/4L65-E	7-221
Vibration Analysis	
Driveline	0-34
Engine	0-39
Engine Balance	0-47
Engine/Accessory Isolation	0-42
Hub and/or Axle Input	0-37
Road Testing	0-27
Tire and Wheel	0-32

Vibration Diagnostic Aids	0-51
Vibration Duplicated, Appears to be	
Potential Operating Characteristic	0-53
Vibration Duplicated, Component Not	
Identified	0-52
Vibration Duplicated, Difficult to	
Isolate/Balance Component	0-52
Vibration Intermittent or Not Duplicated	0-51
Vibration in Service-Stall Test	
Non-Torque Sensitive	0-63
Torque Sensitive	0-63
Vibration Theory and Terminology	
Vibration Diagnosis and Correction	0-78
Voltage Drop, Measuring	
Wiring Systems	8-990
Voltage, Measuring	
Wiring Systems	8-990

W

Wander Description	
Wheel Alignment	3-18
Washer	
Hose Replacement	
Windshield Washer	8-970
Pump Replacement	8-968
Solvent Container Replacement	8-967
Washers	
Always On	8-958
Inoperative	8-960
Water Deflector	
Replacement - Front Door	8-294
Water Hose Test	
Waterleaks	0-95
Water Management Description and	
Operation	8-32
Water Pump	
Replacement	
Engine Cooling	6-305
Waterleak	
Body Waterleak Repair	0-96
Test Preparation	0-93
Weatherstrip Replacement	
Door	8-330
Endgate - Mucket Side	8-95
Folding Top - Rear Panel, Lower	8-817
Folding Top Front Panel	8-819
Folding Top Rear Panel - Side	8-823
Folding Top Stowage Compartment Lid	8-826
Folding Top Stowage Compartment Lid	
Extension Panel, Front/Rear	8-824
Rear Compartment Lid	8-96
Rear Compartment Opening	8-97
Wheel Alignment	
Measuring	3-13
Specifications	3-13

- Wheel Bearing
 - Diagnosis
 - Suspension General Diagnosis 3-11
 - Hub, Knuckle, and Seal Replacement
 - Front Suspension 3-39
 - Wear
 - Rear Drive Axle 4-18, 4-20
 - Wheel Hub
 - Bearing, Knuckle, and Seal Replacement
 - Front Suspension 3-39
 - Wheel Mounting Surface Check 3-68
 - Wheel Speed Sensor
 - Replacement
 - ABS 5-191
 - Wheel Stud
 - Replacement
 - Front Suspension 3-39
 - Rear Suspension 3-65
 - Wheelhouse
 - Replacement - Front
 - Collision Repair 8-148
 - Replacement - Rear Outer
 - Collision Repair 8-191, 8-194
 - Wheelhouse Liner
 - Replacement - Front 8-26
 - Wheelhouse Liner Panel
 - Replacement - Rear 8-61
 - Wheels
 - Replacement Wheels Description 3-76
 - Whine or Growl Noise
 - Power Steering System 2-11
 - Wind Noise
 - Exterior 0-91
 - Windnoise
 - Interior 0-91
 - Window Height Adjustment
 - Door Minor 8-320
 - Window Regulator
 - Motor Replacement
 - Door 8-323
 - Replacement
 - Doors 8-320
 - Window Replacement
 - Door 8-325
 - Window Tip-In Adjustment - Door 8-318
 - Windshield
 - Frame, Header Panel Replacement - Front
 - Collision Repair 8-163
 - Frame, Header Panel Replacement - Front Inner
 - Collision Repair 8-167
 - Glass Cleaning
 - Wipers/Washer Systems 8-976
 - Replacement
 - Stationary Windows 8-940
 - Wiper
 - Arm Blade Replacement 8-972
 - Arm Replacement 8-971
 - Arm Tip Pressure Check 8-966
 - Blade Element Check 8-966
 - Blade Element Cleaning 8-976
 - Blade Element Replacement 8-973
 - Chatter Repair 8-976
 - Motor Replacement 8-973
 - Transmission Replacement 8-974
 - Washer Nozzle Replacement 8-970
 - Wipers
 - Always On 8-962
 - Inoperative - All Modes 8-963
 - Inoperative - One or More Modes 8-964
 - Wiper/Washer
 - System Description and Operation 8-976
 - Wire Insulation, Repairing Damaged
 - Wiring Systems 8-996
 - Wiring Harness
 - Replacement - Front Door 8-314
 - Wiring Repairs 8-996
 - Work Sheets, Diagnostic 0-5
- Y**
- Yazaki Connectors
 - Wiring Systems 8-1025

